

Panasonic®



Administrator Guide

Cell Station Unit (SIP)

Model No. KX-UDS124

Thank you for purchasing this Panasonic product.
Please read this manual carefully before using this product and save this manual for future use.

KX-UDS124: Software File Version 01.400 or later

KX-UDS124 : DECT 6.0 Cell Station Unit (SIP)
KX-UDS124CE : DECT Cell Station Unit (SIP)

In this manual, the suffix of each model number (e.g., KX-UDS124CE) is omitted unless necessary.

Introduction

Outline

This Administrator Guide provides detailed information on the configuration and management of this SIP Cell Station Unit (SIP-CS), which supports SIP-CS compatible Portable Stations (S-PSs).

Audience

This Administrator Guide contains explanations about the installation, maintenance, and management of the SIP-CS and is aimed at network administrators and dealers.

Technical descriptions are included in this guide. Prior knowledge of networking and VoIP (Voice over Internet Protocol) is required.

Related Documentation

Installation Guide

Briefly describes basic information about the installation of the SIP-CS.

Manuals and supporting information are provided on the Panasonic Web site at:

<http://www.panasonic.com/sip> (for users in the United States)

<http://panasonic.net/pcc/support/sipphone> (for users in all other countries/areas)

Technical Support

When technical support is required, contact your dealer.

Open Source Software Notice

Parts of this product use open source software. For details about the open source software, see **11.1 Open Source Software**.

Trademarks

- Microsoft, Excel, Internet Explorer, Outlook, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Mozilla and Firefox are registered trademarks of the Mozilla Foundation.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.
- All other trademarks identified herein are the property of their respective owners.

NOTES

- The screen shots shown in this guide are provided for reference only, and may differ from the screens displayed on your PC.
- The contents and design of the software are subject to change without notice.

Terminology

Air Sync Group

Air Synchronization Group

To obtain steady air synchronization over a wide area, it is necessary to create Air Sync Groups.

Air Sync Master CS

Primary Clock Master of an Air Sync Group

Each Air Sync Group must have a unique Air Sync Master.

Air Sync Secondary Master CS

Secondary Clock Master of an Air Sync Group

DECT

Digital Enhanced Cordless Telecommunication

Handover

Allows you to move between CS coverage areas during a conversation without disrupting the call.

This is only possible within the same Air Sync Group.

IPEI

International Portable Equipment Identity

Decimal, 12-digit, globally unique identification code of PSs. Specified in ETSI EN 300 175-6.

Primary CS

Primary CS for air synchronization

Roaming

Allows you to move between coverage areas of SIP-CSs (even inter-Air Sync Group or inter-SIP Server) when the S-PS is idle.

S-PS

SIP-CS compatible Portable Station/Handset

Secondary CS

Secondary CS for air synchronization

SIP-CS

SIP Cell Station

Super Master CS

Master CS of Air Sync Group 1

This CS manages configuration for the whole system.

Tree Survey

The procedure to obtain a steady air synchronization tree.

Table of Contents

1	Overview	19
1.1	Overview of Programming	20
2	Web User Interface Programming	21
2.1	Web User Interface Programming	22
2.1.1	Before Accessing the Web User Interface	22
2.1.2	Accessing the Web User Interface	24
2.1.3	Web User Interface Setting List	25
2.2	Status	50
2.2.1	Version Information	50
2.2.1.1	CS Version Information	50
	Model	50
	Operating Bank	50
	IPL Version	51
	Firmware Version	51
2.2.1.2	PS Version Information (Model 1)	51
	Model	51
	Firmware Version	51
2.2.1.3	PS Version Information (Model 2)	51
	Model	51
	Firmware Version	51
2.2.1.4	PS Version Information (Model 3)	52
	Model	52
	Firmware Version	52
2.2.2	Network Status	52
2.2.2.1	Network Status	52
	MAC Address	52
	Ethernet Link Status (LAN Port)	53
	Connection Mode	53
	IP Address	53
	Subnet Mask	53
	Default Gateway	53
	DNS1	54
	DNS2	54
2.2.3	CS Version List	54
2.2.3.1	CS Version List	54
	Air Sync Group	54
	CS Name	55
	CS ID	55
	MAC Address	55
	Firmware Version	55
2.2.4	CS Information	55
2.2.4.1	CS Information	56
	Air Sync Group	56
	CS Name	56
	CS ID	56
	MAC Address	56
	Status	57
	Path 1–16	57
	Regist PS Number	58
2.2.5	PS Information	58
2.2.5.1	PS Information	58

No.	58
PS Name	58
Model	59
Firmware Version	59
Phonebook Import Time [Result]	59
2.2.6 PS VoIP Status	59
2.2.6.1 PS VoIP Status	60
No.	60
PS Name	60
Location CS Name	60
Location CS MAC	60
Phone Number	61
VoIP Status	61
2.3 Network	61
2.3.1 Basic Network Settings	62
2.3.1.1 Connection Mode	62
Connection Mode	62
2.3.1.2 DHCP Settings	63
Host Name	63
Domain Name Server	63
2.3.1.3 Static Settings	64
Static IP Address	64
Subnet Mask	64
Default Gateway	64
DNS1	64
DNS2	65
2.3.1.4 Link Speed/Duplex Mode	65
LAN Port	65
2.3.1.5 LLDP Settings	65
Enable LLDP	65
LLDP-MED Interval timer	65
IP Phone (VLAN ID)	66
IP Phone (Priority)	66
2.3.1.6 VLAN Settings	66
Enable VLAN	66
IP Phone (VLAN ID)	66
IP Phone (Priority)	66
2.3.2 HTTP Client Settings	67
2.3.2.1 HTTP Client Settings	67
HTTP Version	67
HTTP User Agent	67
2.3.2.2 Proxy Server Settings	68
Enable Proxy	68
Proxy Server Address	68
Proxy Server Port	68
2.3.3 HTTP Authentication	68
2.3.3.1 HTTP Authentication	69
Authentication ID	69
Authentication Password	69
2.3.4 Global Address Detection	69
2.3.4.1 Global Address Detection	70
Detection Method	70
Detection Interval	70
2.3.4.2 STUN Server	70
STUN Server Address	70

Table of Contents

	STUN Server Port	71
2.3.5	Network Directory	71
2.3.5.1	Network Directory	71
	Xsi Server Address	71
	Xsi User ID	71
	Xsi User Password	71
	Phonebook Type	72
2.4	System	72
2.4.1	Web Language	72
2.4.1.1	Web Language	72
	Language	72
2.4.2	Administrator Password	73
2.4.2.1	Change Administrator Password	73
	Current Password	73
	New Password	74
	Confirm New Password	74
2.4.3	Change User Password	74
2.4.3.1	Change User Password	75
	No.	75
	PS Name	75
	Phone Number	75
2.4.3.2	Changing User Password	75
2.4.3.3	PS Name	75
	PS Name	75
2.4.3.4	Change User Password	76
	New Password	76
	Confirm New Password	76
2.4.4	Web Server Settings	76
2.4.4.1	Web Server Settings	76
	Web Server Port	76
	Port Close Timer	77
2.4.5	Time Setting	77
2.4.5.1	Time Setting	77
	Date	77
	Time	78
2.4.6	Time Adjust Settings	78
2.4.6.1	Synchronization	78
	Enable Synchronization by NTP	78
	Synchronization Interval	79
2.4.6.2	Time Server	79
	NTP Server Address	79
2.4.6.3	Time Zone	79
	Time Zone	79
2.4.6.4	Daylight Saving Time (Summer Time)	79
	Enable DST (Enable Summer Time)	79
	DST Offset (Summer Time Offset)	79
2.4.6.5	Start Day and Time of DST (Start Day and Time of Summer Time)	80
	Month	80
	Day of Week	80
	Time	81
2.4.6.6	End Day and Time of DST (End Day and Time of Summer Time)	81
	Month	81
	Day of Week	81
	Time	82
2.4.7	CS Name	82

2.4.7.1	CS Name82
	Name82
2.4.8	Air Settings82
2.4.8.1	Air Sync Group83
	Air Sync Group83
2.4.8.2	CS Class83
	CS Class83
2.4.8.3	Super Master CS IP Address84
	IP Address84
2.4.9	CS Management84
2.4.9.1	CS Registration85
	Air Sync Group85
	Number of CS85
2.4.9.2	CS Registered List85
	No.85
	Index85
	CS Name86
	CS ID86
	MAC Address86
	IP Address86
	CS Class86
2.4.10	Tree Survey87
2.4.10.1	Tree Survey87
	Air Sync Group87
2.4.10.2	Survey List88
	Index88
	CS Name88
	MAC Address88
	CS Class88
	Status88
	Primary CS Index89
	Secondary CS Index89
	Level89
2.4.11	CS Monitor89
2.4.11.1	CS Monitor90
	Air Sync Group90
	Index90
	RSSI90
	Error Rate91
	Wired LAN91
	CS Name91
	MAC Address91
	Status92
	Current Sync CS (CS Type)92
	Current Sync CS (CS RPT)92
	Current Sync CS (CS Index)92
2.4.12	PS Registration92
2.4.12.1	PS Registration93
	No.93
	PS Name93
	Phone Number93
	Wireless Status94
2.4.13	PS Registration - Start PS Registration94
2.4.14	PS Registration - Delete PS Registration94
2.4.15	PS Registration - PS Settings95

Table of Contents

2.4.15.1	PIN Code	95
	PIN Code	95
2.5	VoIP	95
2.5.1	SIP Settings	96
2.5.1.1	SIP Setting	96
	SIP User Agent	96
2.5.1.2	SIP Server	97
	Registrar Server Address	97
	Registrar Server Port	97
	Proxy Server Address	97
	Proxy Server Port	97
	Presence Server Address	98
	Presence Server Port	98
2.5.1.3	Outbound Proxy Server	98
	Outbound Proxy Server Address	98
	Outbound Proxy Server Port	98
2.5.1.4	SIP Service Domain	98
	Service Domain	98
2.5.1.5	DNS	99
	Enable DNS SRV lookup	99
	SRV lookup Prefix for UDP	99
	SRV lookup Prefix for TCP	99
2.5.1.6	Transport Protocol of SIP	99
	Transport Protocol	99
2.5.1.7	Timer Settings	100
	T1 Timer	100
	T2 Timer	100
	Timer B	100
	Timer D	100
	Timer F	101
	Timer H	101
	Timer J	101
2.5.1.8	Quality of Service (QoS)	101
	SIP Packet QoS (DSCP)	101
2.5.1.9	SIP extensions	101
	Supports 100rel (RFC 3262)	101
	Supports Session Timer (RFC 4028)	102
2.5.1.10	Security	102
	Enable SSAF (SIP Source Address Filter)	102
2.5.2	SIP Settings - PS	102
2.5.2.1	SIP Settings	103
	No.	103
	PS Name	103
	Line No.	103
	Phone Number	103
2.5.3	SIP Settings - PS [Line 1–2]	104
2.5.3.1	PS Name	104
	PS Name	104
2.5.3.2	Phone Number	104
	Phone Number	104
	SIP URI	105
2.5.3.3	SIP Authentication	105
	Authentication ID	105
	Authentication Password	105
2.5.3.4	SIP Source Port	105

	Source Port	105
2.5.4	VoIP Settings	106
2.5.4.1	RTP Settings	106
	RTP Packet Time	106
	Minimum RTP Port Number	107
	Maximum RTP Port Number	107
	Telephone-event Payload Type	107
2.5.4.2	Quality of Service (QoS)	108
	RTP Packet QoS (DSCP)	108
2.5.4.3	Statistical Information	108
	RTCP Enable	108
	RTCP Interval	108
2.5.4.4	Jitter Buffer	108
	Maximum Delay	108
	Minimum Delay	109
	Initial Delay	109
2.5.4.5	DTMF	109
	DTMF Type	109
2.5.4.6	Call Hold	109
	Supports RFC 2543 (c=0.0.0.0)	109
2.5.4.7	CODEC Preferences	110
	G722 (Enable)	110
	G722 (Priority)	110
	PCMA (Enable)	110
	PCMA (Priority)	110
	G726–32 (Enable)	111
	G726–32 (Priority)	111
	G729A (Enable)	111
	G729A (Priority)	111
	PCMU (Enable)	111
	PCMU (Priority)	111
2.6	Telephone	112
2.6.1	Call Control - Common	112
2.6.1.1	Call Control	113
	Send SUBSCRIBE to Voice Mail Server	113
	Conference Server URI	113
	Inter-digit Timeout	113
	Timer for Dial Plan	113
	International Call Prefix	114
	Country Calling Code	114
	National Access Code	114
	Flash/Recall Button	114
	Flash Hook Event	114
2.6.1.2	Call Rejection Phone Numbers	115
	1–30	115
2.6.2	Call Control - PS	115
2.6.2.1	Call Control	115
	No.	115
	PS Name	116
	Line No. 1–2	116
	Phone Number	116
2.6.3	Call Control [PS]	116
2.6.3.1	PS Name	117
	PS Name	117
2.6.3.2	Call Control	117

Table of Contents

2.6.3.3	Default Line for Outgoing	117
	Dial Plan	117
	Dial Plan (max 500 columns)	117
	Call Even If Dial Plan Does Not Match	117
2.6.4	Call Control [Line 1–2]	118
2.6.4.1	PS Name	118
	PS Name	118
2.6.4.2	Phone Number	119
	Phone Number	119
2.6.4.3	Call Control	119
	Display Name	119
	Voice Mail Access Number	119
	Enable Shared Call	119
	Synchronize Do Not Disturb and Call Forward	120
2.6.4.4	Call Features	120
	Block Caller ID	120
	Block Anonymous Call	120
	Do Not Disturb	121
2.6.4.5	Call Forward	121
	Unconditional (Enable Call Forward)	121
	Unconditional (Phone Number)	122
	Busy (Enable Call Forward)	122
	Busy (Phone Number)	123
	No Answer (Enable Call Forward)	123
	No Answer (Phone Number)	124
	No Answer (Ring Count)	124
2.6.5	Button Settings	124
2.6.5.1	Button Settings	125
	No	125
	PS Name	125
	Phone Number	125
2.6.6	Button Settings - PS	126
2.6.6.1	PS Name	126
	PS Name	126
2.6.6.2	Flexible Button Settings	126
	No	126
	Type (No. 1–12)	127
	Parameter (No. 1–12)	127
	Label Name (No. 1–12)	127
2.6.7	Button Settings - Copy & Paste	128
2.6.7.1	Copy Source PS Name	128
	PS Name	128
2.6.7.2	Copy Source Flexible Button Settings	128
	No	128
	Type (No. 1–12)	129
	Parameter (No. 1–12)	129
	Label Name (No. 1–12)	129
2.6.7.3	Copy Destination PS Lists	129
2.6.8	Tone Settings	130
2.6.8.1	Dial Tone	130
	Tone Frequencies	130
	Tone Timings	131
2.6.8.2	Busy Tone	131
	Tone Frequencies	131
	Tone Timings	131

2.6.8.3	Ringing Tone	132
	Tone Frequencies	132
	Tone Timings	132
2.6.8.4	Stutter Tone	132
	Tone Frequencies	132
	Tone Timings	132
2.6.8.5	Reorder Tone	133
	Tone Frequencies	133
	Tone Timings	133
2.6.9	Telephone Settings	133
2.6.9.1	Telephone Settings	133
	Number Matching Lower Digit	133
	Number Matching Upper Digit	134
2.6.10	Import Phonebook - All	134
2.6.10.1	Import Mode	134
	Mode Select	134
2.6.10.2	Import Time Setting	135
	Date	135
	Time	135
2.6.10.3	Import Phonebook	135
	File Name	135
2.6.11	Import Phonebook - PS	135
2.6.11.1	Import Phonebook	136
	No.	136
	PS Name	136
	Phone Number	136
2.6.12	Import Phonebook (PS select screen)	137
2.6.12.1	PS Name	137
	PS Name	137
2.6.12.2	Import Phonebook	137
	File Name	137
2.6.13	Export Phonebook - PS	137
2.6.13.1	Export Phonebook	138
	PS Name	138
	Phone Number	138
2.7	Maintenance	138
2.7.1	Backup	139
2.7.2	Restore	139
2.7.3	Firmware Maintenance	140
2.7.3.1	Firmware Maintenance	140
	Enable Firmware Update	140
	Firmware File URL	140
	PS Update Type	141
2.7.4	All Firmware Update	141
2.7.4.1	Update Mode	142
	Mode	142
2.7.4.2	Update Time Setting	142
	Date	142
	Time	142
2.7.4.3	Update Firmware	142
	Encryption	142
	File Name	142
2.7.5	Provisioning Maintenance	143
2.7.5.1	Provisioning Maintenance	144
	Enable Provisioning	144

Table of Contents

Standard File URL	144
Product File URL	144
Master File URL	144
System File URL	145
Cyclic Auto Resync	145
Resync Interval	145
Header Value for Resync Event	145
2.7.6 Error Log	146
2.7.7 Restart	146
3 General Information on Provisioning	147
3.1 Pre-provisioning	148
3.1.1 What is Pre-provisioning?	148
3.1.2 Pre-provisioning when Setting Static IP Addresses	148
3.1.3 Server for Pre-provisioning	149
3.1.4 Pre-provisioning Setting Example	149
3.2 Provisioning	152
3.2.1 What is Provisioning?	152
3.2.2 Protocols for Provisioning	152
3.2.3 Configuration File	152
3.2.4 Downloading Configuration Files	154
3.2.5 Provisioning Server Setting Example	157
3.2.6 Encryption	158
3.3 Priority of Setting Methods	159
3.4 Configuration File Specifications	160
3.5 Configuration File Examples	161
3.5.1 Examples of Codec Settings	161
3.5.2 Example with Incorrect Descriptions	162
4 Configuration File Programming	165
4.1 General Information on the Configuration Files	166
4.1.1 Configuration File Parameters	166
4.1.2 Characters Available for String Values	167
4.2 System Settings	167
4.2.1 Login Account Settings	167
ADMIN_ID	167
ADMIN_PASS	167
USER_PASS_PSY	168
4.2.2 System Time Settings	168
TIME_ZONE	168
DST_ENABLE	168
DST_OFFSET	169
DST_START_MONTH	169
DST_START_ORDINAL_DAY	169
DST_START_DAY_OF_WEEK	170
DST_START_TIME	170
DST_STOP_MONTH	171
DST_STOP_ORDINAL_DAY	171
DST_STOP_DAY_OF_WEEK	171
DST_STOP_TIME	172
LOCAL_TIME_ZONE_POSIX	172
4.2.3 Syslog Settings	173
SYSLOG_EVENT_SIP	173
SYSLOG_EVENT_CFG	173
SYSLOG_EVENT_VOIP	173

SYSLOG_EVENT_TEL	173
SYSLOG_ADDR	174
SYSLOG_PORT	174
SYSLOG_RTPSMLY_INVL	174
4.2.4 Firmware Update Settings	174
FIRM_UPGRADE_ENABLE	174
FIRM_VERSION	175
PS_FIRM_UPGRADE_AUTO	175
FIRM_FILE_PATH	175
4.2.5 Provisioning Settings	176
OPTION66_ENABLE	176
OPTION66_REBOOT	176
PROVISION_ENABLE	177
CFG_STANDARD_FILE_PATH	177
CFG_PRODUCT_FILE_PATH	178
CFG_MASTER_FILE_PATH	179
CFG_SYSTEM_FILE_PATH	180
CFG_FILE_KEY1	181
CFG_FILE_KEY2	182
CFG_FILE_KEY3	182
CFG_FILE_KEY4	182
CFG_FILE_KEY_LENGTH	183
CFG_CYCLIC	183
CFG_CYCLIC_INVL	183
CFG_RTRY_INVL	183
CFG_RESYNC_TIME	184
CFG_RESYNC_FROM_SIP	184
4.2.6 Other Settings	184
IPEI_PSy	184
SIP_REGI_PS_LIMIT	184
PROVISION_SUPERMASTER_ONLY	185
PS_FIRM_UPGRADE_MODE	185
4.3 Network Settings	186
4.3.1 IP Settings	186
CONNECTION_TYPE	186
HOST_NAME	186
DHCP_DNS_ENABLE	186
STATIC_IP_ADDRESS	187
STATIC_SUBNET	187
STATIC_GATEWAY	187
USER_DNS1_ADDR	188
USER_DNS2_ADDR	188
4.3.2 DNS Settings	188
DNS_QRY_PRLL	188
DNS_PRIORITY	189
DNS1_ADDR	189
DNS2_ADDR	189
4.3.3 Ethernet Port Settings	189
LLDP_ENABLE	189
LLDP_INTERVAL	190
VLAN_ENABLE	190
VLAN_ID_IP_PHONE	190
VLAN_PRI_IP_PHONE	190
4.3.4 HTTP Settings	190
HTTPD_PORTOPEN_AUTO	190

Table of Contents

	HTTP_VER	191
	HTTP_USER_AGENT	191
	HTTP_SSL_VERIFY	192
	CFG_ROOT_CERTIFICATE_PATH	192
4.3.5	Time Adjust Settings	193
	NTP_ADDR	193
	TIME_SYNC_INTVL	193
	TIME_QUERY_INTVL	193
4.3.6	STUN Settings	193
	STUN_SERV_ADDR	193
	STUN_SERV_PORT	193
	STUN_2NDSERV_ADDR	194
	STUN_2NDSERV_PORT	194
4.3.7	Xsi Server Settings	194
	XSI_SERVER	194
	XSI_USERID	194
	XSI_PASSWORD	195
	XSI_PHONEBOOK_TYPE	195
4.4	Telephone Settings	195
4.4.1	Call Control Settings	195
	VM_SUBSCRIBE_ENABLE	195
	CONFERENCE_SERVER_URI	195
	FIRSTDIGIT_TIM	196
	INTDIGIT_TIM	196
	MACRODIGIT_TIM	196
	INTERNATIONAL_ACCESS_CODE	197
	COUNTRY_CALLING_CODE	197
	NATIONAL_ACCESS_CODE	197
	DEFAULT_LINE_SELECT_PSY	197
	HOLD_RECALL_TIM	197
	AUTO_CALL_HOLD	198
	DISCONNECTION_MODE	198
	TONE_LEN_DISCONNECT_HANDSFREE	198
4.4.2	Tone Settings	198
	DIAL_TONE1_FRQ	198
	DIAL_TONE1_GAIN	199
	DIAL_TONE1_RPT	199
	DIAL_TONE1_TIMING	199
	DIAL_TONE2_FRQ	199
	DIAL_TONE2_GAIN	200
	DIAL_TONE2_RPT	200
	DIAL_TONE2_TIMING	200
	DIAL_TONE4_FRQ	200
	DIAL_TONE4_GAIN	201
	DIAL_TONE4_RPT	201
	DIAL_TONE4_TIMING	201
	BUSY_TONE_FRQ	201
	BUSY_TONE_GAIN	202
	BUSY_TONE_RPT	202
	BUSY_TONE_TIMING	202
	REORDER_TONE_FRQ	202
	REORDER_TONE_GAIN	202
	REORDER_TONE_RPT	203
	REORDER_TONE_TIMING	203
	RINGBACK_TONE_FRQ	203

RINGBACK_TONE_GAIN	203
RINGBACK_TONE_RPT	204
RINGBACK_TONE_TIMING	204
HOLD_TONE_FRQ	204
HOLD_TONE_GAIN	204
BELL_CORE_PATTERN1_TIMING	205
BELL_CORE_PATTERN2_TIMING	205
BELL_CORE_PATTERN3_TIMING	205
BELL_CORE_PATTERN4_TIMING	205
BELL_CORE_PATTERN5_TIMING	206
4.4.3 Telephone Settings	206
NUMBER_MATCHING_LOWER_DIGIT	206
NUMBER_MATCHING_UPPER_DIGIT	206
DEFAULT_LANGUAGE	207
POUND_KEY_DELIMITER_ENABLE	207
FLEXIBLE_KEY_LIST_DISPLAY_TIMER	207
4.4.4 SIP-CS Settings	208
WL_PSREGISTRATION_PIN	208
WL_AIRSYNCGROUP_CS	208
SUPERMASTER_IPADDRESS_CS	208
WL_CLASS_CS	208
HO_RTP_PORT_MIN	209
HO_RTP_PORT_MAX	209
HO_EXE_TIME	209
4.4.5 Flexible Button Settings	210
FLEX_BUTTON_FACILITY_ACTx_PSy	210
FLEX_BUTTON_FACILITY_ARGx_PSy	210
FLEX_BUTTON_QUICK_DIALx_PSy	210
FLEX_BUTTON_LABELx_PSy	211
4.5 VoIP Settings	211
4.5.1 Codec Settings	211
CODEC_G711_REQ	211
CODEC_G729_PARAM	211
CODEC_ENABLEx	211
CODEC_PRIORITYx	212
4.5.2 RTP Settings	212
DSCP_RTP	212
DSCP_RTCP	213
RTCP_INVL	213
MAX_DELAY	213
MIN_DELAY	213
NOM_DELAY	214
RTP_PORT_MIN	214
RTP_PORT_MAX	214
RTP_PTIME	215
RTCP_ENABLE	215
RTCP_SEND_BY_SDP	215
RTP_CLOSE_ENABLE	215
4.5.3 Miscellaneous VoIP Settings	216
OUTBANDDTMF	216
DTMF_RELAY	216
OUTBANDDTMF_VOL	216
INBANDDTMF_VOL	216
TELEVENT_PAYLOAD	217
RFC2543_HOLD_ENABLE	217

Table of Contents

	DTMF_SIGNAL_LEN	217
	DTMF_INTDIGIT_TIM	217
4.6	Line Settings	218
4.6.1	Call Control Settings	218
	DISPLAY_NAME_PSy_n	218
	VM_NUMBER_PSy_n	218
	DIAL_PLAN_PSy	218
	DIAL_PLAN_NOT_MATCH_ENABLE_PSy	219
	SHARED_CALL_ENABLE_PSy_n	219
	FWD_DND_SYNCHRO_ENABLE_PSy_n	220
	CW_ENABLE_PSy_n	220
	RETURN_VOL_SET_DEFAULT_ENABLE	220
	FLASH_RECALL_TERMINATE	221
	FLASHHOOK_CONTENT_TYPE	221
	VOICE_MESSAGE_AVAILABLE	221
	HOLD_SOUND_PATH	221
4.6.2	SIP Settings	222
	SIP_USER_AGENT	222
	PHONE_NUMBER_PSy_n	222
	SIP_URI_PSy_n	223
	LINE_ENABLE_PSy_n	223
	PROFILE_ENABLE_PSy	224
	PROFILE_NAME_CS	224
	PROFILE_NAME_PSy	224
	SIP_AUTHID_PSy_n	224
	SIP_PASS_PSy_n	224
	SIP_SRC_PORT_PSy_n	225
	SIP_PRXY_ADDR	225
	SIP_PRXY_PORT	225
	SIP_RGSTR_ADDR	226
	SIP_RGSTR_PORT	226
	SIP_SVCDOMAIN	226
	REG_EXPIRE_TIME	226
	REG_INTERVAL_RATE	226
	SIP_SESSION_TIME	227
	SIP_SESSION_METHOD	227
	DSCP_SIP	227
	SIP_2NDPROXY_ADDR	227
	SIP_2NDPROXY_PORT	227
	SIP_2NDRGSTR_ADDR	228
	SIP_2NDRGSTR_PORT	228
	SIP_TIMER_T1	228
	SIP_TIMER_T2	228
	SIP_TIMER_T4	229
	SIP_FOVR_NORSP	229
	SIP_FOVR_MAX	229
	SIP_REFRESH	230
	SIP_DNSSRV_ENA	230
	SIP_UDP_SRV_PREFIX	230
	SIP_TCP_SRV_PREFIX	230
	SIP_100REL_ENABLE	231
	SIP_INVITE_EXPIRE	231
	SIP_18X_RTX_INTVL	231
	SIP_PRSNC_ADDR	232
	SIP_PRSNC_PORT	232

SIP_2NDPRSNC_ADDR	232
SIP_2NDPRSNC_PORT	232
USE_DEL_REG_OPEN	232
PORT_PUNCH_INTVL	233
SIP_ADD_RPORT	233
SIP_REQURI_PORT	233
SIP_SUBS_EXPIRE	234
SUB_RTX_INTVL	234
REG_RTX_INTVL	234
SIP_P_PREFERRED_ID	234
SIP_PRIVACY	235
ADD_USER_PHONE	235
SDP_USER_ID	235
SUB_INTERVAL_RATE	235
SIP_OUTPROXY_ADDR	236
SIP_OUTPROXY_PORT	236
SIP_TRANSPORT	236
SIP_ANM_DISPNAME	236
SIP_ANM_USERNAME	236
SIP_ANM_HOSTNAME	237
SIP_DETECT_SSAF	237
SIP_RCV_DET_HEADER	237
SIP_CONTACT_ON_ACK	238
SIP_TIMER_B	238
SIP_TIMER_D	238
SIP_TIMER_F	238
SIP_TIMER_H	239
SIP_TIMER_J	239
ADD_TRANSPORT_UDP	239
ADD_EXPIRES_HEADER	239
SIP_HOLD_HOLDRECEIVE	239
SIP_ADD_DIVERSION	240
SIP_RESPONSE_CODE_DND	240
SIP_RESPONSE_CODE_CALL_REJECT	240
SIP_FOVR_MODE	240
SIP_FOVR_DURATION	241
SIP_403_REG_SUB_RTX	241
CSL_PC_LISTEN_PORT	241
5 PS Registration	243
5.1 PS Registration from Web User Interface	244
5.2 PS Registration using Provisioning	250
6 Useful Telephone Functions	253
6.1 Phonebook Import and Export	254
6.1.1 Import/Export Operation	256
6.1.2 Editing with Microsoft Excel	257
6.1.3 Exporting Data from Microsoft Outlook	260
6.2 Dial Plan	260
6.2.1 Dial Plan Settings	261
6.3 Flexible Buttons	264
6.3.1 Flexible Button Settings	264
6.4 Copying Flexible Button Settings to Other S-PSs	265
7 Firmware Update	267

Table of Contents

7.1	Firmware Update Overview	268
7.2	Firmware Server Setup	269
7.3	Firmware Update Settings	269
7.4	Executing Firmware Update	270
7.5	Local Firmware Update	271
8	How to Backup and Restore Configurations	273
8.1	How to back up and restore configuration data	274
9	Resetting to Factory Default	277
9.1	Resetting to Factory Default	278
10	Troubleshooting	279
10.1	Troubleshooting	280
11	Appendix	283
11.1	Open Source Software	284
11.2	Revision History	288
11.2.1	KX-UDS124 Software File Version 01.400	288
Index.....		289

Section 1

Overview

This section provides an overview of the programming of the SIP-CS.


1.1 Overview of Programming

There are 2 types of programming, as shown in the table below:

Programming Type	Description	References
Web user interface programming	Configuring the SIP-CSs settings by accessing the Web user interface from a PC connected to the same network.	→ Section 2 Web User Interface Programming
Configuration file programming	Configuring the SIP-CSs settings beforehand by creating configuration files (pre-provisioning), and having the SIP-CS download the files from a server on the Internet and configure its own settings (provisioning).	→ Section 3 General Information on Provisioning → Section 4 Configuration File Programming

All programming is controlled by the Super Master CS. When programming is performed on the Super Master CS, all necessary configuration data is distributed to all other Air Sync Master CSs and Slave CSs.

For details about the different types of SIP-CSs, refer to the Installation Guide on the Panasonic Web site (→ see **Introduction**).




Section 2

Web User Interface Programming

This section provides information about the settings available in the Web user interface.

2.1 Web User Interface Programming

After connecting the SIP-CS (Super Master CS) to your network, you can configure the SIP-CS's settings by accessing the Web user interface from a PC connected to the same network.



2.1.1 Before Accessing the Web User Interface

Account Login ID and Password

Access to the Web user interface requires the following login ID and password:

Account	ID (default)	Password (default)	Password Restrictions
Administrator	admin	adminpass	<ul style="list-style-type: none">You can change the password (→ see 2.4.2 Administrator Password).The password can consist of 6 to 16 ASCII characters (case-sensitive).

Notice

- You cannot log in to the Web user interface using the same account as someone who is already logged in.
- The ID can be changed through configuration file programming (→ see "**ADMIN_ID**" in **4.2.1 Login Account Settings**).
- You can reset the account ID and password to their factory default settings by pressing the RESET switch on the back of the SIP-CS. For details, see **9.1 Resetting to Factory Default**.

Recommended Environment

This SIP-CS supports the following specifications:

HTTP Version	HTTP/1.0 (RFC 1945), HTTP/1.1 (RFC 2616)
Authentication Method	Digest (or Basic)

The Web user interface will operate correctly in the following environments:

Operating System	Microsoft® Windows® XP or Windows 7 operating system (32 bit)
Web Browser	Windows Internet Explorer® 7, Windows Internet Explorer 8, Windows Internet Explorer 9, or Mozilla® Firefox® web browser
Language (recommended)	English

Opening the Web Port

To access the Web user interface, you must open the SIP-CS's Web port beforehand.

Note

- If there are no registered S-PSs, the SIP-CS's Web port is always open.

- Turn on the S-PS.
- Press **[FIELD] / [MENU]** or the **[CENTER]** navigation key.



- Select **(Setting Handset)** ("Setting Handset") and then press **OK**.



- Press **NEXT**.




- Select "System Option" and then press **OK**.
The "System Option" menu is displayed.

2.1.2 Accessing the Web User Interface

Note

- You may need to enter a system password to access this menu.



6. Press **NEXT** to display the second screen, select "Enable CS Web", and then press **OK**.
7. When the operation is complete, the following screen is displayed.



Note

- You can access the Web with a fixed IP address without a registered S-PS by following the procedure below.
 1. Turn on SIP-CS by holding the RESET switch.
 2. After the LED flashes red, amber and green alternately, release the RESET switch.The default IP address and subnet mask are as follows:
 - IP address: 192.168.0.241
 - Subnet mask: 255.255.255.0- When accessing the Web with a fixed IP address, the VLAN feature will be turned off.

2.1.2 Accessing the Web User Interface


The SIP-CS can be configured from the Web user interface.

To access the Web user interface

1. Determine the Master CS's IP address.
If the Master CS's IP address is already known, skip this step and proceed to step **2**.
 - a. Enter the "Setting Handset" menu on your S-PS (→ see **Opening the Web Port**).
 - b. Select "Other Option" and then press **OK**.



- c. Select "MasterCS Address" and then press **OK**.

[Example]

2. Open your Web browser, and then enter "http://" followed by the SIP-CS's IP address into the address field of your browser.
3. Log in to the SIP-CS as the administrator.

Note

- The default ID and password for the administrator are as follows:
 - ID: admin
 - Password: adminpass

4. The Web user interface window is displayed. Configure the settings for the SIP-CS as desired.
5. You can log out from the Web user interface at any time by clicking [**Web Port Close**].

2.1.3 Web User Interface Setting List

The following tables show all the settings that you can configure from the Web user interface. For details about each setting, see the reference pages listed.

IMPORTANT

Please note that all screens are available when accessing the Web user interface for a Super Master CS. However, some screens are not available when accessing the Web user interface for an Air Sync Master CS or a Slave CS.

Status

Version Information

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Version Information	Model	50	—	—
	Operating Bank	50	—	—
	IPL Version	51	—	—
	Firmware Version	51	—	—
PS Version Information (Model 1)	Model	51	—	—
	Firmware Version	51	—	—
PS Version Information (Model 2)	Model	51	—	—
	Firmware Version	51	—	—
PS Version Information (Model 3)	Model	52	—	—
	Firmware Version	52	—	—

2.1.3 Web User Interface Setting List

Network Status

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Network Status	MAC Address	52	—	—
	Ethernet Link Status (LAN Port)	53	—	—
	Connection Mode	53	—	—
	IP Address	53	—	—
	Subnet Mask	53	—	—
	Default Gateway	53	—	—
	DNS1	54	—	—
	DNS2	54	—	—

CS Version List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Version List	Air Sync Group	54	—	—
	CS Name	55	—	—
	CS ID	55	—	—
	MAC Address	55	—	—
	Firmware Version	55	—	—

CS Information

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Information	Air Sync Group	56	—	—
	CS Name	56	—	—
	CS ID	56	—	—
	MAC Address	56	—	—
	Status	57	—	—
	Path 1–16	57	—	—
	Regist PS Number	58	—	—

PS Information

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen	—	—	—	—
PS Information	No.	58	—	—
	PS Name	58	PROFILE_NAME_PSy	224
	Model	59	—	—
	Firmware Version	59	—	—
	Phonebook Import Time [Result]	59	—	—

PS VoIP Status

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen	—	—	—	—
PS VoIP Status	No.	60	—	—
	PS Name	60	PROFILE_NAME_PSy	224
	Location CS Name	60	—	—
	Location CS MAC	60	—	—
	Phone Number	61	PHONE_NUMBER_PSy_n	222
	VoIP Status	61	—	—

Network

Basic Network Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Connection Mode	Connection Mode	62	CONNECTION_TYPE	186
DHCP Settings	Host Name	63	HOST_NAME	186
	Domain Name Server	63	DHCP_DNS_ENABLE	186
			DNS1_ADDR	189
			DNS2_ADDR	189

2.1.3 Web User Interface Setting List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Static Settings	Static IP Address	64	STATIC_IP_ADDRESS	187
	Subnet Mask	64	STATIC_SUBNET	187
	Default Gateway	64	STATIC_GATEWAY	187
	DNS1	64	USER_DNS1_ADDR	188
	DNS2	65	USER_DNS2_ADDR	188
Link Speed/Duplex Mode	LAN Port	65	—	—
LLDP Settings	Enable LLDP	65	LLDP_ENABLE	189
	LLDP-MED Interval timer	65	LLDP_INTERVAL	190
	IP Phone	—	—	—
	VLAN ID	—	—	—
	Priority	—	—	—
VLAN Settings	Enable VLAN	66	VLAN_ENABLE	189
	IP Phone	—	—	—
	VLAN ID	66	VLAN_ID_IP_PHONE	190
	Priority	66	VLAN_PRI_IP_PHONE	190

HTTP Client Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
HTTP Client Settings	HTTP Version	67	HTTP_VER	191
	HTTP User Agent	67	HTTP_USER_AGENT	191
Proxy Server Settings	Enable Proxy	68	—	—
	Proxy Server Address	68	—	—
	Proxy Server Port	68	—	—

HTTP Authentication

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
HTTP Authentication	Authentication ID	69	—	—
	Authentication Password	69	—	—

Global Address Detection

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Global Address Detection	Detection Method	70	—	—
	Detection Interval	70	—	—
STUN Server	STUN Server Address	70	STUN_SERV_ADDR	193
	STUN Server Port	71	STUN_SERV_PORT	193

System

Web Language

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Web Language	Language	72	—	—

Administrator Password

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Change Administrator Password	Current Password	73	ADMIN_PASS	167
	New Password	74	ADMIN_PASS	167
	Confirm New Password	74	ADMIN_PASS	167

Change User Password

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen	—	—	—	—
Change User Password	No.	75	—	—
	PS Name	75	PROFILE_NAME_PSy	224
	Phone Number	75	PHONE_NUMBER_PSy_n	222
PS select screen	—	—	—	—
PS Name	PS Name	75	PROFILE_NAME_PSy	224
Change User Password	New Password	76	USER_PASS_PSy	168
	Confirm New Password	76	USER_PASS_PSy	168

2.1.3 Web User Interface Setting List

Web Server Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Web Server Settings	Web Server Port	76	—	—
	Port Close Timer	77	—	—

Time Setting

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Time Setting	Date	—	—	—
	Date	77	—	—
	Month	77	—	—
	Year	77	—	—
	Time	—	—	—
	Hour	78	—	—
	Minute	78	—	—

Time Adjust Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Synchronization	Enable Synchronization by NTP	78	—	—
	Synchronization Interval	79	TIME_QUERY_INVL	193
Time Server	NTP Server Address	79	NTP_ADDR	193
Time Zone	Time Zone	79	TIME_ZONE	168
Daylight Saving Time (Summer Time)	Enable DST (Enable Summer Time)	79	DST_ENABLE	168
	DST Offset (Summer Time Offset)	79	DST_OFFSET	169
Start Day and Time of DST (Start Day and Time of Summer Time)	Month	80	DST_START_MONTH	169
	Day of Week	80	DST_START_ORDINAL_DAY DST_START_DAY_OF_WEEK	169, 170
	Time	81	DST_START_TIME	170

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
End Day and Time of DST (End Day and Time of Summer Time)	Month	81	DST_STOP_MONTH	171
	Day of Week	81	DST_STOP_ORDINAL_DAY DST_STOP_DAY_OF_WEEK	171, 171
	Time	82	DST_STOP_TIME	172

CS Name

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Name	Name	82	PROFILE_NAME_CS	224

Air Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Air Sync Group	Air Sync Group	83	WL_AIRSYNCGROUP_CS	208
CS Class	CS Class	83	WL_CLASS_CS	208
Super Master CS IP Address	IP Address	84	SUPERMASTER_IPADDRESS_CS	208

CS Management

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Registration	Air Sync Group	85	—	—
	Number of CS	85	—	—
CS Registered List	No.	85	—	—
	Index	85	—	—
	CS Name	86	—	—
	CS ID	86	—	—
	MAC Address	86	—	—
	IP Address	86	—	—
	CS Class	86	—	—

2.1.3 Web User Interface Setting List

Tree Survey

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Tree Survey	Air Sync Group	87	—	—
Survey List	Index	88	—	—
	CS Name	88	—	—
	MAC Address	88	—	—
	CS Class	88	—	—
	Status	88	—	—
	Primary CS Index	89	—	—
	Secondary CS Index	89	—	—
	Level	89	—	—

CS Monitor

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CS Monitor	Air Sync Group	90	—	—
	Index	90	—	—
	RSSI	90	—	—
	Error Rate	91	—	—
	Wired LAN	91	—	—
	CS Name	91	—	—
	MAC Address	91	—	—
	Status	92	—	—
	Current Sync CS	—	—	—
	CS Type	92	—	—
	CS RPT	92	—	—
	CS Index	92	—	—

PS Registration

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen	—	—	—	—

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS Registration	No.	93	—	—
	PS Name	93	PROFILE_NAME_PSy	224
	Phone Number	93	PHONE_NUMBER_PSy_n	222
	Wireless Status	94	—	—

PS Registration - Start PS Registration

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS Lists		94	—	—

PS Registration - Delete PS Registration

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS Lists		94	—	—

PS Registration - PS Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PIN Code	PIN Code	95	WL_PSREGISTRATION_PIN	208

VoIP

SIP Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
SIP Setting	SIP User Agent	96	SIP_USER_AGENT	222

2.1.3 Web User Interface Setting List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
SIP Server	Registrar Server Address	97	SIP_RGSTR_ADDR	226
	Registrar Server Port	97	SIP_RGSTR_PORT	226
	Proxy Server Address	97	SIP_PRXY_ADDR	225
	Proxy Server Port	97	SIP_PRXY_PORT	225
	Presence Server Address	98	SIP_PRSNC_ADDR	232
	Presence Server Port	98	SIP_PRSNC_PORT	232
Outbound Proxy Server	Outbound Proxy Server Address	98	SIP_OUTPROXY_ADDR	236
	Outbound Proxy Server Port	98	SIP_OUTPROXY_PORT	236
SIP Service Domain	Service Domain	98	SIP_SVCDOMAIN	226
DNS	Enable DNS SRV lookup	99	SIP_DNSSRV_ENA	230
	SRV lookup Prefix for UDP	99	SIP_UDP_SRV_PREFIX	230
	SRV lookup Prefix for TCP	99	SIP_TCP_SRV_PREFIX	230
Transport Protocol of SIP	Transport Protocol	99	SIP_TRANSPORT	236
Timer Settings	T1 Timer	100	SIP_TIMER_T1	228
	T2 Timer	100	SIP_TIMER_T2	228
	Timer B	100	SIP_TIMER_B	238
	Timer D	100	SIP_TIMER_D	238
	Timer F	101	SIP_TIMER_F	238
	Timer H	101	SIP_TIMER_H	239
	Timer J	101	SIP_TIMER_J	239
Quality of Service (QoS)	SIP Packet QoS (DSCP)	101	DSCP_SIP	227
SIP extensions	Supports 100rel (RFC 3262)	101	SIP_100REL_ENABLE	231
	Supports Session Timer (RFC 4028)	102	SIP_SESSION_TIME	227
Security	Enable SSAF (SIP Source Address Filter)	102	SIP_DETECT_SSAF	237

SIP Settings - PS

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen		—	—	—

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
SIP Settings	No.	103	—	—
	PS Name	103	PROFILE_NAME_PSy	224
	Line No.	103	—	—
	Phone Number	103	PHONE_NUMBER_PSy_n	222
PS select screen		—	—	—
PS Name	PS Name	104	PROFILE_NAME_PSy	224
Phone Number	Phone Number	104	PHONE_NUMBER_PSy_n	222
	SIP URI	105	SIP_URI_PSy_n	223
SIP Authentication	Authentication ID	105	SIP_AUTHID_PSy_n	224
	Authentication Password	105	SIP_PASS_PSy_n	224
SIP Source Port	Source Port	105	SIP_SRC_PORT_PSy_n	225

VoIP Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
RTP Settings	RTP Packet Time	106	RTP_PTIME	215
	Minimum RTP Port Number	107	RTP_PORT_MIN	214
	Maximum RTP Port Number	107	RTP_PORT_MAX	214
	Telephone-event Payload Type	107	TELEVENT_PAYLOAD	217
Quality of Service (QoS)	RTP Packet QoS (DSCP)	108	DSCP_RTP	212
Statistical Information	RTCP Enable	108	RTCP_ENABLE	215
	RTCP Interval	108	RTCP_INTVL	213
Jitter Buffer	Maximum Delay	108	MAX_DELAY	213
	Minimum Delay	109	MIN_DELAY	213
	Initial Delay	109	NOM_DELAY	214
DTMF	DTMF Type	109	OUTBANDDTMF	216
Call Hold	Supports RFC 2543 (c=0.0.0.0)	109	RFC2543_HOLD_ENABLE	217

2.1.3 Web User Interface Setting List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
CODEC Preferences	G722	—	—	—
	Enable	110	CODEC_ENABLEx	211
	Priority	110	CODEC_PRIORITYx	212
	PCMA	—	—	—
	Enable	110	CODEC_ENABLEx	211
	Priority	110	CODEC_PRIORITYx	212
	G726-32	—	—	—
	Enable	111	CODEC_ENABLEx	211
	Priority	111	CODEC_PRIORITYx	212
	G729A	—	—	—
	Enable	111	CODEC_ENABLEx	211
	Priority	111	CODEC_PRIORITYx	212
	PCMU	—	—	—
	Enable	111	CODEC_ENABLEx	211
	Priority	111	CODEC_PRIORITYx	212

Telephone

Call Control

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Common tab screen	—	—	—	—

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Call Control	Send SUBSCRIBE to Voice Mail Server	113	VM_SUBSCRIBE_ENABL_E	195
	Conference Server URI	113	CONFERENCE_SERVER_URI	195
	Inter-digit Timeout	113	INTDIGIT_TIM	196
	Timer for Dial Plan	113	MACRODIGIT_TIM	196
	International Call Prefix	114	INTERNATIONAL_ACCE_SS_CODE	197
	Country Calling Code	114	COUNTRY_CALLING_CODE	197
	National Access Code	114	NATIONAL_ACCESS_CODE	197
	Flash/Recall Button	114	FLASH_RECALL_TERMINATE	221
Call Rejection Phone Numbers	Flash Hook Event	114	FLASHHOOK_CONTENT_TYPE	221
	1–30	115	—	—
PS tab screen		—	—	—
Call Control	No.	115	—	—
	PS Name	116	PROFILE_NAME_PSy	224
	Line No. 1–2	116	—	—
	Phone Number	116	PHONE_NUMBER_PSy_n	222
PS select screen		—	—	—
PS Name	PS Name	117	PROFILE_NAME_PSy	224
Call Control	Default Line for Outgoing	117	DEFAULT_LINE_SELECT_PSy	197
Dial Plan	Dial Plan (max 500 columns)	117	DIAL_PLAN_PSy	218
	Call Even If Dial Plan Does Not Match	117	DIAL_PLAN_NOT_MATCH_ENABLE_PSy	219
Line select screen		—	—	—
PS Name	PS Name	118	PROFILE_NAME_PSy	224
Phone Number	Phone Number	119	PHONE_NUMBER_PSy_n	222

2.1.3 Web User Interface Setting List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Call Control	Display Name	119	<code>DISPLAY_NAME_PSy_n</code>	218
	Voice Mail Access Number	119	<code>VM_NUMBER_PSy_n</code>	218
	Enable Shared Call	119	<code>SHARED_CALL_ENABLE_PSy_n</code>	219
	Synchronize Do Not Disturb and Call Forward	120	<code>FWD_DND_SYNCHRO_ENABLE_PSy_n</code>	220
Call Features	Block Caller ID	120	—	—
	Block Anonymous Call	120	—	—
	Do Not Disturb	121	—	—
Call Forward	Unconditional	—	—	—
	Enable Call Forward	121	—	—
	Phone Number	122	—	—
	Busy	—	—	—
	Enable Call Forward	122	—	—
	Phone Number	123	—	—
	No Answer	—	—	—
	Enable Call Forward	123	—	—
	Phone Number	124	—	—
	Ring Count	124	—	—

Button Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen	—	—	—	—
Button Settings	No.	125	—	—
	PS Name	125	<code>PROFILE_NAME_PSy</code>	224
	Phone Number	125	<code>PHONE_NUMBER_PSy_n</code>	222

Button Settings - PS

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS Name	PS Name	126	<code>PROFILE_NAME_PSy</code>	224

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Flexible Button Settings	No.	126	—	—
	Type (No. 1–12)	127	FLEX_BUTTON_FACILITY_ACTx_PSy	210
	Parameter (No. 1–12)	127	FLEX_BUTTON_FACILITY_ARGx_PSy	210
	Label Name (No. 1–12)	127	FLEX_BUTTON_LABELx_PSy	211

Button Settings - Copy & Paste

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Copy Source PS Name	PS Name	128	PROFILE_NAME_PSy	224
Copy Source Flexible Button Settings	No.	128	—	—
	Type (No. 1–12)	129	FLEX_BUTTON_FACILITY_ACTx_PSy	210
	Parameter (No. 1–12)	129	FLEX_BUTTON_FACILITY_ARGx_PSy	210
	Label Name (No. 1–12)	129	FLEX_BUTTON_LABELx_PSy	211

Tone Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Dial Tone	Tone Frequencies	130	DIAL_TONE1_FRQ	198
	Tone Timings	131	DIAL_TONE1_TIMING	199
Busy Tone	Tone Frequencies	131	BUSY_TONE_FRQ	201
	Tone Timings	131	BUSY_TONE_TIMING	202
Ringing Tone	Tone Frequencies	132	RINGBACK_TONE_FRQ	203
	Tone Timings	132	RINGBACK_TONE_TIMING	204
Stutter Tone	Tone Frequencies	132	DIAL_TONE4_FRQ	200
	Tone Timings	132	DIAL_TONE4_TIMING	201

2.1.3 Web User Interface Setting List

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Reorder Tone	Tone Frequencies	133	REORDER_TONE_FRO	202
	Tone Timings	133	REORDER_TONE_TIMING	203

Telephone Settings

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Telephone Settings	Number Matching Lower Digit	133	NUMBER_MATCHING_LOWER_DIGIT	206
	Number Matching Upper Digit	134	NUMBER_MATCHING_UPPER_DIGIT	206

Import Phonebook

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
All tab screen		—	—	—
Import Mode	Mode Select	134	—	—
Import Time Setting	Date	—	—	—
	Date	135	—	—
	Month	135	—	—
	Year	135	—	—
	Time	—	—	—
	Hour	135	—	—
	Minute	135	—	—
Import Phonebook	File Name	135	—	—
PS tab screen		—	—	—
Import Phonebook	No.	136	—	—
	PS Name	136	PROFILE_NAME_PSY	224
	Phone Number	136	PHONE_NUMBER_PSY_n	222
PS select screen		—	—	—
PS Name	PS Name	137	PROFILE_NAME_PSY	224
Import Phonebook	File Name	137	—	—

Export Phonebook

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
PS tab screen		—	—	—
Export Phonebook		137	—	—
Export Phonebook	PS Name	138	PROFILE_NAME_PSy	224
	Phone Number	138	PHONE_NUMBER_PSy_n	222

Maintenance

Backup

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Backup		139	—	—

Restore

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Restore		139	—	—

Firmware Maintenance

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Firmware Maintenance	Enable Firmware Update	140	FIRM_UPGRADE_ENABLE	174
	Firmware File URL	140	FIRM_FILE_PATH	175
	PS Update Type	141	PS_FIRM_UPGRADE_AUTO	175

2.1.3 Web User Interface Setting List

Firmware Maintenance

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Firmware Maintenance	Enable Firmware Update	140	FIRM_UPGRADE_ENABLE	174
	Firmware File URL	140	FIRM_FILE_PATH	175
	PS Update Type	141	PS_FIRM_UPGRADE_AUTO	175

All Firmware Update

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Update Mode	Mode	142	—	—
Update Time Setting	Date	—	—	—
	Date	142	—	—
	Month	142	—	—
	Year	142	—	—
	Time	—	—	—
	Hour	142	—	—
	Minute	142	—	—
Update Firmware	Encryption	142	—	—
	File Name	142	—	—

Provisioning Maintenance

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Provisioning Maintenance	Enable Provisioning	144	PROVISION_ENABLE	177
	Standard File URL	144	CFG_STANDARD_FILE_PATH	177
	Product File URL	144	CFG_PRODUCT_FILE_PATH	178
	Master File URL	144	CFG_MASTER_FILE_PATH	179
	System File URL	145	CFG_SYSTEM_FILE_PATH	180
	Cyclic Auto Resync	145	CFG_CYCLIC	183
	Resync Interval	145	CFG_CYCLIC_INTVL	183
	Header Value for Resync Event	145	CFG_RESYNC_FROM_SI_P	184

Error Log

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Error Log		146	—	—


Restart

Web User Interface			Configuration File Parameter	
Section Title	Setting	Ref. (Page)	Parameter Name	Ref. (Page)
Restart		146	—	—

2.1.3 Web User Interface Setting List

Controls on the Window

The Web user interface window contains various controls for navigating and configuring settings. The following figure shows the controls that are displayed on the **[Basic Network Settings]** screen as an example:



Note

- Actual default values may vary depending on your dealer.

① Tabs

Tabs are the top categories for classifying settings. When you click a tab, the corresponding menu items and the configuration screen of the first menu item appear. There are 6 tabs for the Administrator account.

② Menu

The menu displays the sub-categories of the selected tab.

③ Configuration Screen

Clicking a menu displays the corresponding configuration screen, which contains the actual settings, grouped into sections. For details, see **2.2 Status to 2.7.7 Restart**.

④ Buttons

The following standard buttons are displayed in the Web user interface:

Button	Function
Web Logout	Logs out from Web programming.
Web Port Close	Closes the Web port of the SIP-CS and logs you out of the Web user interface after a confirmation message is displayed.
Save	Saves settings for the SIP-CS that is being configured.
Cancel	Discards changes. The settings on the current screen will return to the values they had before being changed.
Collection Start	Starts collecting information necessary for SIP-CS synchronization.
Collection Stop	Stops collecting information necessary for SIP-CS synchronization.
All Save	Saves the same settings for all SIP-CSs.

Button	Function
Back	Returns to the previous screen.
Change User Password	Changes the password used to authenticate the User account.
Tree Image	Displays an image of the tree structure.
Next	Proceeds to the next process.
Import	Imports phonebook data to the specified SIP-CS or S-PS only.
All Import	Imports phonebook data to all SIP-CSs or S-PSs.
All Update Firmware	Updates the firmware of all SIP-CSs.
Update Firmware	Updates the firmware of the specified SIP-CS only.
Execute	Executes the process on the current screen (e.g., opens the TELNET port).
Restart	Restarts the SIP-CS that is being configured.
Start CS Registration	Starts the SIP-CS registration.
Stop CS Registration	Stops the SIP-CS registration.
Delete CS Registration	Deletes the registration of the selected SIP-CS.
Stop PS Registration	Stops the S-PS registration.
Apply	Applies changes or the Tree Survey results to the relevant SIP-CS.
Start PS Registration	Starts the S-PS registration.
Delete PS Registration	Deletes the S-PS registration.
Linex SIP Setting	Displays the SIP settings screen for the S-PS of the selected line.
PS Call Control	Displays the call control settings screen for the selected S-PS.
Linex Call Control	Displays the call control settings screen for the S-PS of the selected line.
Button Settings	Displays the flexible button settings screen.
Copy & Paste	Copies the flexible button settings for an S-PS and applies them to other S-PSs.
Import Phonebook	Displays the import phonebook screen.
Start Tree Survey	Starts the Tree Survey.
Browse	Locates the file to be imported or updated.
Refresh	Updates the status information displayed on the screen. This button is displayed in the upper-right area of the [Network Status] screen.
Monitor Start	Starts monitoring the SIP-CS.
Monitor Stop	Stops monitoring the SIP-CS.
Export Phonebook	Displays the [Export Phonebook] screen for the selected S-PS.
Login	Logs in to the Web user interface for the selected SIP-CS.

Result Messages

When you click **[Save]** after changing the settings on the current configuration screen, one of the following messages will appear in the upper-left area of the current configuration screen:

Result Message	Description	Applicable Screens
Complete	The operation has successfully completed.	All screens except <ul style="list-style-type: none"> • 2.2.3 CS Version List • 2.2.5 PS Information • 2.4.9 CS Management • 2.4.10 Tree Survey • 2.4.12 PS Registration • 2.6.13 Export Phonebook - PS
Failed (Parameter Error)	The operation failed because: <ul style="list-style-type: none"> • Some specified values are out of range or invalid. 	All screens
Failed (Memory Access Error)	The operation failed because: <ul style="list-style-type: none"> • Access error to the flash memory occurred while reading or writing the data. 	All screens
	<ul style="list-style-type: none"> • A flash error occurred in reply to a SIP-CS synchronization error. 	2.6.10 Import Phonebook - All
	<ul style="list-style-type: none"> • The sent data was not created correctly. 	2.6.13 Export Phonebook - PS
	<ul style="list-style-type: none"> • A flash error occurred while restoring the data. 	2.7.2 Restore
Failed (Busy)	The operation failed because: <ul style="list-style-type: none"> • The SIP-CS is performing an operation that accesses the flash memory of the SIP-CS. 	All screens
	<ul style="list-style-type: none"> • HSAPP resources cannot be reserved. (The SIP-CS is busy.) 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> • The specified S-PS is on a call. (The S-PS's busy status is known in status management.) 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> • The specified S-PS is busy. (The S-PS's busy status is not known in status management.) 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> • The SIP-CS is busy. (e.g., The flash memory is in use.) 	2.7.1 Backup 2.7.2 Restore

Result Message	Description	Applicable Screens
Failed (Invalid File)	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The firmware file is corrupted or invalid. • Analysis of the received data failed. • The backup data is corrupted or invalid. Select the correct backup data. 	2.7.4 All Firmware Update 2.6.11 Import Phonebook - PS 2.7.2 Restore
	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The size of the imported phonebook is too large. • The size of the firmware file is insufficient. 	2.6.10 Import Phonebook - All 2.6.11 Import Phonebook - PS 2.7.4 All Firmware Update
	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The firmware version of the Super Master CS to be restored does not match the firmware version of the Super Master CS with which the backup file was created. Update the Super Master CS firmware to the version with which the backup file was created. 	2.7.1 Backup 2.7.2 Restore
Failed (Firmware Version Mismatch)	<p>Note</p> <ul style="list-style-type: none"> • The file name of the backup data includes the CS firmware version with which the file was created. If the name of the backup data is "backup_UDS_00.031.bin", the firmware version of the Super Master CS is version 00.031. 	
	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The time has not been set on the SIP-CS. 	2.6.10 Import Phonebook - All 2.7.4 All Firmware Update
Failed (Past Time)	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The specified time is a time in the past. 	2.6.10 Import Phonebook - All
Failed (No Handset, or Busy)	<p>The operation failed because:</p> <ul style="list-style-type: none"> • The specified S-PS is not registered. (It cannot be found in an S-PS search via SIP-CS synchronization.) 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> • The specified S-PS cannot be connected to. 	2.6.11 Import Phonebook - PS

2.1.3 Web User Interface Setting List

Result Message	Description	Applicable Screens
Failed (No Reception)	The operation failed because: <ul style="list-style-type: none"> The connection to the specified S-PS suddenly cuts out (becomes out of range). 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> An error occurred on the specified S-PS while importing data. 	2.6.11 Import Phonebook - PS
	<ul style="list-style-type: none"> An error occurred on the specified S-PS while exporting data. 	2.6.13 Export Phonebook - PS
Failed (CS Link Failure)	The operation failed because: <ul style="list-style-type: none"> A SIP-CS synchronization failure occurred (due to a network failure etc.). 	2.6.11 Import Phonebook - PS
Failed (Config PS Registering)	The operation failed because: <ul style="list-style-type: none"> There was a conflict of IPEI numbers during the S-PS registration process. 	2.4.12 PS Registration
Failed (Charge Battery)	The operation failed because: <ul style="list-style-type: none"> The battery needs to be charged. 	2.6.13 Export Phonebook - PS
Memory Full	The operation failed because: <ul style="list-style-type: none"> The imported phonebook data contains more than 500 entries. 	2.6.11 Import Phonebook - PS
No Data	The operation failed because: <ul style="list-style-type: none"> No phonebook entry is registered in the specified S-PS. 	2.6.13 Export Phonebook - PS
No checkbox	The operation failed because: <ul style="list-style-type: none"> The SIP-CS selected via check box does not exist. 	2.4.9 CS Management
Collecting	Data is being collected.	2.2.4 CS Information 2.2.6 PS VoIP Status
Trying...	A process is being executed.	2.4.9 CS Management 2.4.10 Tree Survey 2.4.12 PS Registration
CS Registration Complete	SIP-CS registration is complete.	2.4.9 CS Management
CS Registration Stop	SIP-CS registration has been canceled.	2.4.9 CS Management
CS Registration Timeout	The specified number of SIP-CSs has not been registered.	2.4.9 CS Management
CS Delete Complete	The SIP-CS has been deleted successfully.	2.4.9 CS Management
Tree Survey Complete	Tree Survey has completed.	2.4.10 Tree Survey
Tree Survey Stop	Tree Survey has been canceled.	2.4.10 Tree Survey
Apply Complete	Settings have been applied successfully.	2.4.10 Tree Survey
Monitoring...	Monitoring is being executed.	2.4.11 CS Monitor

Result Message	Description	Applicable Screens
Stop	A process has been canceled.	2.2.4 CS Information 2.2.6 PS VoIP Status 2.4.11 CS Monitor
PS Registration Complete	S-PS registration is complete.	2.4.12 PS Registration
PS Registration Stop	S-PS registration has been canceled.	2.4.12 PS Registration
PS Delete Complete	The S-PS has been deleted successfully.	2.4.12 PS Registration

Notice

- Do not click the navigation buttons of your Web browser or open a new window to display the screen. Otherwise, an error ("403 Forbidden") will occur when you click [**Save**].

2.2.1 Version Information

2.2 Status

This section provides detailed descriptions about all the settings classified under the [Status] tab.

2.2.1 Version Information

This screen allows you to view the current version information such as the model number and the firmware version of the SIP-CS.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close

Version Information

CS Version Information

Model	KX-UDS124
Operating Bank	Bank1
IPL Version	01.06
Firmware Version	Bank1: 00.117 Bank2: 00.100
VoIP Version	02.33f.1925

PS Version Information (Model 1)

Model	...
Firmware Version	...

PS Version Information (Model 2)

Model	...
Firmware Version	...

PS Version Information (Model 3)

Model	...
Firmware Version	...

2.2.1.1 CS Version Information

Model

Description	Indicates the model number of the SIP-CS (reference only).
Value Range	KX-UDS124
Default Value	Current model number

Operating Bank

Description	Indicates the storage area of the SIP-CS firmware that is currently operating (reference only).
Value Range	<ul style="list-style-type: none">• Bank1• Bank2
Default Value	Not applicable.

IPL Version

Description	Indicates the version of the IPL (Initial Program Load) that runs when starting the SIP-CS (reference only).
Value Range	IPL version ("nn.nn" [n=0–9])
Default Value	Current IPL version

Firmware Version

Description	Indicates the version of the firmware that is currently installed on the SIP-CS (reference only).
Value Range	Bank1 (Bank2): Firmware version ("nn.nnn" [n=0–9]), -
Default Value	Not applicable.

2.2.1.2 PS Version Information (Model 1)

Model

Description	Indicates the model number of the listed S-PS (reference only).
Value Range	KX-UDT111, - , ...
Default Value	Not applicable.

Firmware Version

Description	Indicates the version of the firmware of the listed S-PS (reference only).
Value Range	Firmware version ("nn.nn.nnn" [n=0–9]), - , ...
Default Value	Not applicable.

2.2.1.3 PS Version Information (Model 2)

Model

Description	Indicates the model number of the listed S-PS (reference only).
Value Range	KX-UDT121/KX-UDT131, - , ...
Default Value	Not applicable.

Firmware Version

Description	Indicates the version of the firmware of the listed S-PS (reference only).
--------------------	--

2.2.2 Network Status

Value Range	Firmware version ("nn.nnn.nnn" [n=0–9]), - , ...
Default Value	Not applicable.

2.2.1.4 PS Version Information (Model 3)

Model

Description	Indicates the model number of the listed S-PS (reference only).
Value Range	- , ...
Default Value	Not applicable.

Firmware Version

Description	Indicates the version of the firmware of the listed S-PS (reference only).
Value Range	Firmware version ("nn.nnn.nnn" [n=0–9]), - , ...
Default Value	Not applicable.

2.2.2 Network Status

This screen allows you to view the current network information of the SIP-CS, such as the MAC address, IP address, Ethernet port status, etc.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close Refresh

Status

Version Information
Network Status
CS Version List
CS Information
PS Information
PS VoIP Status

Network Status

MAC Address	0080F0E975F9
Ethernet Link Status (LAN Port)	Connected
Connection Mode	DHCP
IP Address	192.168.0.38
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.10
DNS1	192.168.0.10
DNS2	

2.2.2.1 Network Status

MAC Address

Description	Indicates the MAC address of the SIP-CS (reference only).
Value Range	Not applicable.

Default Value	Not applicable.
----------------------	-----------------

Ethernet Link Status (LAN Port)

Description	Indicates the current connection status of the Ethernet LAN port (reference only).
Value Range	<ul style="list-style-type: none"> • Connected
Default Value	Not applicable.

Connection Mode

Description	Indicates whether the IP address of the SIP-CS is assigned automatically (DHCP) or manually (static) (reference only).
Value Range	<ul style="list-style-type: none"> • DHCP • Static
Default Value	DHCP

IP Address

Description	Indicates the currently assigned IP address of the SIP-CS (reference only).
Value Range	IP address
Default Value	Not applicable.

Subnet Mask

Description	Indicates the specified subnet mask for the SIP-CS (reference only).
Value Range	Subnet mask
Default Value	Not applicable.

Default Gateway

Description	Indicates the specified IP address of the default gateway for the network (reference only).
	<p>Note</p> <ul style="list-style-type: none"> • If the default gateway address is not specified, this field will be left blank.
Value Range	IP address of the default gateway
Default Value	Not applicable.

2.2.3 CS Version List

DNS1

Description	Indicates the specified IP address of the primary DNS server (reference only).
Note	<ul style="list-style-type: none">If the primary DNS server address is not specified, this field will be left blank.
Value Range	IP address of the primary DNS server
Default Value	Not applicable.

DNS2

Description	Indicates the specified IP address of the secondary DNS server (reference only).
Note	<ul style="list-style-type: none">If the secondary DNS server address is not specified, this field will be left blank.
Value Range	IP address of the secondary DNS server
Default Value	Not applicable.

2.2.3 CS Version List

This screen allows you to view current version information such as the model number and the firmware version of the SIP-CS that belongs to a particular Air Sync Group.

The screenshot shows the Panasonic SIP CS KX-UDS124 web interface. The top navigation bar includes links for SIP CS KX-UDS124, Status, Network, System, VoIP, Telephone, and Maintenance. On the left, there's a sidebar with links for Web Logout, Web Port Close, Status (Version Information, Network Status, CS Version List), CS Information, PS Information, and PS VoIP Status. The main content area is titled 'CS Version List' and displays a table with columns for Air Sync Group (dropdown set to 1), CS Name (0018E66300), MAC Address (00.80.F0.E9.75.F9), and Firmware Version (00.030). The 'CS Version List' link in the sidebar is highlighted with a red box.

2.2.3.1 CS Version List

Air Sync Group

Description	Selects the number of the Air Sync Group to be displayed.
Value Range	1–8

Default Value	Not stored.
----------------------	-------------

CS Name

Description	Indicates the name of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

CS ID

Description	Indicates the ID of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	10 characters
Default Value	Not applicable.

MAC Address

Description	Indicates the MAC address of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	Not applicable.
Default Value	Not applicable.

Firmware Version

Description	Indicates the firmware version of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	Firmware version ("nn.nnn" [n=0–9])
Default Value	Not applicable.


2.2.4 CS Information

This screen allows you to view information such as the service status and the path of the SIP-CS that belongs to a particular Air Sync Group.

2.2.4 CS Information

Note

- After clicking [Collection Start], the SIP-CS will continue to gather information for 15 seconds until [Collection Stop] is clicked.



2.2.4.1 CS Information

Air Sync Group

Description	Selects the number of the Air Sync Group to be displayed.
Value Range	1–8
Default Value	Not stored.

CS Name

Description	Indicates the name of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

CS ID

Description	Indicates the ID of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	10 characters
Default Value	Not applicable.

MAC Address

Description	Indicates the MAC address of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
-------------	---

Value Range	Not applicable.
Default Value	Not applicable.


Status

Description	Indicates the service status of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	<ul style="list-style-type: none"> INS - (not available)
Default Value	Not applicable.

Path 1-16

Description	Indicates the status of the path of the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Note	<ul style="list-style-type: none"> Total 8 paths (Max. 4 paths for talking; max. 8 paths for Handover) ^{*1}
Value Range	<ul style="list-style-type: none"> OFF 2 characters ("H ") + 1–32 digits 1–32 digits <p>Note</p> <ul style="list-style-type: none"> "-" means that the path is unused.
Default Value	Not applicable.

^{*1} When the handover happens, the call is redirected from the original CS to a latest CS. The handover call requires processing power of the original CS during the call. The CS's processing power resource is limited and shared by calls (include handover calls) as below.



2.2.5 PS Information

Regist PS Number

Description	Indicates the number of S-PSs registered to the SIP-CS that belongs to the Air Sync Group of the selected number (reference only).
Value Range	0–32
Default Value	Not applicable.

2.2.5 PS Information

This screen allows you to view information such as the model number, the firmware version, and the phonebook import record of the S-PSs that are registered to the SIP-CS.

Click a numbered tab to view this screen for a particular S-PS.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close

Status

Version Information
Network Status
CS Version List
CS Information
PS Information
PS VoIP Status

PS Information

1- 21- 41- 61- 81- 101- 121- 141- 161- 181- 201- 221- 241-

No.	PS Name	Model	Firmware Version	Phonebook Import Time [Result]
1				
2				
3				
4				
5				

2.2.5.1 PS Information

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Model

Description	Indicates the model number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	<ul style="list-style-type: none"> • KX-UDT111 • KX-UDT121 • KX-UDT131
Default Value	Not applicable.

Firmware Version

Description	Indicates the firmware version of the S-PS that is registered to the SIP-CS (reference only).
Value Range	Firmware version ("nn.nn.nnn" [n=0–9])
Default Value	Not applicable.

Phonebook Import Time [Result]

Description	Indicates the time that phonebook data is imported to S-PSs when importing phonebook data to all S-PSs (→ see 2.6.10 Import Phonebook - All). The information in brackets ([]) indicates the import result (reference only).
Value Range	"nn/nn/nnnn nn:nn [xxxxxxxxxxxxxxxxxxxx]" Note <ul style="list-style-type: none">• When the SIP-CS's time is not set, "-" will be displayed.
Default Value	Not applicable.

2.2.6 PS VoIP Status

This screen allows you to view the information of the SIP-CS to which each S-PS is connected, and the phone number and VoIP status of each S-PS.

2.2.6 PS VoIP Status

Click a numbered tab to view this screen for a particular S-PS.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close

PS VoIP Status

Collecting

1	1F	2F	3F	4F	5F	6F	7F	8F	9F	10F	11F
12F	13F	14F	15F	16F	17F	18F	19F	20F	21F	22F	23F
24F	25F										

Collection Start Collection Stop

Status

Version Information
Network Status
CS Version List
CS Information
PS Information
PS VoIP Status

No.	PS Name	Location CS Name Location CS MAC	Phone Number	VoIP Status
1	test	-	4262	-
2	test2	-	4261	-
3				

2.2.6.1 PS VoIP Status

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Location CS Name

Description	Indicates the name of the SIP-CS to which the S-PS is currently connected (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Location CS MAC

Description	Indicates the MAC address of the SIP-CS to which the S-PS is currently connected (reference only).
Value Range	Not applicable.

Default Value	Not applicable.
----------------------	-----------------

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Note	<ul style="list-style-type: none"> The corresponding field is blank if a line has not yet been leased or if the SIP-CS has not been configured.
Value Range	Max. 32 digits
Default Value	Not applicable.

VoIP Status

Description	Indicates the current VoIP status of each line of the SIP-CS to which the S-PS is currently connected (reference only).
Value Range	<ul style="list-style-type: none"> 200 OK: The SIP-CS has been registered to the SIP server, and the line can be used. Registering: The SIP-CS is being registered to the SIP server, and the line cannot be used. Blank: The line has not been leased, the SIP-CS has not been configured yet, or a SIP authentication failure has occurred. DNS Error: Registration to the server failed due to a DNS error. No Response: Registration to the server failed. There is no response from the server. SIP Error(xxx): Registration to the server failed. An error number (xxx) was returned from the server. Internal Status Error: Registration to the server failed due to an internal cause.
Note	<ul style="list-style-type: none"> Immediately after starting up the SIP-CS, the phone numbers of the lines will be displayed, but the status of the line may not be displayed because the SIP-CS is still being registered to the SIP server. When not performing SIP registration, "-" is displayed.
Default Value	Not applicable.

2.3 Network

This section provides detailed descriptions about all the settings classified under the [Network] tab.

2.3.1 Basic Network Settings

2.3.1 Basic Network Settings

This screen allows you to change basic network settings such as whether to use a DHCP server, and the IP address of the SIP-CS.

Note

- Changes to the settings on this screen are applied when the message "Complete" appears after clicking **[Save]**. Because the IP address of the SIP-CS will probably be changed if you change these settings, you will not be able to continue using the Web user interface. To continue configuring the SIP-CS from the Web user interface, log in to the Web user interface again after confirming the newly assigned IP address of the SIP-CS. In addition, if the IP address of the PC from which you try to access the Web user interface has been changed, close the Web port once by clicking **[Web Port Close]**.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close

Network

Basic Network Settings (highlighted)

HTTP Client Settings

HTTP Authentication

Global Address Detection

Network Directory

Basic Network Settings

Connection Mode

Connection Mode DHCP Static

DHCP Settings

Host Name: {MODEL}

Receive DNS server address automatically

Use the following settings
DNS1: _____
DNS2: _____

Static Settings

Static IP Address: 192.168.0.100
Subnet Mask: 255.255.255.0
Default Gateway: 192.168.0.1
DNS1: _____
DNS2: _____

Link Speed/Duplex Mode

LAN Port: Auto Negotiation

The CS reboots automatically if you change the settings on this item.

LLDP Settings

Enable LLDP: Yes No
LLDP-MED Interval timer: 30 seconds [1-3600]
IP Phone VLAN ID: ----
IP Phone Priority: -

The CS reboots automatically if you change the settings on this item.

VLAN Settings

Enable VLAN: Yes No
IP Phone VLAN ID: 2 [1-4094]
IP Phone Priority: 7

The CS reboots automatically if you change the settings on this item.

Save Cancel

2.3.1.1 Connection Mode

Connection Mode

Description	Selects whether to assign the IP address automatically (DHCP) or manually (static).
--------------------	---

Value Range	<ul style="list-style-type: none"> • DHCP • Static
Default Value	DHCP

2.3.1.2 DHCP Settings

Host Name

Description	Specifies the host name for the SIP-CS to send to the DHCP server.
	<p>Note</p> <ul style="list-style-type: none"> • This setting is available only when [Connection Mode] is set to [DHCP].
Value Range	Max. 63 characters
Default Value	{MODEL}

Domain Name Server

Description	Selects whether to receive DNS server addresses automatically or to assign a DNS server addresses (up to 2) manually.
	<p>Note</p> <ul style="list-style-type: none"> • This setting is available only when [Connection Mode] is set to [DHCP].
Value Range	<ul style="list-style-type: none"> • Receive DNS server address automatically • Use the following settings <ul style="list-style-type: none"> – DNS1 – DNS2 <p>Note</p> <ul style="list-style-type: none"> • If you select [Use the following settings], specify the IP address(es) of the primary and, if necessary, secondary DNS server(s) manually. The permissible values are: Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
Default Value	Receive DNS server address automatically

2.3.1 Basic Network Settings

2.3.1.3 Static Settings

Static IP Address

Description	Specifies the IP address for the SIP-CS.
Note	<ul style="list-style-type: none">This setting is available only when [Connection Mode] is set to [Static].
Value Range	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
Default Value	Not stored.

Subnet Mask

Description	Specifies the subnet mask for the SIP-CS.
Note	<ul style="list-style-type: none">This setting is available only when [Connection Mode] is set to [Static].
Value Range	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
Default Value	Not stored.

Default Gateway

Description	Specifies the IP address of the default gateway for the network where the SIP-CS is connected.
Note	<ul style="list-style-type: none">This setting is available only when [Connection Mode] is set to [Static].
Value Range	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
Default Value	Not stored.

DNS1

Description	Specifies the IP address of the primary DNS server.
Note	<ul style="list-style-type: none">This setting is available only when [Connection Mode] is set to [Static].
Value Range	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)

Default Value	Not stored.
----------------------	-------------

DNS2

Description	Specifies the IP address of the secondary DNS server.
Note	<ul style="list-style-type: none"> This setting is available only when [Connection Mode] is set to [Static].
Value Range	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
Default Value	Not stored.

2.3.1.4 Link Speed/Duplex Mode

LAN Port

Description	Selects the connection mode (link speed and duplex mode) of the LAN port.
Value Range	<ul style="list-style-type: none"> Auto Negotiation 100 Mbps/Full Duplex 100 Mbps/Half Duplex 10 Mbps/Full Duplex 10 Mbps/Half Duplex
Default Value	Auto Negotiation

2.3.1.5 LLDP Settings

Enable LLDP

Description	Selects whether to enable or disable sending and receiving LLDP frames.
Value Range	<ul style="list-style-type: none"> Y (Enable) N (Disable)
Default Value	Y

LLDP-MED Interval timer

Description	Specifies the interval, in seconds, between sending each LLDP frame.
Value Range	1–3600
Default Value	30

2.3.1 Basic Network Settings

IP Phone (VLAN ID)

Description	Indicates the VLAN ID for the SIP-CS (reference only).
Value Range	1–4094
Default Value	Not applicable.

IP Phone (Priority)

Description	Indicates the priority number for the SIP-CS (reference only).
Value Range	0–7
Default Value	Not applicable.

2.3.1.6 VLAN Settings

Enable VLAN

Description	Selects whether to use the VLAN feature to perform VoIP communication securely.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	No

IP Phone (VLAN ID)

Description	Specifies the VLAN ID for this SIP-CS.
Value Range	1–4094
Default Value	2

IP Phone (Priority)

Description	Selects the priority number for the SIP-CS.
Value Range	0–7
Default Value	7

2.3.2 HTTP Client Settings

This screen allows you to change the HTTP client settings for the SIP-CS in order to access the HTTP server of your phone system and download configuration files.

2.3.2.1 HTTP Client Settings

HTTP Version

Description	Selects which version of the HTTP protocol to use for HTTP communication.
Value Range	<ul style="list-style-type: none"> • HTTP/1.0 • HTTP/1.1 <p>Note</p> <ul style="list-style-type: none"> • For this SIP-CS, it is strongly recommended that you select [HTTP/1.0]. However, if the HTTP server does not function well with HTTP/1.0, try changing the setting [HTTP/1.1].
Default Value	HTTP/1.0

HTTP User Agent

Description	Specifies the text string to send as the user agent in the header of HTTP requests.
--------------------	---

2.3.3 HTTP Authentication

Value Range	Max. 40 characters
Note	<ul style="list-style-type: none">• You cannot leave this field empty.• If "{mac}" is included in this field, it will be replaced with the SIP-CS's MAC address in lower-case.• If "{MAC}" is included in this field, it will be replaced with the SIP-CS's MAC address in upper-case.• If "{MODEL}" is included in this field, it will be replaced with the SIP-CS's model name.• If "{fwver}" is included in this field, it will be replaced with the firmware version of the SIP-CS.
Default Value	Panasonic_{MODEL}/{fwver} ({mac})

2.3.2.2 Proxy Server Settings

Enable Proxy

Description	Selects whether to use the proxy server.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	No

Proxy Server Address

Description	Specifies the IP address or FQDN of the proxy server.
Value Range	Max. 127 characters
Note	<ul style="list-style-type: none">• You cannot leave this field empty if [Enable Proxy] is set to [Yes].

Proxy Server Port

Description	Specifies the port number of the proxy server.
Value Range	1–65535
Default Value	8080

2.3.3 HTTP Authentication

This screen allows you to change the ID and the password used to authenticate the User account.

Note

- Although this setting is technically possible, you cannot log in to the Web user interface with the User account.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout	HTTP Authentication	
Web Port Close		
Network	HTTP Authentication	
Basic Network Settings	Authentication ID	<input type="text"/>
HTTP Client Settings	Authentication Password	<input type="password"/>
HTTP Authentication	<input type="button" value="Save"/> <input type="button" value="Cancel"/>	
Global Address Detection		
Network Directory		

2.3.3.1 HTTP Authentication

Authentication ID

Description	Specifies the ID for the User account for Web user interface programming.
Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Not stored.

Authentication Password

Description	Specifies the password for the User account for Web user interface programming.
Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Not stored.

2.3.4 Global Address Detection

This screen allows you to configure the Global Address Detection feature and STUN server settings. The global IP address of the network the SIP-CS is connected to will be detected periodically. If the global IP address has changed, the new address will be registered to the SIP server.

2.3.4 Global Address Detection

Note

- If the SIP-CS is connected directly to the Internet, or the network global address is static (i.e., does not change), you do not need to configure Global Address Detection.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Network Basic Network Settings HTTP Client Settings HTTP Authentication Global Address Detection Network Directory

Global Address Detection

Detection Method STUN SIP
Detection Interval 0 second(s) [10-65535, 0: Disable]

STUN Server

STUN Server Address
STUN Server Port 3478 [1-65535]

All Save Cancel

2.3.4.1 Global Address Detection

Detection Method

Description	Selects the method to use for detecting the global IP address.
Value Range	<ul style="list-style-type: none">• STUN• SIP
Default Value	STUN

Detection Interval

Description	Specifies the interval, in seconds, to wait between attempts to detect the global IP address.
Value Range	0, 10-65535 (0: Disable)
Default Value	0

2.3.4.2 STUN Server

STUN Server Address

Description	Specifies the IP address or FQDN of the STUN server.
Value Range	Max. 127 characters
Default Value	Not stored.

STUN Server Port

Description	Specifies the port number of the STUN server.
Value Range	1–65535
Default Value	3478

2.3.5 Network Directory

This screen allows you to configure the Xsi Server settings to download the phonebook from Xsi Server.

The screenshot shows the Panasonic SIP CS KX-UDS124 web interface. The top navigation bar includes Status, Network, System, VoIP, Telephone, and Maintenance. The left sidebar under Network has options for Basic Network Settings, HTTP Client Settings, HTTP Authentication, Global Address Detection, and Network Directory, with Network Directory highlighted. The main content area is titled 'Network Directory' and contains a form for 'Broadsoft Xsi Settings'. It includes fields for Xsi Server, Xsi User ID, Xsi User Password, and Phonebook Type (set to 'Group'). At the bottom of the form are 'Save' and 'Cancel' buttons.

2.3.5.1 Network Directory

Xsi Server Address

Description	Specifies the IP address or FQDN of Xsi server, which consists of "http(s)://", and an Xsi Service server address and port, for example, "http://xsi.com", "https://xsi.com", "http://xsi.com:8080", "https://xsi.com:8080".
Value Range	Max. 84 characters
Default Value	Not stored.

Xsi User ID

Description	Specifies the unique ID used by the Xsi server.
Value Range	Max. 84 characters (except ", &, ', :, <, >, and space)
Default Value	Not stored.

Xsi User Password

Description	Specifies the password used by the Xsi server.
--------------------	--

2.4.1 Web Language

Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Not stored.

Phonebook Type

Description	Selects the phonebook type that is downloaded from the Xsi server.
Value Range	<ul style="list-style-type: none">• Group• Group Common• Enterprise• Enterprise Common• Personal
Default Value	Group

2.4 System

This section provides detailed descriptions about all the settings classified under the **[System]** tab.

2.4.1 Web Language

This screen allows you to select the language used for the Web user interface.

Note

- Although this setting is technically possible, the language used for the Web user interface for the Administrator account is always English.



2.4.1.1 Web Language

Language

Description	Selects the language used for the Web user interface.
--------------------	---

Value Range	<ul style="list-style-type: none"> • English (US) • English (UK) • Deutsch • Français • Español • Italiano • Portugués • Русский
Default Value	English (US)

2.4.2 Administrator Password

This screen allows you to change the password used to authenticate the Administrator account when logging in to the Web user interface.

Note

- For security reasons, the characters entered for the password are masked by special characters, which differ depending on the Web browser.
- After you change the administrator password, the next time you access the Web user interface, the authentication dialog box appears. Two consecutive login failures will result in an error ("401 Unauthorized"). This restriction only applies the first time you attempt to log in after changing the password. In all other circumstances, an error occurs after 3 unsuccessful login attempts.

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

Web Logout Web Port Close

System

- Web Language
- Administrator Password**
- Change User Password
- Web Server Settings
- Time Setting
- Time Adjust Settings
- CS Name

Change Administrator Password

Current Password	<input type="text"/>
New Password	<input type="text"/> 6-16 characters
Confirm New Password	<input type="text"/>

All Save Cancel

2.4.2.1 Change Administrator Password

Current Password

Description	Specifies the current password to use to authenticate the Administrator account when logging in to the Web user interface.
Value Range	6–16 characters (except ", &, :, <, >, and space)
Default Value	adminpass

2.4.3 Change User Password

New Password

Description	Specifies the new password to use to authenticate the Administrator account when logging in to the Web user interface.
Value Range	6–16 characters (except ", &, ', :, <, >, and space)
Default Value	Not stored.

Confirm New Password

Description	Specifies the same password that you entered in [New Password] for confirmation.
Value Range	6–16 characters (except ", &, ', :, <, >, and space) Note <ul style="list-style-type: none">This value must be the same as the value entered in [New Password].
Default Value	Not stored.

2.4.3 Change User Password

This screen allows you to view the name and phone number of each S-PS.
Click a numbered tab to view this screen for a particular S-PS.

Note

- Although this setting is technically possible, you cannot log in to the Web user interface with the User account.

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

Web Logout Web Port Close

Change User Password

1 - 21 - 41 - 61 - 81 - 101 - 121 - 141 - 161 - 181 - 201 - 221 - 241 -

No.	PS Name	Phone Number	Select Button
1	efgh	1001	<input type="button" value="Change User Password"/>
2			<input type="button" value="Change User Password"/>
3			<input type="button" value="Change User Password"/>
4			<input type="button" value="Change User Password"/>
5			<input type="button" value="Change User Password"/>
6			<input type="button" value="Change User Password"/>
7			<input type="button" value="Change User Password"/>
8			<input type="button" value="Change User Password"/>
9			<input type="button" value="Change User Password"/>
10			<input type="button" value="Change User Password"/>

System

- [Web Language](#)
- [Administrator Password](#)
- [Change User Password](#)
- [Web Server Settings](#)
- [Time Setting](#)
- [Time Adjust Settings](#)
- [CS Name](#)
- [Air Settings](#)
- [CS Management](#)
- [Tree Survey](#)
- [CS Monitor](#)
- [PS Registration](#)
- [- PS Settings](#)

2.4.3.1 Change User Password

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Note	<ul style="list-style-type: none"> Indicates both lines if the SIP-CS is connected in general SIP Server.
Value Range	Max. 32 digits
Default Value	Not applicable.

2.4.3.2 Changing User Password

This screen will be displayed by clicking [Change User Password] under [Select Button] on the [Change User Password] screen. You can change the password used to authenticate the User account on this screen.

Note

- Although this setting is technically possible, you cannot log in to the Web user interface with the User account.

2.4.3.3 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.4.4 Web Server Settings

2.4.3.4 Change User Password

New Password


Description	Specifies the new password to use to authenticate the User account for Web user interface programming.
Value Range	6–16 characters (except ", &, :, <, >, and space)
Default Value	Not stored.

Confirm New Password

Description	Specifies the same password that you entered in [New Password] for confirmation.
Value Range	6–16 characters (except ", &, :, <, >, and space) Note <ul style="list-style-type: none">This value must be the same as the value entered in [New Password].
Default Value	Not stored.

2.4.4 Web Server Settings

This screen allows you to change the Web server settings.



2.4.4.1 Web Server Settings

Web Server Port

Description	Specifies the port number used by the Web server.
-------------	---

Value Range	80, 1024–49151
Note	<ul style="list-style-type: none"> You cannot specify here the same port number as any of the port numbers specified for the individual lines in [Source Port] in 2.5.3.4 SIP Source Port.
Default Value	80

Port Close Timer

Description	Specifies the length of time, in minutes, to keep the Web port open when there has been no communication between the SIP-CS and the PC. If the specified length of time elapses without any communication, the Web port closes automatically. Communication is detected when you click a tab, menu item, the [Save] button, or by reloading the application or pressing the F5 key.
Value Range	1–1440
Default Value	30

2.4.5 Time Setting

This screen allows you to change the time settings.

The screenshot shows the Panasonic SIP CS KX-UDS124 web interface. The top navigation bar includes links for Status, Network, System (which is selected), VoIP, Telephone, and Maintenance. On the left, a sidebar under the System heading lists Web Language, Administrator Password, Change User Password, Web Server Settings, and Time Setting, with the Time Setting link highlighted by a red box. The main content area is titled "Time Setting" and contains fields for Date (set to 1 / 31 / 2012) and Time (set to 00 : 00). At the bottom are "All Save" and "Cancel" buttons.

2.4.5.1 Time Setting

Date

Description	Specifies the month (1–2 digits), date (1–2 digits), and year (4 digits).
Value Range	Month: 1–12, Date: 1–31, Year: 2000–2099
Default Value	1/31/2012

2.4.6 Time Adjust Settings

Time

Description	Specifies the hour (1–2 digits) and minute (1–2 digits).
Value Range	00:00–23:59
Default Value	00:00

2.4.6 Time Adjust Settings

This screen allows you to enable automatic clock adjustment using an NTP server and configure the settings for DST (Daylight Saving Time), also known as Summer Time.

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

Web Logout Web Port Close

Time Adjust Settings

System

- Web Language
- Administrator Password
- Change User Password
- Web Server Settings
- Time Setting
- Time Adjust Settings**
- CS Name
- Air Settings
- CS Management
- Tree Survey
- CS Monitor
- PS Registration
- PS Settings

Synchronization

Enable Synchronization by NTP Yes No

Synchronization Interval 43200 seconds [10-86400]

Time Server

NTP Server Address []

Time Zone

Time Zone GMT

Daylight Saving Time

Enable DST Yes No

DST Offset 60 minute(s) [0-720]

Start Day and Time of DST

Month March

Day of Week Second Sunday

Time 120 minute(s) [0-1439]

End Day and Time of DST

Month October

Day of Week Second Sunday

Time 120 minute(s) [0-1439]

All Save Cancel

2.4.6.1 Synchronization

Enable Synchronization by NTP

Description	Selects whether to enable the SIP-CS to automatically adjust its clock according to the time information provided by an NTP server.
Value Range	<ul style="list-style-type: none">• Yes• No <p>Note</p> <ul style="list-style-type: none">• Even if you select [Yes], this feature will not function properly if the NTP server address setting is invalid.

Default Value	Yes
----------------------	-----

Synchronization Interval

Description	Specifies the interval, in seconds, between synchronizations with the NTP server.
Value Range	10–86400
Default Value	43200

2.4.6.2 Time Server

NTP Server Address

Description	Specifies the IP address or FQDN of the NTP server.
Value Range	Max. 127 characters
Default Value	Not stored.

2.4.6.3 Time Zone

Time Zone

Description	Selects your time zone.
Value Range	GMT -12:00–GMT +13:00
Default Value	GMT

2.4.6.4 Daylight Saving Time (Summer Time)

Enable DST (Enable Summer Time)

Description	Selects whether to enable DST (Summer Time).
Value Range	<ul style="list-style-type: none"> • Yes • No
Default Value	No

DST Offset (Summer Time Offset)

Description	Specifies the amount of time, in minutes, to change the time when [Enable DST (Enable Summer Time)] is set to [Yes].
Value Range	0–720

2.4.6 Time Adjust Settings

Default Value	60
---------------	----

2.4.6.5 Start Day and Time of DST (Start Day and Time of Summer Time) Month

Description	Selects the month in which DST (Summer Time) starts.
Value Range	<ul style="list-style-type: none">• January• February• March• April• May• June• July• August• September• October• November• December
Default Value	March

Day of Week

Using the 2 following settings, specify on which day of the selected month DST (Summer Time) starts. For example, to specify the second Sunday, select [Second] and [Sunday].

Description	Selects the number of the week on which DST (Summer Time) starts.
Value Range	<ul style="list-style-type: none">• First• Second• Third• Fourth• Last
Default Value	Second

Description	Selects the day of the week on which DST (Summer Time) starts.
Value Range	<ul style="list-style-type: none">• Sunday• Monday• Tuesday• Wednesday• Thursday• Friday• Saturday
Default Value	Sunday

Time

Description	Specifies the start time of DST (Summer Time) in minutes after 12:00 AM.
Value Range	0–1439
Default Value	120

2.4.6.6 End Day and Time of DST (End Day and Time of Summer Time)

Month

Description	Selects the month in which DST (Summer Time) ends.
Value Range	<ul style="list-style-type: none"> • January • February • March • April • May • June • July • August • September • October • November • December
Default Value	October

Day of Week

Using the 2 following settings, specify on which day of the selected month DST (Summer Time) ends. For example, to specify the second Sunday, select [Second] and [Sunday].

Description	Selects the number of the week on which DST (Summer Time) ends.
Value Range	<ul style="list-style-type: none"> • First • Second • Third • Fourth • Last
Default Value	Second

Description	Selects the day of the week on which DST (Summer Time) ends.
--------------------	--

2.4.8 Air Settings

Value Range	<ul style="list-style-type: none">• Sunday• Monday• Tuesday• Wednesday• Thursday• Friday• Saturday
Default Value	Sunday

Time

Description	Specifies the end time of DST (Summer Time) in minutes after 12:00 AM.
Value Range	0–1439
Default Value	120

2.4.7 CS Name

This screen allows you to specify the name of the SIP-CS.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Web Logout Web Port Close

CS Name


System

Web Language
Administrator Password
Change User Password
Web Server Settings
Time Setting
Time Adjust Settings
CS Name

CS Name

Name

Save Cancel



2.4.7.1 CS Name

Name

Description	Specifies the name of the SIP-CS.
Value Range	Max. 20 characters
Default Value	Not stored.

2.4.8 Air Settings

This screen allows you to change air synchronization settings.

Note

- When you change the settings on this screen and click [**Save**], after the message "Complete" has been displayed, the SIP-CS will restart automatically with the new settings applied.

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

Web Logout Web Port Close System Web Language Administrator Password Change User Password Web Server Settings Time Setting Time Adjust Settings CS Name Air Settings CS Management Tree Survey CS Monitor PS Registration - PS Settings	<h3>Air Settings</h3> <p>Air Sync Group Air Sync Group <input type="text" value="1"/></p> <p>CS Class It is necessary to execute Tree Survey again if you change this mode. CS Class <input checked="" type="radio"/> Master <input type="radio"/> Second Master <input type="radio"/> Slave</p> <p>Super Master CS IP Address IP Address <input type="text"/></p> <p style="text-align: center;">Save Cancel</p> <p>The CS reboots automatically if you change the settings on this screen.</p>
---	---

2.4.8.1 Air Sync Group

Air Sync Group

Description	Selects the number of the Air Sync Group that the SIP-CS belongs to.
	<p>Note</p> <ul style="list-style-type: none"> This setting is effective when the class of the SIP-CS is "Master".
Value Range	1–8
Default Value	1

2.4.8.2 CS Class

CS Class

Description	Selects the classification of the SIP-CS.
Value Range	<ul style="list-style-type: none"> Master Second Master Slave <p>Note</p> <ul style="list-style-type: none"> [Second Master] is for reference only and cannot be selected.
Default Value	Slave

2.4.8.3 Super Master CS IP Address

IP Address

Description	Specifies the IP address of the Super Master CS to which the SIP-CS is connected.
Note	<ul style="list-style-type: none"> The "Super Master CS" refers to the Master CS of Air Sync Group 1. This setting is effective when the class of the SIP-CS is "Master".
Value Range	IP address
Default Value	Not stored.

2.4.9 CS Management

This screen allows you to manage the SIP-CS registration to a particular Air Sync Group.

After selecting the target Air Sync Group, you can change the SIP-CS registration status as follows:

- Click **[Start CS Registration]** to register the SIP-CS to the selected Air Sync Group.
- Click **[Stop CS Registration]** to stop the proceeding SIP-CS registration.
- If you want to delete the registered SIP-CS from the selected Air Sync Group, check the check box of the target SIP-CS in **[CS Registered List]**, and then click **[Delete CS Registration]**.

Note

- You cannot delete a SIP-CS that is registered as a "Master CS".

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

Web Logout	CS Management					
Web Port Close						
System						
Web Language	Air Sync Group	1				
Administrator Password	Number of CS	30				
Change User Password	Start CS Registration					
Web Server Settings	Stop CS Registration					
Time Setting	Only CS that has a check in the check box can be deleted					
Time Adjust Settings	CS Registration Delete					Delete CS Registration
CS Name						
Air Settings						
CS Management						
Tree Survey						
CS Monitor						
PS Registration						
- PS Settings						
CS Registered List						
<input type="checkbox"/> All						
No.	Index	CS Name CS ID	MAC Address IP Address	CS Class	Remote Login	
1	1	01973103D0	00:80:F0:E9:74:40 192.168.0.103	Master		
2	2	0018E58900	00:80:F0:AC:67:44 192.168.0.142	Slave	Login	
3						
4						
5						
6						

2.4.9.1 CS Registration

Air Sync Group

Description	Selects the number of the Air Sync Group that contains the SIP-CS to be registered, stopped, or deleted.
Value Range	1–8
Default Value	1

Number of CS

Description	Selects the maximum number of SIP-CS registrations in your environment.
Value Range	1–32
Default Value	31

2.4.9.2 CS Registered List

Note

- In order to delete the registered SIP-CS from the selected Air Sync Group, you must check the check box of the target SIP-CS first. If you want to delete all the registered SIP-CS, check the check box for [All].
- You can display the [CS Name] screen of the [System] tab by clicking [Login] under [Remote Login] for each SIP-CS.
When logged in remotely, if you click [Web Logout] on the screen being remotely accessed, the Web user interface of the local SIP-CS may return to the login screen. In this case, enter the ID and password to log in again.

No.

Description	Indicates the number of the SIP-CS (reference only).
Value Range	1–128
Default Value	Not applicable.

Index

Description	Indicates the index of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	1–128
Default Value	Not applicable.

2.4.9 CS Management

CS Name

Description	Indicates the name of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

CS ID

Description	Indicates the ID of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	10 characters
Default Value	Not applicable.

MAC Address

Description	Indicates the MAC address of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	Not applicable.
Default Value	Not applicable.

IP Address

Description	Indicates the IP address of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	IP address
Default Value	Not applicable.

CS Class

Description	Indicates the class of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	<ul style="list-style-type: none">• Master• 2nd Master• Slave
Default Value	Not applicable.

2.4.10 Tree Survey

This screen allows you to change settings for Tree Survey.

Tree Survey

Index	CS Name MAC Address	CS Class	Status	Primary CS Index	Secondary CS Index	Level
1	0080F0E975F9	Master	INS	-	-	-
2	0080F0D755E7	Slave	-	1		1
4	0080F0E97605	2nd Master	-	1		1

2.4.10.1 Tree Survey

Air Sync Group

Description	Selects the number of the Air Sync Group to be configured.
Value Range	1–8
Default Value	1

This screen allows you to change the Tree Survey settings for a particular Air Sync Group.

After selecting the target Air Sync Group, you can change the Tree Survey settings as follows:

- Click [**Start Tree Survey**] to start the Tree Survey for all SIP-CSs in the Air Sync Group.
After the Tree Survey has completed, click [**Tree Image**]. A connection diagram of the SIP-CSs will be displayed.
- Click [**Apply**] to apply the Tree Survey results to all SIP-CSs in the Air Sync Group.
- Click [**Cancel**] to cancel the Tree Survey results for all SIP-CSs in the Air Sync Group.

Note

- If you press [**Start Tree Survey**] or [**Apply**] while an S-PS is on a call, the call will be disconnected.

2.4.10 Tree Survey

2.4.10.2 Survey List

Index

Description	Indicates the index of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	1–128
Default Value	Not applicable.

CS Name

Description	Indicates the name of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

MAC Address

Description	Indicates the MAC address of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	Not applicable.
Default Value	Not applicable.

CS Class

Description	Selects the class of the SIP-CS that is registered to the Super Master CS.
Value Range	<ul style="list-style-type: none">• Master (reference only)• 2nd Master• Slave
Default Value	Not stored.

Status

Description	Indicates the service status of the SIP-CS that is registered to the Super Master CS (reference only).
Value Range	<ul style="list-style-type: none">• INS• - (not available)
Default Value	Not applicable.

Primary CS Index

Description	Specifies the primary sync index of the SIP-CS that is registered to the Super Master CS.
Value Range	1–128, - Note <ul style="list-style-type: none">• "-" means unused.
Default Value	Not stored.

Secondary CS Index

Description	Specifies the secondary sync index of the SIP-CS that is registered to the Super Master CS.
Value Range	1–128, - Note <ul style="list-style-type: none">• "-" means unused.
Default Value	Not stored.

Level

Description	Indicates the level of the SIP-CS that is registered to the Super Master CS (reference only). Note <ul style="list-style-type: none">• The level refers to the level in the tree structure.
Value Range	1–8
Default Value	Not applicable.

2.4.11 CS Monitor


This screen allows you to view information such as the current air synchronization status of each SIP-CS in a particular Air Sync Group.

After selecting the target Air Sync Group, you can monitor the SIP-CS status as follows:

- Click **[Monitor Start]** to start monitoring.
- Click **[Monitor Stop]** to stop the proceeding monitoring.

2.4.11 CS Monitor

- After monitoring has completed, click **[Tree Image]**. A connection diagram of the SIP-CSs will be displayed.



2.4.11.1 CS Monitor

Air Sync Group

Description	Selects the number of the Air Sync Group whose SIP-CSs you want to monitor.
Value Range	1–8
Default Value	1

Index

Description	Indicates the index of the SIP-CS that is currently connected (reference only).
Value Range	1–128
Default Value	Not applicable.

RSSI

Description	Indicates the RSSI of the SIP-CS that is currently connected (reference only).
Value Range	-, -1 – -100
Note	<ul style="list-style-type: none">The RSSI is indicated by the color, as follows:<ul style="list-style-type: none">Green: -80 dBm or greaterYellow: Less than -80 dBmRed: Out of synchronization ("--")

Default Value	Not applicable.
----------------------	-----------------

Error Rate

Description	Indicates the Error Rate of the SIP-CS that is currently connected (reference only).
Value Range	-, 0 – 100 (%) Note <ul style="list-style-type: none"> The error rate is indicated by the color, as follows: <ul style="list-style-type: none"> Green: Less than 10% Yellow: 10% or greater Red: Out of synchronization ("")
Default Value	Not applicable.

Wired LAN

Description	Indicates the wired LAN status of the SIP-CS that is currently connected (reference only).
Value Range	<ul style="list-style-type: none"> OK NG Note <ul style="list-style-type: none"> The wired LAN status is indicated by the color, as follows: <ul style="list-style-type: none"> Green: OK Red: NG
Default Value	Not applicable.

CS Name

Description	Indicates the name of the SIP-CS that is currently connected (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

MAC Address

Description	Indicates the MAC address of the SIP-CS that is currently connected (reference only).
Value Range	Not applicable.
Default Value	Not applicable.

2.4.12 PS Registration

Status

Description	Indicates the service status of the SIP-CS that is currently connected (reference only).
Value Range	<ul style="list-style-type: none">• INS• - (not available)
Default Value	Not applicable.

Current Sync CS (CS Type)

Description	Indicates the type of the SIP-CS that is currently connected (reference only).
Value Range	<ul style="list-style-type: none">• Primary• Secondary• Other
Note	<ul style="list-style-type: none">• [Other] is displayed when the SIP-CS cannot be synchronized to the Primary CS or Secondary CS, but can be synchronized to another SIP-CS. In other words, synchronization to the Primary CS or Secondary CS is not available due to radio interference, the Primary/Secondary CS being turned off, etc., but synchronization to another SIP-CS is available.
Default Value	Not applicable.

Current Sync CS (CS RPT)

Description	Indicates whether a SIP-CS or a repeater is currently connected (reference only).
Value Range	CS
Default Value	CS (fixed)

Current Sync CS (CS Index)

Description	Indicates the index of the SIP-CS that is currently connected (reference only).
Value Range	1–128
Default Value	Not applicable.

2.4.12 PS Registration

This screen allows you to manage the registration of S-PSs to the SIP-CS.
Click a numbered tab to view this screen for a particular S-PS.

Note

- The [SIP Settings - PS [Line x]] screen will be displayed by clicking [Linex SIP Setting] under [Select Button] (→ see 2.5.2 SIP Settings - PS).

Panasonic

SIP CS KX-UDS124 Status | Network | **System** | VoIP | Telephone | Maintenance

[Web Logout](#)
[Web Port Close](#)

System

- [Web Language](#)
- [Administrator Password](#)
- [Change User Password](#)
- [Web Server Settings](#)
- [Time Setting](#)
- [Time Adjust Settings](#)
- [CS Name](#)
- [Air Settings](#)
- [CS Management](#)
- [Tree Survey](#)
- [CS Monitor](#)
- [PS Registration](#)
- [- PS Settings](#)

PS Registration

Please push the "Stop PS Registration" button to stop on the way after starting PS Registration.

PS Registration	Start PS Registration
	Stop PS Registration

Please push the "Delete PS Registration" to delete registered PS.

PS Registration Delete	Delete PS Registration
1 - 21 - 41 - 61 - 81 - 101 - 121 - 141 - 161 - 181 - 201 - 221 - 241	

PS Name / Number

No.	PS Name	Select Button	Phone Number	Wireless Status
1	test	Line1 SIP Setting Line2 SIP Setting	4261	Registered
2	test2	Line1 SIP Setting Line2 SIP Setting	4262	Registered

2.4.12.1 PS Registration**No.**

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Specifies the name of the S-PS that is registered to the SIP-CS.
Value Range	Max. 20 characters
Default Value	Not stored.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.4.14 PS Registration - Delete PS Registration

Wireless Status

Description	Indicates the wireless status of the S-PS that is registered to the SIP-CS (reference only).
Value Range	<ul style="list-style-type: none">• Registered• Un Registered
Default Value	Not applicable.

2.4.13 PS Registration - Start PS Registration

This screen will be displayed if **[Start PS Registration]** is clicked on the **[PS Registration]** screen. You can register the desired S-PSs to the SIP-CS as follows. To stop the preceding PS Registration, click **[Stop PS Registration]**.

1. Select the S-PSs to be registered in **[Available PS]**, and then click . To select all available S-PSs, click . To deselect S-PS(s), click  or .
2. Click **[Next]**. A dialog box to confirm the saving of settings is displayed.
3. Click **[OK]**.

2.4.14 PS Registration - Delete PS Registration

This screen will be displayed if **[Delete PS Registration]** is clicked on the **[PS Registration]** screen. You can delete the desired S-PSs from the SIP-CS as follows.

1. Select the S-PSs to be unregistered in **[Available PS]**, and then click . To select all available S-PSs, click . To deselect S-PS(s), click  or .
2. Click **[Next]**. A dialog box to confirm the saving of settings is displayed.
3. Click **[OK]**.

2.4.15 PS Registration - PS Settings

This screen allows you to set the PIN Code for S-PS registration.

2.4.15.1 PIN Code

PIN Code

Description	Specifies the PIN (Personal Identification Number) used when registering the S-PS.
Value Range	Max. 4 digits
Default Value	1234

2.5 VoIP

This section provides detailed descriptions about all the settings classified under the [VoIP] tab.

2.5.1 SIP Settings

2.5.1 SIP Settings

This screen allows you to change the SIP settings that are common to all lines.

Panasonic

SIP CS KX-UDS124 Status | Network | System | **VoIP** | Telephone | Maintenance

Web Logout | Web Port Close

SIP Settings

SIP Setting

SIP User Agent	Panasonic_{MODEL}/{fwver} ({mac})
----------------	-----------------------------------

SIP Server

Registrar Server Address	192.168.0.10
Registrar Server Port	5060 [1-65535]
Proxy Server Address	192.168.0.10
Proxy Server Port	5060 [1-65535]
Presence Server Address	
Presence Server Port	5060 [1-65535]

Outbound Proxy Server

Outbound Proxy Server Address	
Outbound Proxy Server Port	5060 [1-65535]

SIP Service Domain

Service Domain	
----------------	--

DNS

Enable DNS SRV lookup	<input checked="" type="radio"/> Yes <input type="radio"/> No
SRV lookup Prefix for UDP	_sip_udp.
SRV lookup Prefix for TCP	_sip_tcp.

Transport Protocol for SIP

Transport Protocol	<input checked="" type="radio"/> UDP <input type="radio"/> TCP
--------------------	--

Timer Settings

T1 Timer	500 milliseconds
T2 Timer	4 seconds
Timer B	32000 milliseconds [250-64000]
Timer D	5000 milliseconds [0, 250-64000]
Timer F	32000 milliseconds [250-64000]
Timer H	32000 milliseconds [250-64000]
Timer J	5000 milliseconds [0, 250-64000]

Quality of Service (QoS)

SIP Packet QoS (DSCP)	0 [0-63]
-----------------------	----------


SIP extensions

Supports 100rel (RFC 3262)	<input checked="" type="radio"/> Yes <input type="radio"/> No
Supports Session Timer (RFC 4028)	0 seconds [60-65535, 0: Disable]

Security

Enable SSAF (SIP Source Address Filter)	<input type="radio"/> Yes <input checked="" type="radio"/> No
---	---

All Save | Cancel |



2.5.1.1 SIP Setting

SIP User Agent

Description	Specifies the text string to send as the user agent in the headers of SIP messages.
-------------	---

Value Range	Max. 40 characters
Note	<ul style="list-style-type: none"> • You cannot leave this field empty. • If "{mac}" is included in this field, it will be replaced with the SIP-CS's MAC address in lower-case. • If "{MAC}" is included in this field, it will be replaced with the SIP-CS's MAC address in upper-case. • If "{MODEL}" is included in this field, it will be replaced with the SIP-CS's model name. • If "{fwver}" is included in this field, it will be replaced with the firmware version of the SIP-CS.
Default Value	Panasonic_{MODEL}/{fwver} ({mac})

2.5.1.2 SIP Server

Registrar Server Address

Description	Specifies the IP address or FQDN of the SIP registrar server.
Value Range	Max. 127 characters
Default Value	Not stored.

Registrar Server Port

Description	Specifies the port number to use for communication with the SIP registrar server.
Value Range	1–65535
Default Value	5060

Proxy Server Address

Description	Specifies the IP address or FQDN of the SIP proxy server.
Value Range	Max. 127 characters
Default Value	Not stored.

Proxy Server Port

Description	Specifies the port number to use for communication with the SIP proxy server.
Value Range	1–65535
Default Value	5060

2.5.1 SIP Settings

Presence Server Address

Description	Specifies the IP address or FQDN of the SIP presence server.
Value Range	Max. 127 characters
Default Value	Not stored.

Presence Server Port

Description	Specifies the port number to use for communication with the SIP presence server.
Value Range	1–65535
Default Value	5060

2.5.1.3 Outbound Proxy Server

Outbound Proxy Server Address

Description	Specifies the IP address or FQDN of the SIP outbound proxy server.
Value Range	Max. 127 characters
Default Value	Not stored.

Outbound Proxy Server Port

Description	Specifies the port number to use for communication with the SIP outbound proxy server.
Value Range	1–65535
Default Value	5060

2.5.1.4 SIP Service Domain

Service Domain

Description	Specifies the domain name provided by your dealer. The domain name is the part of the SIP URI that comes after the "@" symbol.
Value Range	Max. 127 characters
Default Value	Not stored.

2.5.1.5 DNS

Enable DNS SRV lookup

Description	Selects whether to request the DNS server to translate domain names into IP addresses using the SRV record.
Value Range	<ul style="list-style-type: none"> • Yes • No <p>Note</p> <ul style="list-style-type: none"> • If you select [Yes], the SIP-CS will perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server. If you select [No], the SIP-CS will not perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.
Default Value	Yes

SRV lookup Prefix for UDP

Description	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using UDP.
Note	<ul style="list-style-type: none"> • This setting is available only when [Enable DNS SRV lookup] is set to [Yes].
Value Range	Max. 32 characters
Default Value	_sip._udp.

SRV lookup Prefix for TCP

Description	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using TCP.
Note	<ul style="list-style-type: none"> • This setting is available only when [Enable DNS SRV lookup] is set to [Yes].
Value Range	Max. 32 characters
Default Value	_sip._tcp.

2.5.1.6 Transport Protocol of SIP

Transport Protocol

Description	Selects which transport layer protocol to use for sending SIP packets.
--------------------	--

2.5.1 SIP Settings

Value Range	<ul style="list-style-type: none">• UDP• TCP
Default Value	UDP

2.5.1.7 Timer Settings

T1 Timer

Description	Selects the default interval, in milliseconds, between transmissions of SIP messages. For details, refer to RFC 3261.
Value Range	<ul style="list-style-type: none">• 250• 500• 1000• 2000• 4000
Default Value	500

T2 Timer

Description	Selects the maximum interval, in seconds, between transmissions of SIP messages. For details, refer to RFC 3261.
Value Range	<ul style="list-style-type: none">• 2• 4• 8• 16• 32
Default Value	4

Timer B

Description	Specifies the value of SIP timer B (INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000
Default Value	32000

Timer D

Description	Specifies the value of SIP timer D (wait time for answer resending), in milliseconds. For details, refer to RFC 3261.
Value Range	0, 250–64000
Default Value	5000

Timer F

Description	Specifies the value of SIP timer F (non-INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000
Default Value	32000

Timer H

Description	Specifies the value of SIP timer H (wait time for ACK reception), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000
Default Value	32000

Timer J

Description	Specifies the value of SIP timer J (wait time for non-INVITE request resending), in milliseconds. For details, refer to RFC 3261.
Value Range	0, 250–64000
Default Value	5000

2.5.1.8 Quality of Service (QoS)

SIP Packet QoS (DSCP)

Description	Specifies the DSCP (Differentiated Services Code Point) level of DiffServ applied to SIP packets.
Value Range	0–63
Default Value	0

2.5.1.9 SIP extensions

Supports 100rel (RFC 3262)

Description	Selects whether to add the option tag 100rel to the "Supported" header of the INVITE message. For details, refer to RFC 3262.
--------------------	---

2.5.2 SIP Settings - PS

Value Range	<ul style="list-style-type: none">• Yes• No
Note <ul style="list-style-type: none">• If you select [Yes], the Reliability of Provisional Responses function will be enabled. The option tag 100rel will be added to the "Supported" header of the INVITE message and to the "Require" header of the "1xx" provisional message. If you select [No], the option tag 100rel will not be used.	
Default Value	No

Supports Session Timer (RFC 4028)

Description	Specifies the length of time, in seconds, that the SIP-CS waits before terminating SIP sessions when no reply to repeated requests is received. For details, refer to RFC 4028.
Value Range	0, 60–65535 (0: Disable)
Default Value	0

2.5.1.10 Security

Enable SSAF (SIP Source Address Filter)

Description	Selects whether to enable SSAF (SIP Source Address Filter) for the SIP servers (registrar server, proxy server, and presence server).
Value Range	<ul style="list-style-type: none">• Yes• No
Note <ul style="list-style-type: none">• If you select [Yes], the SIP-CS receives SIP messages only from the source addresses stored in the SIP servers (registrar server, proxy server, and presence server), and not from other addresses. However, if [Outbound Proxy Server Address] in 2.5.1.3 Outbound Proxy Server is specified, the SIP-CS also receives SIP messages from the source address stored in the SIP outbound proxy server.	
Default Value	No

2.5.2 SIP Settings - PS

This screen allows you to check the SIP settings of S-PSs.

Click a numbered tab to view this screen for a particular S-PS.

No.	PS Name	Line No.	Phone Number	Select Button
1	001	1 2	1100	<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>
2		1 2		<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>

2.5.2.1 SIP Settings

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Line No.

Description	Indicates the line number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	Line 1–2
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.5.3 SIP Settings - PS [Line 1–2]

2.5.3 SIP Settings - PS [Line 1–2]

This screen will be displayed by clicking [**Linex SIP Setting**] under [**Select Button**] on the [**SIP Settings - PS**] screen. You can change the SIP settings for the specific line of the desired S-PS on this screen.

Panasonic

SIP CS KX-UDS124 Status Network System **VoIP** Telephone Maintenance

Web Logout Web Port Close Back

VoIP

SIP Settings **SIP Settings - PS** VoIP Settings

SIP Settings - PS [Line 1]


PS Name
PS Name: 001

Phone Number
Phone Number: 1100
SIP URI:

SIP Authentication
Authentication ID: 1100
Authentication Password:

SIP Source Port
Source Port: 5061 [1024-49151]

All Save Cancel



2.5.3.1 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.5.3.2 Phone Number

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not stored.

SIP URI

Description	Specifies the unique ID used by the SIP registrar server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com".
Note	<ul style="list-style-type: none"> When registering using a user ID that is not a phone number, you should use this setting. In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.
Value Range	Max. 195 characters
Default Value	Not stored.

2.5.3.3 SIP Authentication

Authentication ID

Description	Specifies the authentication ID of the S-PS that is registered to the SIP-CS.
Value Range	Max. 127 characters (except ", &, ', :, <, >, and space)
Default Value	Not stored.

Authentication Password

Description	Specifies the authentication password of the S-PS that is registered to the SIP-CS.
Value Range	Max. 127 characters (except ", &, ', :, <, >, and space)
Default Value	Not stored.

2.5.3.4 SIP Source Port

Source Port

Description	Specifies the source port number of the S-PS that is registered to the SIP-CS.
Value Range	1024–49151
Default Value	<ul style="list-style-type: none"> PS1 Line1: 5061 PS1 Line2: 5062 PS2 Line1: 5063... <p>Note</p> <ul style="list-style-type: none"> The default value increases by 1 for each line.

2.5.4 VoIP Settings

2.5.4 VoIP Settings

This screen allows you to change the VoIP settings that are common to all lines.

Panasonic

SIP CS KX-UDS124 Status Network System **VoIP** Telephone Maintenance

Web Logout Web Port Close

VoIP

SIP Settings SIP Settings - PS **VoIP Settings**

VoIP Settings

RTP Settings

RTP Packet Time	20 <input type="button" value="milliseconds"/>
Minimum RTP Port Number	16000 [1024-48750: Even Number Only]
Maximum RTP Port Number	20000 [1424-49150: Even Number Only]
Telephone-event Payload Type	101 [96-127]

Quality of Service (QoS)

RTP Packet QoS (DSCP)	0 [0-63]
-----------------------	----------

Statistical Information

RTCP Enable	<input type="radio"/> Yes <input checked="" type="radio"/> No
RTCP Interval	5 seconds [5-65535]

Jitter Buffer

Maximum Delay	20 [3-50]
Minimum Delay	2 [1-2]
Initial Delay	2 [1-7]

DTMF

DTMF Type	<input checked="" type="radio"/> Outband <input type="radio"/> Inband
-----------	---


Call Hold

Supports RFC 2543 (c=0.0.0.0)	<input checked="" type="radio"/> Yes <input type="radio"/> No
-------------------------------	---

CODEC Preferences

G722	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	1 [1-255]
PCMA	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	1 [1-255]
G726-32	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	1 [1-255]
G729A	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	1 [1-255]
PCMU	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	1 [1-255]

All Save Cancel



2.5.4.1 RTP Settings

RTP Packet Time

Description	Selects the interval, in milliseconds, between transmissions of RTP packets.
Value Range	<ul style="list-style-type: none">• 20• 30• 40
Default Value	20

Minimum RTP Port Number

Description	Specifies the lowest port number that the SIP-CS will use for RTP packets.
Note	<ul style="list-style-type: none"> The available channel number varies depending on the type of the SIP-CS being used.
Value Range	1024–45150 (even number only) Note <ul style="list-style-type: none"> The value for this setting must be less than or equal to "[Maximum RTP Port Number] - 4000". Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: $\text{No. of lines} \times \text{No. of channels} \times 2 \times 1$ (No. of terminals)
Default Value	16000

Maximum RTP Port Number

Description	Specifies the highest port number that the SIP-CS will use for RTP packets.
Note	<ul style="list-style-type: none"> The available channel number varies depending on the type of the SIP-CS being used.
Value Range	5024–49150 (even number only) Note <ul style="list-style-type: none"> The value for this setting must be greater than or equal to "[Minimum RTP Port Number] + 4000". Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: $\text{No. of lines} \times \text{No. of channels} \times 2 \times 1$ (No. of terminals)
Default Value	29000

Telephone-event Payload Type

Description	Specifies the RFC 2833 payload type for DTMF tones.
Note	<ul style="list-style-type: none"> This setting is available only when [DTMF Type] is set to [Outband].
Value Range	96–127

2.5.4 VoIP Settings

Default Value	101
---------------	-----

2.5.4.2 Quality of Service (QoS)

RTP Packet QoS (DSCP)

Description	Specifies the DSCP level of DiffServ applied to RTP packets.
Value Range	0–63
Default Value	0

2.5.4.3 Statistical Information

RTCP Enable

Description	Selects whether to enable or disable RTCP (Real-Time Transport Control Protocol). For details, refer to RFC 3550.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	No

RTCP Interval

Description	Specifies the interval, in seconds, between RTCP packets.
Value Range	5–65535
Default Value	5

2.5.4.4 Jitter Buffer

Maximum Delay

Description	Specifies the maximum delay, in 10-millisecond units, of the jitter buffer.
Value Range	3–50 ($\times 10$ ms)
Note	<ul style="list-style-type: none">• This setting is subject to the following conditions:<ul style="list-style-type: none">– This value must be greater than [Initial Delay]– This value must be greater than [Minimum Delay]– [Initial Delay] must be greater than or equal to [Minimum Delay]
Default Value	20 ($\times 10$ ms)

Minimum Delay

Description	Specifies the minimum delay, in 10-millisecond units, of the jitter buffer.
Value Range	1 or 2 ($\times 10$ ms)
	<p>Note</p> <ul style="list-style-type: none"> This setting is subject to the following conditions: <ul style="list-style-type: none"> This value must be less than or equal to [Initial Delay] This value must be less than [Maximum Delay] [Maximum Delay] must be greater than [Initial Delay]
Default Value	2 ($\times 10$ ms)

Initial Delay

Description	Specifies the initial delay, in 10-millisecond units, of the jitter buffer.
Value Range	1–7 ($\times 10$ ms)
	<p>Note</p> <ul style="list-style-type: none"> This setting is subject to the following conditions: <ul style="list-style-type: none"> This value must be greater than or equal to [Minimum Delay] This value must be less than [Maximum Delay]
Default Value	2 ($\times 10$ ms)

2.5.4.5 DTMF

DTMF Type

Description	Selects the method for transmitting DTMF (Dual Tone Multi-Frequency) tones.
Value Range	<ul style="list-style-type: none"> Outband Inband
	<p>Note</p> <ul style="list-style-type: none"> If you select [Outband], DTMF tones will be sent through SDP (Session Description Protocol), compliant with RFC 2833. If you select [Inband], DTMF tones will be encoded in the RTP stream.
Default Value	Outband

2.5.4.6 Call Hold

Supports RFC 2543 (c=0.0.0.0)

Description	Selects whether to enable the RFC 2543 Call Hold feature on this line.
--------------------	--

2.5.4 VoIP Settings

Value Range	<ul style="list-style-type: none">• Yes• No <p>Note</p> <ul style="list-style-type: none">• If you select [Yes], the "c=0.0.0.0" syntax will be set in SDP when sending a re-INVITE message to hold the call. If you select [No], the "c=x.x.x.x" syntax will be set in SDP.
Default Value	Yes

2.5.4.7 CODEC Preferences

G722 (Enable)

Description	Selects whether to enable the G.722 codec for voice data transmission.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	Yes

G722 (Priority)

Description	Specifies the numerical order usage priority for the G.722 codec.
Value Range	1–255
Default Value	1

PCMA (Enable)

Description	Selects whether to enable the PCMA codec for voice data transmission.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	Yes

PCMA (Priority)

Description	Specifies the numerical order usage priority for the PCMA codec.
Value Range	1–255
Default Value	1

G726-32 (Enable)

Description	Selects whether to enable the G.726-32 codec for voice data transmission.
Value Range	<ul style="list-style-type: none"> • Yes • No
Default Value	Yes

G726-32 (Priority)

Description	Specifies the numerical order usage priority for the G.726-32 codec.
Value Range	1–255
Default Value	1

G729A (Enable)

Description	Selects whether to enable the G.729A codec for voice data transmission.
Value Range	<ul style="list-style-type: none"> • Yes • No
Default Value	Yes

G729A (Priority)

Description	Specifies the numerical order usage priority for the G.729A codec.
Value Range	1–255
Default Value	1

PCMU (Enable)

Description	Selects whether to enable the PCMU codec for voice data transmission.
Value Range	<ul style="list-style-type: none"> • Yes • No
Default Value	Yes

PCMU (Priority)

Description	Specifies the numerical order usage priority for the PCMU codec.
Value Range	1–255

2.6.1 Call Control - Common

Default Value	1
---------------	---

2.6 Telephone

This section provides detailed descriptions about all the settings classified under the [Telephone] tab.

2.6.1 Call Control - Common

This screen allows you to configure various call features that are common to all lines. Click the [Common] tab to view this screen.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Telephone

- [Call Control](#) (selected)
- [Button Settings](#)
- [Tone Settings](#)
- [Telephone Settings](#)
- [Import Phonebook](#)
- [Export Phonebook](#)


Call Control

Send SUBSCRIBE to Voice Mail Server	<input type="radio"/> Yes <input checked="" type="radio"/> No
Conference Server URI	<input type="text"/>
Inter-digit Timeout	5 <input type="button" value="▼"/> seconds
Timer for Dial Plan	5 <input type="button" value="▼"/> seconds
International Call Prefix	<input type="text"/>
Country Calling Code	<input type="text"/>
National Access Code	<input type="text"/>
Flash/Recall Button	<input checked="" type="radio"/> Terminate <input type="radio"/> Flash Hook
Flash Hook Event	<input checked="" type="radio"/> Signal <input type="radio"/> flashhook

Call Rejection Phone Numbers

1.	<input type="text"/>	2.	<input type="text"/>
3.	<input type="text"/>	4.	<input type="text"/>
5.	<input type="text"/>	6.	<input type="text"/>
7.	<input type="text"/>	8.	<input type="text"/>
9.	<input type="text"/>	10.	<input type="text"/>
11.	<input type="text"/>	12.	<input type="text"/>
13.	<input type="text"/>	14.	<input type="text"/>
15.	<input type="text"/>	16.	<input type="text"/>
17.	<input type="text"/>	18.	<input type="text"/>
19.	<input type="text"/>	20.	<input type="text"/>
21.	<input type="text"/>	22.	<input type="text"/>
23.	<input type="text"/>	24.	<input type="text"/>
25.	<input type="text"/>	26.	<input type="text"/>
27.	<input type="text"/>	28.	<input type="text"/>
29.	<input type="text"/>	30.	<input type="text"/>

All Save Cancel



2.6.1.1 Call Control

Send SUBSCRIBE to Voice Mail Server

Description	Selects whether to send the SUBSCRIBE request to a voice mail server.
Note	<ul style="list-style-type: none"> Your phone system must support voice mail.
Value Range	<ul style="list-style-type: none"> Yes No
Default Value	No

Conference Server URI

Description	Specifies the URI for a conference server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:conference@example.com".
Note	<ul style="list-style-type: none"> In a SIP URI, the user part ("conference" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters. Availability depends on your phone system.
Value Range	Max. 195 characters (except ", &, ', ;, <, >, and space)
Default Value	Not stored.

Inter-digit Timeout

Description	Specifies the length of time, in seconds, within which subsequent digits of a dial number must be dialed. When this timer expires after the last key was pressed, dialing will start.
Value Range	1–15
Default Value	5

Timer for Dial Plan

Description	Specifies the length of time, in seconds, that the SIP-CS waits before dialing the telephone number modified according to the dial plan.
Value Range	1–15
Default Value	5

International Call Prefix

Description	Specifies the number to be shown in the place of the first "+" symbol when the phone number for incoming international calls contains "+".
Value Range	Max. 8 characters
Default Value	Not stored.

Country Calling Code

Description	Specifies the country/area calling code to be used for comparative purposes when dialing a number from the incoming call log that contains a "+" symbol.
Value Range	Max. 8 characters
Default Value	Not stored.

National Access Code

Description	When dialing a number from the incoming call log that contains a "+" symbol and the country calling code matches, the country calling code is removed and the national access code is added.
Value Range	Max. 8 characters
Default Value	Not stored.

Flash/Recall Button

Description	Selects the function of the FLASH/RECALL button during a conversation.
Value Range	<ul style="list-style-type: none"> • Terminate • Flash Hook
Default Value	Terminate

Flash Hook Event

Description	Selects the type of signal sent when sending a flash hook event.
Value Range	<ul style="list-style-type: none"> • Signal • flashhook
Default Value	Signal

2.6.1.2 Call Rejection Phone Numbers

1–30

Description	Specifies the phone numbers to reject incoming calls from. A maximum of 30 phone numbers can be specified.
Value Range	<p>Max. 32 characters</p> <p>Note</p> <ul style="list-style-type: none"> Even if you specify nonconsecutive fields (e.g., fields 1, 5, and 30), they will be rearranged into consecutive fields after you save the settings (i.e., 1, 2, and 3). If the phone number contains characters other than 0–9, *, #, and +, the number may not be rejected correctly.
Default Value	Not stored.

2.6.2 Call Control - PS

This screen allows you to view the current call feature settings for a specific S-PS.
Click a numbered tab to view this screen for a particular S-PS.

No.	PS Name	Select Button	Line No.	Phone Number	Select Button
1	001	PS Call Control	1100	Line1 Call Control	
2		PS Call Control	1100	Line2 Call Control	
3		PS Call Control	1100	Line1 Call Control	
			1100	Line2 Call Control	

2.6.2.1 Call Control

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

2.6.3 Call Control [PS]

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Line No. 1–2

Description	Indicates the line number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	Line 1–2
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.6.3 Call Control [PS]

This screen will be displayed by clicking [PS Call Control] on the [Call Control - PS] screen. You can configure call features for the desired S-PS on this screen.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Call Control [PS]

Back

Web Logout | Web Port Close

Telephone

- [Call Control](#) (selected)
- [Button Settings](#)
- [Tone Settings](#)
- [Telephone Settings](#)
- [Import Phonebook](#)
- [Export Phonebook](#)

PS Name

PS Name	001
---------	-----

Call Control

Default Line for Outgoing	1
---------------------------	---

Dial Plan

Dial Plan (max 500 columns)	<input type="text"/>
Call Even If Dial Plan Does Not Match	<input checked="" type="radio"/> Yes <input type="radio"/> No

All Save | Cancel

2.6.3.1 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.6.3.2 Call Control

Default Line for Outgoing

Description	Selects the line used to make an outgoing call when no line is specified in the dialing operation.
Note	<ul style="list-style-type: none"> The available line number may vary depending on the type of the SIP-CS being used.
Value Range	1–2
Default Value	1

2.6.3.3 Dial Plan

Dial Plan (max 500 columns)

Description	Specifies a dial format, such as specific phone numbers, that control which numbers can be dialed or how to handle the call when making a call. For details, see 6.2 Dial Plan .
Value Range	Max. 500 characters
Note	<ul style="list-style-type: none"> Entering more than 500 characters in this field causes an error and the previous value remains effective.
Default Value	Not stored.

Call Even If Dial Plan Does Not Match

Description	Selects whether to enable dial plan filtering so that a call is not made when the dialed number does not match any of the dial formats specified in [Dial Plan] .
--------------------	---

2.6.4 Call Control [Line 1–2]

Value Range	<ul style="list-style-type: none"> • Yes • No <p>Note</p> <ul style="list-style-type: none"> • If you select [Yes], calls will be made even if the dialed number does not match the dial formats specified in [Dial Plan] (i.e., dial plan filtering is disabled). If you select [No], calls will not be made if the dialed number does not match one of the dial formats specified in [Dial Plan] (i.e., dial plan filtering is enabled).
Default Value	Yes

2.6.4 Call Control [Line 1–2]

This screen will be displayed by clicking [**Linex Call Control**] on the [**Call Control - PS**] screen. You can configure various call features for the selected line of the desired S-PS on this screen.

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | Maintenance

Call Control [Line 1]

PS Name
PS Name: 001

Phone Number
Phone Number: 1100

Call Control

Display Name	[Input Field]
Voice Mail Access Number	[Input Field]
Enable Shared Call	<input type="radio"/> Yes <input checked="" type="radio"/> No
Synchronize Do Not Disturb and Call Forward	<input type="radio"/> Yes <input checked="" type="radio"/> No

Call Features

Block Caller ID	<input type="radio"/> Yes <input checked="" type="radio"/> No
Block Anonymous Call	<input type="radio"/> Yes <input checked="" type="radio"/> No
Do Not Disturb	<input type="radio"/> Yes <input checked="" type="radio"/> No

Call Forward

	Enable Call Forward	<input type="radio"/> Yes <input checked="" type="radio"/> No
Unconditional	Phone Number	[Input Field]
Busy	Enable Call Forward	<input type="radio"/> Yes <input checked="" type="radio"/> No
	Phone Number	[Input Field]
No Answer	Enable Call Forward	<input type="radio"/> Yes <input checked="" type="radio"/> No
	Phone Number	[Input Field]
	Ring Count	[Input Field] count(s) [0, 2-20]

All Save | Cancel

2.6.4.1 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
--------------------	---

Value Range	Max. 20 characters
Default Value	Not applicable.

2.6.4.2 Phone Number

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.6.4.3 Call Control

Display Name

Description	Specifies the name to display as the caller on the other party's phone when you make a call.
Value Range	Max. 24 characters
Note	<ul style="list-style-type: none"> You can use Unicode characters for this setting.
Default Value	Not stored.

Voice Mail Access Number

Description	Specifies the phone number used to access the voice mail server.
Note	<ul style="list-style-type: none"> Your phone system must support voice mail.
Value Range	Max. 32 characters
Default Value	Not stored.

Enable Shared Call

Description	Selects whether to enable the Shared Call feature of the SIP server, which is used to share one line among the SIP-CSs.
Note	<ul style="list-style-type: none"> You cannot set both [Enable Shared Call] and [Synchronize Do Not Disturb and Call Forward] to [Yes] at the same time. Availability depends on your phone system.

2.6.4 Call Control [Line 1–2]

Value Range	<ul style="list-style-type: none">• Yes• No <p>Note</p> <ul style="list-style-type: none">• If you select [Yes], the SIP server will control the line by using a shared-call signaling method. If you select [No], the SIP server will control the line by using a standard signaling method.
Default Value	No

Synchronize Do Not Disturb and Call Forward

Description	Selects whether to synchronize the Do Not Disturb and Call Forward settings, configured via the Web user interface, between the SIP-CS and the portal server that is provided by your dealer.
Note	<ul style="list-style-type: none">• Even if you select [Yes], this feature may not function properly if your phone system does not support it. Before you configure this setting, consult your dealer.• You cannot set both [Enable Shared Call] and [Synchronize Do Not Disturb and Call Forward] to [Yes] at the same time.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	No

2.6.4.4 Call Features

Block Caller ID

Description	Selects whether to make calls without transmitting the phone number to the called party.
Note	<ul style="list-style-type: none">• Availability depends on your phone system.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	No

Block Anonymous Call

Description	Selects whether to reject incoming calls that do not show the caller's number.
Value Range	<ul style="list-style-type: none">• Yes• No

Default Value	No
----------------------	----

Do Not Disturb

Description	Selects whether to enable the Do Not Disturb feature for incoming calls.
Note	<ul style="list-style-type: none"> If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the SIP-CS does not receive any calls, even if you have selected [No] for this setting. If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	<ul style="list-style-type: none"> Yes No
Default Value	No

2.6.4.5 Call Forward

Unconditional (Enable Call Forward)

Description	Selects whether to forward all incoming calls to a specified destination.
Note	<ul style="list-style-type: none"> If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the SIP-CS does not receive any calls, even if you have selected [Yes] for this setting. If you have selected [Yes] for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server. If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected [No] for this setting. You can synchronize the Do Not Disturb and Call Forward settings from the Web user interface (→ see [Synchronize Do Not Disturb and Call Forward] in 2.6.4.3 Call Control) or through configuration file programming (→ see "FWD_DND_SYNCHRO_ENABLE_PSY_n" in 4.6.1 Call Control Settings). If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	<ul style="list-style-type: none"> Yes No

2.6.4 Call Control [Line 1-2]

Default Value	No
----------------------	----

Unconditional (Phone Number)

Description	Specifies the phone number of the destination to forward all incoming calls to.
Note	<ul style="list-style-type: none"> If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	Max. 32 characters
Note	<ul style="list-style-type: none"> You cannot leave this field empty if [Unconditional (Enable Call Forward)] is set to [Yes].
Default Value	Not stored.

Busy (Enable Call Forward)

Description	Selects whether to forward incoming calls to a specified destination when the line is in use.
Note	<ul style="list-style-type: none"> If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the SIP-CS does not receive any calls, even if you have selected [Yes] for this setting. If you have selected [Yes] for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server. If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected [No] for this setting. You can synchronize the Do Not Disturb and Call Forward settings from the Web user interface (→ see [Synchronize Do Not Disturb and Call Forward] in 2.6.4.3 Call Control) or through configuration file programming (→ see "FWD_DND_SYNCHRO_ENABLE_PSy_n" in 4.6.1 Call Control Settings). If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	<ul style="list-style-type: none"> Yes No
Default Value	No

Busy (Phone Number)

Description	Specifies the phone number of the destination to forward calls to when the line is in use.
Note	<ul style="list-style-type: none"> If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	Max. 32 characters
Note	<ul style="list-style-type: none"> You cannot leave this field empty if [Busy (Enable Call Forward)] is set to [Yes].
Default Value	Not stored.

No Answer (Enable Call Forward)

Description	Selects whether to forward incoming calls to a specified destination when a call is not answered after it has rung a specified number of times.
Note	<ul style="list-style-type: none"> If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the SIP-CS does not receive any calls, even if you have selected [Yes] for this setting. If you have selected [Yes] for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server. If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected [No] for this setting. You can synchronize the Do Not Disturb and Call Forward from the Web user interface (→ see [Synchronize Do Not Disturb and Call Forward] in 2.6.4.3 Call Control) or through configuration file programming (→ see "FWD_DND_SYNCHRO_ENABLE_PSY_n" in 4.6.1 Call Control Settings). If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	<ul style="list-style-type: none"> Yes No
Default Value	No

2.6.5 Button Settings

No Answer (Phone Number)

Description	Specifies the phone number of the destination to forward calls to when a call is not answered after it has rung a specified number of times.
Note	<ul style="list-style-type: none">If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	Max. 32 characters
Note	<ul style="list-style-type: none">You cannot leave this field empty if [No Answer (Enable Call Forward)] is set to [Yes].
Default Value	Not stored.

No Answer (Ring Count)

Description	Specifies the number of times that an incoming call rings until the call is forwarded.
Note	<ul style="list-style-type: none">If you change this setting when [Synchronize Do Not Disturb and Call Forward] is set to [Yes], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.
Value Range	0, 2–20 (0: No ring)
Default Value	3

2.6.5 Button Settings

This screen allows you to view the name and phone number of each S-PS.
Click a numbered tab to view this screen for a particular S-PS.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Button Settings

1- 21- 41- 61- 81- 101- 121- 141- 161- 181- 201- 221- 241-

Button Settings				
No.	PS Name	Phone Number	Select Button	Select Button
1	001	1100	Button Settings	Copy & Paste
2			Button Settings	Copy & Paste
3			Button Settings	Copy & Paste
4			Button Settings	Copy & Paste

Telephone

Call Control
Button Settings
Tone Settings
Telephone Settings
Import Phonebook
Export Phonebook

2.6.5.1 Button Settings

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.6.6 Button Settings - PS

This screen will be displayed by clicking [Button Settings] under [Select Button] on the [Button Settings] screen. This screen allows you to configure various features for each flexible button. For more details, see [6.3 Flexible Buttons](#).

No.	Type	Parameter	Label Name
1.	DN	1	
2.	DN	1	
3.	DN	1	
4.	DN	1	
5.	DN	1	
6.	DN	1	
7.	DN	1	
8.	DN	1	
9.	DN	1	
10.	DN	1	
11.	DN	1	
12.	DN	1	

2.6.6.1 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.6.6.2 Flexible Button Settings

No.

Description	Indicates the number of each flexible button for the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–12
Default Value	Not applicable.

Type (No. 1–12)

Description	Selects the feature to be assigned to each flexible button.
Value Range	<ul style="list-style-type: none"> • DN • One-Touch • Not store
Default Value	DN

Parameter (No. 1–12)

Description	Specifies the necessary values for the features assigned to flexible buttons.
Value Range	Max. 32 characters
Default Value	1

Label Name (No. 1–12)

Description	Specifies the message to be displayed on the screen when the flexible button is pressed.
Value Range	Max. 10 characters
Default Value	Not stored.

2.6.7 Button Settings - Copy & Paste

This screen will be displayed by clicking [Copy & Paste] under [Select Source] on the [Button Settings] screen. You can copy the flexible button settings for an S-PS and apply them to other S-PSs on this screen. For more details, see **6.4 Copying Flexible Button Settings to Other S-PSs**.



2.6.7.1 Copy Source PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.6.7.2 Copy Source Flexible Button Settings

No.

Description	Indicates the number of each flexible button for the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–12

Default Value	Not applicable.
----------------------	-----------------

Type (No. 1–12)

Description	Selects the feature to be assigned to each flexible button.
Value Range	<ul style="list-style-type: none"> • DN • One-Touch • Not store
Default Value	DN

Parameter (No. 1–12)

Description	Specifies the necessary values for the features assigned to flexible buttons.
Value Range	Max. 32 characters
Default Value	1

Label Name (No. 1–12)

Description	Specifies the message to be displayed on the screen when the flexible button is pressed.
Value Range	Max. 10 characters
Default Value	Not stored.

2.6.7.3 Copy Destination PS Lists

You can copy the flexible button settings as follows.

1. Select the S-PSs to have settings copied to in **[Available PS]**, and then click . To select all available S-PSs, click . To deselect S-PS(s), click  or .
2. Click **[Copy & Paste]**.

2.6.8 Tone Settings

2.6.8 Tone Settings

This screen allows you to configure the dual-tone frequencies and ringtone patterns of each tone.

2.6.8.1 Dial Tone

Tone Frequencies

Description	Specifies the dual-tone frequencies, in hertz, of dial tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
	Note <ul style="list-style-type: none">If the value for this setting is "350,440", the SIP-CS will use a mixed signal of a 350 Hz tone and a 440 Hz tone.
Default Value	350,440

Tone Timings

Description	Specifies the pattern, in milliseconds, of dial tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
Note	<ul style="list-style-type: none"> The SIP-CS will not play the tone for the duration of the first value, play it for the duration of the second value, stop it for the duration of the third value, play it again for the duration of the fourth value, and so on. The whole sequence will then repeat. For example, if the value for this setting is "100,100,100,0", the SIP-CS will not play the tone for 100 ms, play it for 100 ms, stop it for 100 ms, and then play it continuously. It is recommended that you set a value of 60 milliseconds or more for the first value (off 1). Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,0

2.6.8.2 Busy Tone

Tone Frequencies

Description	Specifies the dual-tone frequencies, in hertz, of busy tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	480,620

Tone Timings

Description	Specifies the pattern, in milliseconds, of busy tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
Note	<ul style="list-style-type: none"> It is recommended that you set a value of 60 milliseconds or more for the first value (off 1). Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,500,440

2.6.8 Tone Settings

2.6.8.3 Ringing Tone

Tone Frequencies

Description	Specifies the dual-tone frequencies, in hertz, of ringback tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	440,480

Tone Timings

Description	Specifies the pattern, in milliseconds, of ringback tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
	Note <ul style="list-style-type: none"><li data-bbox="647 804 1283 824">• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).<li data-bbox="647 848 1283 869">• Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,2000,3940

2.6.8.4 Stutter Tone

Tone Frequencies

Description	Specifies the dual-tone frequencies, in hertz, of stutter dial tones to notify that a voice mail is waiting, using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	350,440

Tone Timings

2.6.8.5 Reorder Tone

Tone Frequencies


Description	Specifies the dual-tone frequencies, in hertz, of reorder tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	480,620

Tone Timings

Description	Specifies the pattern, in milliseconds, of reorder tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
Note	<ul style="list-style-type: none"> It is recommended that you set a value of 60 milliseconds or more for the first value (off 1). Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,250,190

2.6.9 Telephone Settings

This screen allows you to configure the minimum and maximum number of digits with which to match a phonebook entry with an incoming call's caller ID.



2.6.9.1 Telephone Settings

Number Matching Lower Digit

Description	Specifies the minimum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
Value Range	1–15

2.6.10 Import Phonebook - All

Default Value	7
---------------	---

Number Matching Upper Digit

Description	Specifies the maximum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
Value Range	1–15
Default Value	10

2.6.10 Import Phonebook - All

This screen allows you to import the phonebook data from a PC to all S-PSs. For details, see [6.1.1 Import/Export Operation](#).

Click the [All] tab to view this screen.

Note

- If the existing phonebook data has an entry with the same name and phone number as an imported entry, the imported entry is not added as a new entry.
- When you begin transferring the phonebook data, the "Now Processing File Data" screen is displayed, and the screen is periodically reloaded. Depending on your Web browser, the screen might not reload automatically, and you will need to click the text "HERE" before the timer expires in order for the import operation to function properly.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Import Phonebook

All 1- 21- 41- 61- 81- 101- 121- 141- 161- 181- 201- 221- 241-

Import Mode
Mode Direct Appoint Date/Time

Import Time Setting
Date 1 / 31 / 2012 [mm / dd / yyyy]
Time 00 : 00 [hh : mm]

Import Phonebook
File Name Browse...
All Import

Telephone
Call Control
Button Settings
Tone Settings
Telephone Settings
Import Phonebook
Export Phonebook

2.6.10.1 Import Mode

Mode Select

Description	Selects the method of import.
Value Range	<ul style="list-style-type: none">Direct (The import starts immediately.)Appoint Date/Time (The import starts at the set time.)
Default Value	Direct

2.6.10.2 Import Time Setting

Date

Description	Specifies the month (1–2 digits), date (1–2 digits), and year (4 digits) of the import.
Value Range	Month: 1–12, Date: 1–31, Year: 2000–2099
Default Value	1/31/2012

Time

Description	Specifies hour (1–2 digits) and minute (1–2 digits) of the import.
Value Range	00:00–23:59
Default Value	00:00

2.6.10.3 Import Phonebook

File Name

Description	Specifies the path of the TSV (Tab-separated Value) file to import from the PC.
Value Range	No limitation
	<p>Note</p> <ul style="list-style-type: none"> There are no limitations for the field entry. However, it is recommended that paths of less than 254 characters be used: longer paths may cause longer data transfer times and result in an internal error.
Default Value	Not stored.

2.6.11 Import Phonebook - PS

This screen allows you to view the name and phone number of each S-PS.

2.6.11 Import Phonebook - PS

Click a numbered tab to view this screen for a particular S-PS.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Import Phonebook

All 1- 21- 41- 61- 81- 101- 121- 141- 161- 181- 201- 221- 241-

Telephone

Call Control
Button Settings
Tone Settings
Telephone Settings
Import Phonebook
Export Phonebook

Import Phonebook

No	PS Name	Phone Number	Select Button
1	001	1100,	Import Phonebook
2			Import Phonebook
3			Import Phonebook
4			Import Phonebook

2.6.11.1 Import Phonebook

No.

Description	Indicates the table number of the S-PS that is registered to the SIP-CS (reference only).
Value Range	1–255
Default Value	Not applicable.

PS Name


Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.6.12 Import Phonebook (PS select screen)

This screen will be displayed by clicking [Import Phonebook] under [Select Button] on the [Import Phonebook - PS] screen. You can import the phonebook data from a PC to the desired S-PS.



2.6.12.1 PS Name

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

2.6.12.2 Import Phonebook

File Name

Description	Specifies the path of the TSV (Tab-separated Value) file to import from the PC.
Value Range	No limitation
<u>Note</u>	<ul style="list-style-type: none"> There are no limitations for the field entry. However, it is recommended that paths of less than 254 characters be used: longer paths may cause longer data transfer times and result in an internal error.
Default Value	Not stored.

2.6.13 Export Phonebook - PS

This screen allows you to save the phonebook data stored in the S-PS as a TSV file on a PC. For details, see [6.1.1 Import/Export Operation](#).

2.7 Maintenance

Click a numbered tab to view this screen for a particular S-PS.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Telephone

- Call Control
- Button Settings
- Tone Settings
- Telephone Settings
- Import Phonebook
- Export Phonebook**

Export Phonebook

Click [Export] button to export the phonebook from this unit.

PS Name	Phone Number	Select Button
001	1100,	Export Phonebook
		Export Phonebook
		Export Phonebook

2.6.13.1 Export Phonebook

PS Name

Description	Indicates the currently assigned name of the S-PS (reference only).
Value Range	Max. 20 characters
Default Value	Not applicable.

Phone Number

Description	Indicates the currently assigned phone numbers (reference only).
Value Range	Max. 32 digits
Default Value	Not applicable.

2.7 Maintenance

This section provides detailed descriptions about all the settings classified under the **[Maintenance]** tab.

2.7.1 Backup

This screen allows you to backup the Super Master CS configuration data for the recovery of the Super Master CS. For details, see **8.1 How to back up and restore configuration data**.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Maintenance

- Backup** (highlighted)
- Restore
- Firmware Maintenance
- All Firmware Update
- Provisioning Maintenance
- Error Log
- Restart

Backup

Export CS Backup File

Click [Backup] button to export the CS Backup File from this unit.

Backup

2.7.2 Restore

This screen allows you to restore Super Master CS configurations for the recovery of the Super Master CS. For details, see **8.1 How to back up and restore configuration data**.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Maintenance

- Backup
- Restore** (highlighted)
- Firmware Maintenance
- All Firmware Update
- Provisioning Maintenance
- Error Log
- Restart

Restore

Import CS Backup File

File Name Browse...

Restore

2.7.3 Firmware Maintenance

2.7.3 Firmware Maintenance

This screen allows you to perform firmware updates automatically or manually.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close


Maintenance

Backup
Restore
Firmware Maintenance
All Firmware Update
Provisioning Maintenance
Error Log
Restart

Firmware Maintenance

Enable Firmware Update Yes No
Firmware File URL
PS Update Type Automatic Manual

All Save Cancel



2.7.3.1 Firmware Maintenance

Enable Firmware Update

Description	Selects whether to perform firmware updates when the SIP-CS detects a newer version of firmware.
Note	<ul style="list-style-type: none">• Changing this setting may require restarting the SIP-CS.• Local firmware updates from the Web user interface (→ see 2.7.4 All Firmware Update) can be performed regardless of this setting.• Firmware updates using TR-069 can be performed regardless of this setting.
Value Range	<ul style="list-style-type: none">• Yes• No
Default Value	Yes

Firmware File URL

Description	Specifies the URL where the firmware file is stored.
Note	<ul style="list-style-type: none">• This setting is available only when [Enable Firmware Update] is set to [Yes].• Changing this setting may require restarting the SIP-CS.
Value Range	Max. 500 characters

Default Value	Not stored.
----------------------	-------------

PS Update Type

Description	Selects whether to display a confirmation message asking the user to perform a firmware update (manual) or perform the firmware update without asking the user (automatic) when the S-PS detects a newer version of firmware.
Note	<ul style="list-style-type: none"> This setting is available only when [Enable Firmware Update] is set to [Yes]. Changing this setting may require restarting the SIP-CS.
Value Range	<ul style="list-style-type: none"> Automatic Manual
Default Value	Automatic

2.7.4 All Firmware Update

This screen allows you to manually update the firmware of all SIP-CSs from a PC by clicking [**All Update Firmware**].

Note

- After the firmware has been successfully updated, the SIP-CS will restart automatically.

Panasonic

The screenshot shows the Panasonic SIP CS KX-UDS124 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone, and Maintenance. The Maintenance menu on the left is expanded, showing options like Backup, Restore, Firmware Maintenance, and All Firmware Update (which is highlighted with a red box). The main content area is titled "All Firmware Update". It contains three main sections: "Update Mode" (Mode: Direct), "Update Time Setting" (Date: 1 / 31 / 2012, Time: 00 : 00), and "Update Firmware" (Encryption: Yes). At the bottom is a large blue button labeled "All Update Firmware".

2.7.4 All Firmware Update

2.7.4.1 Update Mode

Mode

Description	Selects the mode for firmware update.
Value Range	<ul style="list-style-type: none">Direct (The update starts immediately.)Appoint Date/Time (The update starts at the set time.)
Default Value	Direct

2.7.4.2 Update Time Setting

Date

Description	Specifies the month (1–2 digits), date (1–2 digits), and year (4 digits) of the update.
Value Range	Month: 1–12, Date: 1–31, Year: 2000–2099
Default Value	1/31/2012

Time

Description	Specifies the hour (1–2 digits) and minute (1–2 digits) of the update.
Value Range	00:00–23:59
Default Value	00:00

2.7.4.3 Update Firmware

Encryption

Description	Selects whether the firmware files are encrypted or not.
Note	<ul style="list-style-type: none">When the provided firmware files are encrypted, select [Yes]. Usually, the provided firmware files are encrypted.
Value Range	<ul style="list-style-type: none">YesNo
Default Value	Yes

File Name

Description	Specifies the path of the firmware file to be imported.
-------------	---

Value Range	No limitation
Note	<ul style="list-style-type: none"> There are no limitations for the field entry. However, it is recommended that paths of less than 254 characters be used: longer paths may cause longer data transfer times and result in an internal error.
Default Value	Not stored.

2.7.5 Provisioning Maintenance

This screen allows you to change the provisioning setup to download the configuration files from the provisioning server of your phone system.

Note

- Each SIP-CS can accept up to 3 configuration files. For details about provisioning, see [3.2 Provisioning](#).

Panasonic

SIP CS KX-UDS124 Status | Network | System | VoIP | Telephone | **Maintenance**

Web Logout	Provisioning Maintenance																					
Web Port Close																						
Maintenance	<table border="1"> <thead> <tr> <th colspan="2">Provisioning Maintenance</th> </tr> </thead> <tbody> <tr> <td>Enable Provisioning</td> <td><input checked="" type="radio"/> Yes <input type="radio"/> No</td> </tr> <tr> <td>Standard File URL</td> <td>http://192.168.0.23:7580/utdownload/Standard.</td> </tr> <tr> <td>Product File URL</td> <td></td> </tr> <tr> <td>Master File URL</td> <td></td> </tr> <tr> <td>System File URL</td> <td>http://192.168.0.23:7580/utdownload/System.c</td> </tr> <tr> <td>Cyclic Auto Resync</td> <td><input type="radio"/> Yes <input checked="" type="radio"/> No</td> </tr> <tr> <td>Resync Interval</td> <td>10080 minute(s) [1-40320]</td> </tr> <tr> <td>Header Value for Resync Event</td> <td>check-sync</td> </tr> <tr> <td colspan="2"> <input type="button" value="All Save"/> <input type="button" value="Cancel"/> </td> </tr> </tbody> </table>		Provisioning Maintenance		Enable Provisioning	<input checked="" type="radio"/> Yes <input type="radio"/> No	Standard File URL	http://192.168.0.23:7580/utdownload/Standard.	Product File URL		Master File URL		System File URL	http://192.168.0.23:7580/utdownload/System.c	Cyclic Auto Resync	<input type="radio"/> Yes <input checked="" type="radio"/> No	Resync Interval	10080 minute(s) [1-40320]	Header Value for Resync Event	check-sync	<input type="button" value="All Save"/> <input type="button" value="Cancel"/>	
Provisioning Maintenance																						
Enable Provisioning	<input checked="" type="radio"/> Yes <input type="radio"/> No																					
Standard File URL	http://192.168.0.23:7580/utdownload/Standard.																					
Product File URL																						
Master File URL																						
System File URL	http://192.168.0.23:7580/utdownload/System.c																					
Cyclic Auto Resync	<input type="radio"/> Yes <input checked="" type="radio"/> No																					
Resync Interval	10080 minute(s) [1-40320]																					
Header Value for Resync Event	check-sync																					
<input type="button" value="All Save"/> <input type="button" value="Cancel"/>																						
Backup																						
Restore																						
Firmware Maintenance																						
All Firmware Update																						
Provisioning Maintenance																						
Error Log																						
Restart																						

2.7.5.1 Provisioning Maintenance

Enable Provisioning

Description	Selects whether the SIP-CS is automatically configured by downloading the configuration files from the provisioning server of your phone system.
Note	<ul style="list-style-type: none"> • Downloading configuration files using TR-069 can be performed regardless of this setting.
Value Range	<ul style="list-style-type: none"> • Yes • No
Default Value	Yes

Standard File URL

Description	Specifies the URL of the standard configuration file, which is used when every SIP-CS needs different settings.
Note	<ul style="list-style-type: none"> • When you change this setting, set [Enable Provisioning] to [Yes] at the same time.
Value Range	Max. 500 characters
Default Value	http://provisioning.e-connecting.net/redirect/conf/{mac}.cfg

Product File URL

Description	Specifies the URL of the product configuration file, which is used when all SIP-CSs with the same model number need the same settings.
Note	<ul style="list-style-type: none"> • When you change this setting, set [Enable Provisioning] to [Yes] at the same time.
Value Range	Max. 500 characters
Default Value	Not stored.

Master File URL

Description	Specifies the URL of the master configuration file, which is used when all SIP-CSs need the same settings.
Note	<ul style="list-style-type: none"> • When you change this setting, set [Enable Provisioning] to [Yes] at the same time.

Value Range	Max. 500 characters
Default Value	Not stored.

System File URL

Description	Specifies the URL of the system configuration file, which is used when all SIP-CSs in the system need the same settings.
Note	<ul style="list-style-type: none"> When you change this setting, set [Enable Provisioning] to [Yes] at the same time.
Value Range	Max. 500 characters
Default Value	Not stored.

Cyclic Auto Resync

Description	Selects whether the SIP-CS periodically checks for updates of configuration files.
Value Range	<ul style="list-style-type: none"> Yes No
Default Value	No

Resync Interval

Description	Specifies the interval, in minutes, between periodic checks for updates of the configuration files.
Value Range	1–40320
Default Value	10080

Header Value for Resync Event

Description	Specifies the value of the "Event" header sent from the SIP server to the SIP-CS so that the SIP-CS can access the configuration files on the provisioning server.
Value Range	Max. 15 characters
Default Value	check-sync

2.7.7 Restart

2.7.6 Error Log

This screen allows you to export the error log from the SIP-CS by clicking [**Export**].

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Maintenance


- Backup
- Restore
- Firmware Maintenance
- All Firmware Update
- Provisioning Maintenance
- Error Log**
- Restart**

Export Error Log

Export Error Log

Click [Export] button to export the Error Log from this unit.

Export



2.7.7 Restart

This screen allows you to restart the SIP-CS by clicking [**Restart**]. After you click this button, a dialog box is displayed, asking whether you want to restart the SIP-CS. Click [**OK**] to perform a restart, or [**Cancel**].

Notice

- The SIP-CS will restart even if it is on a call.

Panasonic

SIP CS KX-UDS124 Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

Maintenance


- Backup
- Restore
- Firmware Maintenance
- All Firmware Update
- Provisioning Maintenance
- Error Log
- Restart**

Restart

Restart

Click [Restart] to restart this unit. Restarting will take a few moments.

Restart



Section 3

General Information on Provisioning


This section provides an overview of the configuration file programming procedures for the SIP-CS, including pre-provisioning and provisioning.

3.1 Pre-provisioning

3.1.1 What is Pre-provisioning?

To perform pre-provisioning, you must set the IP address of a TFTP server to the DHCP server option 66 so that the SIP-CS can acquire the TFTP server address. When the SIP-CS starts up and no configuration has been applied, it will automatically acquire the address of the TFTP server and download the configuration file. For details about the configuration file, see [3.2.3 Configuration File](#).

For details about the settings that can be configured with the configuration files and how to specify the settings, see [Section 4 Configuration File Programming](#).



Pre-provisioning can aid the installation process by allowing dealers to configure beforehand the minimum settings required to operate the SIP-CS.

For example, dealers can store on the TFTP server a configuration file that contains only the URL of a server where another configuration file is stored. This second configuration file contains settings configured specifically for the usage environment of the user. The user will be able to start using the SIP-CS by just connecting it to the network.

Pre-provisioning is performed only once after the SIP-CS has been shipped. Once configuration by pre-provisioning or provisioning has been applied, pre-provisioning will not be performed again.

Note that the settings configured by pre-provisioning cannot be restored once it has been performed. If you want to restore them, consult your dealer.

Although pre-provisioning is often used to specify the location of the configuration files for provisioning, you can configure any of the settings through pre-provisioning. The SIP-CS can be made fully operational by configuring settings through pre-provisioning.

3.1.2 Pre-provisioning when Setting Static IP Addresses

To perform pre-provisioning, the SIP-CS needs to acquire the TFTP server address from option 66 on a DHCP server. Therefore, pre-provisioning cannot be performed if you use static IP addressing on your network. If you

use static IP addressing and want to perform pre-provisioning, construct a small, separate network and connect a DHCP and TFTP server to that network.

In addition, if option 66 of the DHCP server cannot be set, or if you are unauthorized to change this setting, perform pre-provisioning on the separate network, and then connect the SIP-CS to the actual network.

3.1.3 Server for Pre-provisioning

The DHCP server and TFTP server play important roles in performing pre-provisioning. This section explains their purposes, uses, and brief descriptions.

Server	Purpose	Description
DHCP server	Used to provide the address of a TFTP server, set in option 66 of the DHCP server, to SIP-CSs that have not been configured yet.	<p>In option 66 of the DHCP server, specify the IP address or FQDN (Fully Qualified Domain Name) of the TFTP server. For details, refer to the documentation for your DHCP server.</p> <p>Note</p> <ul style="list-style-type: none"> The maximum length of FQDN text is 255 bytes.
TFTP server	Used to store configuration files, and is set as the access point for downloading them automatically.	<p>The SIP-CS will download the configuration file "(model name).cfg" stored in the root directory of the TFTP server. For example, if the model name is KX-UDS124, the SIP-CS will download the configuration file "/KX-UDS124.cfg".</p>

DHCP and TFTP servers may be supplied with your operating system, provided through commercial services, and are also distributed freely on the Internet. Use a server setup that best matches your environment.

When installing and setting up the DHCP server and TFTP server, refer to the documentation supplied with the product. For details about connecting servers to the network and managing them, consult your network administrator.

3.1.4 Pre-provisioning Setting Example

This section gives an example of how to perform pre-provisioning.

Assumptions

Item	Description/Setting
TFTP server address	192.168.0.130
Distribution directory of TFTP server	/tftpboot
Model name of the SIP-CS	KX-UDS124
MAC address of the SIP-CS	0080F0123456
Provisioning server name (where the configuration file used for provisioning is to be stored)	provisioning.example.com
Distribution directory of the provisioning server	/Panasonic

3.1.4 Pre-provisioning Setting Example

Item	Description/Setting
File name of the configuration file used for provisioning	Config0080F0123456.cfg
URL of the configuration file used for provisioning	http://provisioning.example.com/Panasonic/Config0080F0123456.cfg


Prior Settings

Item	Description/Setting
DHCP server option 66	192.168.0.130
IP address range assigned by DHCP server	192.168.0.16 to 192.168.0.63
File name of the configuration file used for pre-provisioning	KX-UDS124.cfg
URL of the configuration file used for provisioning that is entered in the configuration file	<code>CFG_STANDARD_FILE_PATH="http://provisioning.example.com/Panasonic/Config{MAC}.cfg"</code> Note <ul style="list-style-type: none">"{MAC}" is replaced by the MAC address of the SIP-CS. (e.g., "0080F0123456")
Stored location of the configuration file on the TFTP server	Configuration file "KX-UDS124.cfg" is stored in the directory "/tftpboot".

The pre-provisioning process


Step 1

Connect the SIP-CS to the network, and turn the power on. The SIP-CS is assigned an IP address by the DHCP server, and also receives the TFTP server address from the DHCP server using DHCP server option 66.




Step 2

The SIP-CS downloads the configuration file for pre-provisioning from the TFTP server:
`tftp://192.168.0.130/KX-UDS124.cfg`




Step 3

The URL of the server where the configuration file for provisioning is stored (provisioning server) is set to the SIP-CS:
`http://provisioning.example.com/Panasonic/Config{MAC}.cfg`



Step 4


When pre-provisioning is complete, the SIP-CS's LED will flash red, amber and green alternately.



Step 5

When the LED is flashing alternately, turn off the SIP-CS's power, then turn it back on.
The SIP-CS may restart automatically depending on the configuration file programming (→ see "**"OPTION66_REBOOT"** in **4.2.5 Provisioning Settings**).

When the SIP-CS is distributed to end users and started up in real circumstances, provisioning will be performed correctly.




Note

- This example describes the case when only one SIP-CS is connected. However, multiple SIP-CSs can be configured through the same procedure without changing any settings, because the MAC address is specified by the {MAC} macro.

3.2 Provisioning

3.2.1 What is Provisioning?

After pre-provisioning has been performed (→ see **3.1 Pre-provisioning**), you can set up the SIP-CS automatically by downloading the configuration file stored on the provisioning server into the SIP-CS. This is called "provisioning".



3.2.2 Protocols for Provisioning

Provisioning can be performed over HTTP, HTTPS, FTP, and TFTP. The protocol you should use differs depending on how you will perform provisioning. Normally, HTTP, HTTPS, or FTP is used for provisioning. If you are transmitting encrypted configuration files, it is recommended that you use HTTPS. If you are transmitting unencrypted configuration files, it is recommended that you use HTTP. You may not be able to use FTP depending on the conditions of the network router or the network to be used.

3.2.3 Configuration File

This section gives concrete examples of the functions of the configuration file and how to manage it. The configuration file is a text file that contains the various settings that are necessary for operating the SIP-CS. The files are normally stored on a server maintained by your dealer, and will be downloaded to the SIP-CSs as required. All configurable settings can be specified in the configuration file. You can ignore settings that already have the desired values. Only change parameters as necessary.

For details about setting parameters and their descriptions, see **Section 4 Configuration File Programming**.

Using 4 Types of Configuration Files

The SIP-CS can download up to 4 configuration files. One way to take advantage of this is by classifying the configuration files into the following 4 types:

Type	Usage	Common to all SIP-CSs
System configuration file	<p>Configure settings that are common to all SIP-CSs, such as the SIP server address, and the IP addresses of the DNS and NTP (Network Time Protocol) servers managed by your dealer. This configuration file is used by all the SIP-CSs.</p> <p>Example of the configuration file's URL: http://prov.example.com/Panasonic/{MODEL}.cfg</p> <p>Note</p> <ul style="list-style-type: none"> When a SIP-CS requests the configuration file, "{MODEL}" is replaced by the model name of the SIP-CS. 	Yes
Master configuration file	<p>Configure settings that are common to all SIP-CSs, such as the SIP User ID, password, and IPEI. This configuration file is used by all the SIP-CSs.</p> <p>Example of the configuration file's URL: http://prov.example.com/Panasonic/UserAccount.cfg</p>	Yes
Product configuration file	<p>Configure settings that are unique to each SIP-CS, such as the CS name. If necessary, each CS will download the corresponding configuration file.</p> <p>Example of the configuration file's URL: http://prov.example.com/Panasonic/Config{MAC}.cfg</p> <p>Note</p> <ul style="list-style-type: none"> When a SIP-CS requests the configuration file, "{MAC}" is replaced by the MAC address of the SIP-CS. 	No
Standard configuration file	<p>Configure settings that are unique to each SIP-CS, for future enhancement. If necessary, each CS will download the corresponding configuration file.</p> <p>Example of the configuration file's URL: http://prov.example.com/Panasonic/Config{MAC}.cfg</p> <p>Note</p> <ul style="list-style-type: none"> When a SIP-CS requests the configuration file, "{MAC}" is replaced by the MAC address of the SIP-CS. 	No

Usually, you only need to use the System and Master configuration files. If you need to centralize provisioning to the Super Master CS, set the "**PROVISION_SUPERMASTER_ONLY**" parameter to "Y" (→ see **4.2.6 Other Settings**). As a result, these two files are distributed to all other SIP-CSs automatically and other SIP-CSs do

3.2.4 Downloading Configuration Files

not need to perform provisioning. In this case, the Standard and Product configuration files can also only be used by the Super Master CS.

Depending on the situation, you can use all 4 types of configuration files, and can also use only a Master configuration file.

The above example shows only one possible way to use configuration files. Depending on the requirements of your dealer, there are a number of ways to use configuration files effectively.

3.2.4 Downloading Configuration Files

Downloading a Configuration File via the Web User Interface


The following procedure describes how to enable downloading a configuration file via the Web User Interface to be used for programming the SIP-CS.

1. Confirm that the provisioning server's IP address/FQDN and directory are correct, and store the configuration files in the directory (e.g., http://provisioning.example.com/Panasonic/Config_Sample.cfg).
2. Enter the IP address of the SIP-CS into the PC's Web browser.
3. Log in as the administrator.
4. Click the **[Maintenance]** tab, click **[Provisioning Maintenance]**, and then select **[Yes]** for **[Enable Provisioning]**.
5. Enter the URL set up in Step 1 in **[Standard File URL]**.
6. Click **[Save]**.


Timing of Downloading

A SIP-CS downloads configuration files when it starts up, at regular intervals, and when directed to do so by the server. In addition, you can prohibit SIP-CSs from downloading the configuration files. For details about the settings, see **2.7.5 Provisioning Maintenance** and **4.2.5 Provisioning Settings**.

Download Timing	Explanation
Startup	The configuration files are downloaded when the SIP-CS starts up.

Download Timing	Explanation
<p>At regular intervals of time</p>	<p>The configuration files are downloaded at specified intervals of time, set in minutes. In the example below, the SIP-CS has been programmed to check for and download configuration files from the provisioning server every 3 days (4320 minutes).</p>  <p>The configuration files are downloaded periodically under the following conditions:</p> <ul style="list-style-type: none"> • In the configuration file, add the line, <code>CFG_CYCLIC="Y"</code>. <ul style="list-style-type: none"> – Set an interval (minutes) by specifying "<code>CFG_CYCLIC_INTVL</code>". • In the Web user interface: <ul style="list-style-type: none"> – Click the [Maintenance] tab, click [Provisioning Maintenance], and then select [Yes] for [Cyclic Auto Resync]. – Enter an interval (minutes) in [Resync Interval]. <p>Note</p> <ul style="list-style-type: none"> • The interval may be determined by your dealer. A maximum interval of 28 days (40320 minutes) can be set on the SIP-CS.

3.2.4 Downloading Configuration Files

Download Timing	Explanation
At a specified time each day	<p>After the SIP-CS is powered on, it will check for and download configuration files once per day at the specified time.</p>  <p>The configuration files are downloaded at a set time each day:</p> <ul style="list-style-type: none"> Set a time by specifying "<u>CFG_RESYNC_TIME</u>". <p>Note</p> <ul style="list-style-type: none"> If the value for "<u>CFG_RESYNC_TIME</u>" is any valid value other than an empty string, the SIP-CS downloads the configuration files at the fixed time, and the settings specified in "<u>CFG_CYCLIC</u>", "<u>CFG_CYCLIC_INTVL</u>", and "<u>CFG_RTRY_INTVL</u>" are disabled. The time is specified using a 24-hour clock ("00:00" to "23:59").
When directed	<p>When a setting needs to be changed immediately, SIP-CSs can be directed to download the configuration files by sending them a NOTIFY message that includes a special event from the SIP server.</p> <ul style="list-style-type: none"> In the configuration file: <ul style="list-style-type: none"> Specify the special event text in "<u>CFG_RESYNC_FROM_SIP</u>". In the Web user interface: <ul style="list-style-type: none"> Click the [Maintenance] tab, click [Provisioning Maintenance], and then enter the special event text in [Header Value for Resync Event]. <p>Generally, "check-sync" or "resync" is set as the special event text.</p>

Download Timing	Explanation
None (prohibited)	<p>If you want to prohibit SIP-CSs from changing their settings by downloading configuration files, you can enable this function from the Web user interface. The following operations will be prohibited:</p> <ul style="list-style-type: none"> – Pre-provisioning – Provisioning at startup – Provisioning at regular intervals – Provisioning by sending a NOTIFY message • In the configuration file: <ul style="list-style-type: none"> – Add the line, <code>PROVISION_ENABLE="N"</code>. • In the Web user interface: <ul style="list-style-type: none"> – Click the [Maintenance] tab, click [Provisioning Maintenance], and then select [No] for [Enable Provisioning]. • To enable provisioning again, in the Web user interface: <ul style="list-style-type: none"> – Click the [Maintenance] tab, click [Provisioning Maintenance], and then select [Yes] for [Enable Provisioning].

3.2.5 Provisioning Server Setting Example

This section gives an example of how to set up the SIP-CSs and provisioning server when configuring 2 SIP-CSs with configuration files. The System and Master configuration files are used in this example.

Conditions

Item	Description/Setting
Provisioning server FQDN	prov.example.com
SIP-CS's MAC address	0080F0111111
URL of the configuration files	<p>Configure the following 2 settings either by pre-provisioning or through the Web user interface. The values of both settings must be the same.</p> <ul style="list-style-type: none"> • <code>CFG_SYSTEM_FILE_PATH="http://prov.example.com/Panasonic/KX-UDS124.cfg"</code> • <code>CFG_MASTER_FILE_PATH="http://prov.example.com/Panasonic/UserAccount.cfg"</code>
Directory on the provisioning server containing the configuration files	Create the "Panasonic" directory just under the HTTP root directory of the provisioning server.
File name of configuration files	<p>Store the following configuration files in the "Panasonic" directory.</p> <ul style="list-style-type: none"> • Contains the common settings for all SIP-CSs: <ul style="list-style-type: none"> – UserAccount.cfg • Contains the settings for all SIP-CSs of the same model: <ul style="list-style-type: none"> – KX-UDS124.cfg

To set up the provisioning server

1. Connect the SIP-CSs to the network, and turn them on.
2. The SIP-CS with the MAC address 0080F0111111 accesses the following URLs:
<http://prov.example.com/Panasonic/UserAccount.cfg>
<http://prov.example.com/Panasonic/KX-UDS124.cfg>

3.2.6 Encryption

Example Provisioning Direction from the Server

The following figure shows an example NOTIFY message from the server, directing the SIP-CSs to perform provisioning. The text "check-sync" is specified for "CFG_RESYNC_FROM_SIP".

```
NOTIFY sip:1234567890@sip.example.com SIP/2.0
Via: SIP/2.0/UDP xxx.xxx.xxx.xxx:5060;branch=abcdef-ghijkl
From: sip:prov@sip.example.com
To: sip:1234567890@sip.example.com
Date: Thu, 1 Jan 2009 01:01:01 GMT
Call-ID: 123456-1234567912345678
CSeq: 1 NOTIFY
Contact: sip:xxx.xxx.xxx.xxx:5060
Event: check-sync
Content-Length: 0
```


3.2.6 Encryption

Secure Provisioning Methods

In order to perform provisioning securely, there are 2 methods for transferring configuration files securely between the SIP-CS and the server.

Which method is used depends on the environment and equipment available from the phone system.

Method 1: Transferring Encrypted Configuration Files



To use this method, an encryption key is required to encrypt and decrypt the configuration files. A preset encryption key unique to each SIP-CS, an encryption key set by your dealer, etc., is used for the encryption. When the SIP-CS downloads an encrypted configuration file, it will decrypt the file using the same encryption key, and then configure the settings automatically.

Method 2: Transferring Configuration Files Using HTTPS

This method uses SSL, which is commonly used on the Internet, to transfer configuration files between the SIP-CS and server. For more secure communication, you can use a root certificate.

Notice

- To avoid redundant data transfer over the network, important data, such as the encryption key used to encrypt the configuration files and the root certificate for SSL, should be configured through pre-provisioning as much as possible.
- It is recommended that you encrypt the data in order to keep the communication secure when transferring configuration files.
However, if you are using the SIP-CSs within a secure environment, such as within an intranet, it is not necessary to encrypt the data.

To decrypt configuration files, the SIP-CS uses the encryption key registered to it beforehand. The SIP-CS determines the encryption status by checking the extension of the downloaded configuration file.

For details about encrypting configuration files, contact the appropriate person in your organization.

Extension of Configuration File	Configuration File Parameters Used for Decrypting
".e1c"	<code>CFG_FILE_KEY1</code>
".e2c"	<code>CFG_FILE_KEY2</code>
".e3c"	<code>CFG_FILE_KEY3</code>
".e4c"	<code>CFG_FILE_KEY4</code>
Other than ".e1c", ".e2c", ".e3c", and ".e4c"	Processed as unencrypted configuration files. The extension ".cfg" should be used for unencrypted configuration files.

Comparison of the 2 Methods

The following table compares the characteristics for the 2 transfer methods.

	Transferring Encrypted Configuration Files	Transferring Configuration Files Using HTTPS
Provisioning server load	Light	Heavy (The server encrypts data for each transmission.)
Operation load	Necessary to encrypt data beforehand.	Unnecessary to encrypt data beforehand.
Management of configuration files	Files must be decrypted and re-encrypted for maintenance.	It is easy to manage files because they are not encrypted on the server.
Security of data on the server when operating	High	Low (Configuration files are readable by anyone with access to the server.)

Moreover, there is another method: configuration files are not encrypted while stored on the server, and then, using the encryption key registered to the SIP-CS beforehand, they are encrypted when they are transferred. This method is particularly useful when several SIP-CSs are configured to download a common configuration file using different encryption keys. However, as when downloading an unencrypted configuration file using HTTPS, the server will be heavily burdened when transferring configuration files.

3.3 Priority of Setting Methods

The same settings can be configured by different configuration methods: provisioning, Web user interface programming, etc. This section explains which value is applied when the same setting is specified by multiple methods.

The following table shows the priority with which settings from each method are applied (lower numbers indicate higher priority):

Setting Order	Priority	Setting Method
1	4	The factory default settings for the SIP-CS
2	3	Pre-provisioning with the configuration file

3.4 Configuration File Specifications

Setting Order	Priority	Setting Method
3	2-4	Provisioning with the system configuration file
	2-3	Provisioning with the master configuration file
	2-2	Provisioning with the product configuration file
	2-1	Provisioning with the standard configuration file
4	1	Settings configured from the Web user interface

According to the table, settings configured later override previous settings (i.e., settings listed lower in the table have a higher priority).

If different values are specified for the same setting by the master configuration file and Web user interface programming, the value specified from the Web user interface is applied. This is because values specified from the Web user interface have a higher priority.

For settings configured from the Web user interface, the value specified most recently receives priority.

3.4 Configuration File Specifications

The specifications of the configuration files are as follows:

File Format

The configuration file is in plain text format.

File Size

The maximum size of a configuration file is 2040 KB. Regardless of the number of configuration files, the total size of the configuration files must be 2040 KB or less.

Lines in Configuration Files

A configuration file consists of a sequence of lines, with the following conditions:

- Each line must end with "<CR><LF>".
- The maximum length of a line is 537 bytes including "<CR><LF>".
- The following lines are ignored:
 - Lines that exceed the limit of 537 bytes
 - Empty lines
 - Comment lines that start with "#"
- Configuration files must start with a comment line containing the following designated character sequence (44 bytes):

```
# Panasonic SIP Phone Standard Format File #
```

The hexadecimal notation of this sequence is:

```
23 20 50 61 6E 61 73 6F 6E 69 63 20 53 49 50 20  
50 68 6F 6E 65 20 53 74 61 6E 64 61 72 64 20 46  
6F 72 6D 61 74 20 46 69 6C 65 20 23
```

- To prevent the designated character sequence being altered by chance, it is recommended that the configuration file starts with the comment line shown below:

```
# Panasonic SIP Phone Standard Format File # DO NOT CHANGE THIS LINE!
```
- Configuration files must end with an empty line.
- Each parameter line is written in the form of XXX="yyy" (XXX: parameter name, yyy: parameter value). The value must be enclosed by double quotation marks.
- A parameter line written over multiple lines is not allowed. It will cause an error on the configuration file, resulting in invalid provisioning.

Configuration Parameters

- The maximum length of a parameter name is 32 characters.
 - The maximum length of a parameter value is 500 characters excluding double quotation marks.
 - No space characters are allowed in the line except when the value includes a space character(s).
- Example:
- ```
DISPLAY_NAME_PS1_1="John Smith" (valid)
DISPLAY_NAME_PS1_1 = "John Smith" (invalid)
```
- Some parameter values can be specified as "empty" to set the parameter values to empty.
- Example:
- ```
NTP_ADDR=""
```
- The parameters have no order.
 - If the same parameter is specified in a configuration file more than once, the value specified first is applied.
 - All configurable settings can be specified in the configuration file. You can ignore settings that already have the desired values. Only change parameters as necessary.

3.5 Configuration File Examples

The following examples of configuration files are provided on the Panasonic Web site (→ see **Introduction**).

- Simplified Example of the Configuration File
- Comprehensive Example of the Configuration File

3.5.1 Examples of Codec Settings

Setting the Codec Priority to (1)G.729A, (2)G.726-32, (3)PCMU, (4)G.722

```
## Codec Settings
# Enable G722
CODEC_ENABLE0_1="Y"
CODEC_PRIORITY0_1="4"
# Disable PCMA
CODEC_ENABLE1_1="N"
# Enable G726-32K
CODEC_ENABLE2_1="Y"
CODEC_PRIORITY2_1="2"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Enable PCMU
CODEC_ENABLE4_1="Y"
CODEC_PRIORITY4_1="3"
```

Setting Narrow-band Codecs (PCMA, G.726-32 and G.729A)

```
## Codec Settings
# Disable G722
CODEC_ENABLE0_1="N"
# Enable PCMA
CODEC_ENABLE1_1="Y"
CODEC_PRIORITY1_1="1"
```

3.5.2 Example with Incorrect Descriptions

```
# Enable G726-32K
CODEC_ENABLE2_1="Y"
CODEC_PRIORITY2_1="1"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Disable PCMU
CODEC_ENABLE4_1="N"
```

Setting the G.729A Codec Only

```
## Codec Settings
# Disable G722
CODEC_ENABLE0_1="N"
# Disable PCMA
CODEC_ENABLE1_1="N"
# Disable G726-32K
CODEC_ENABLE2_1="N"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Disable PCMU
CODEC_ENABLE4_1="N"
# Do not set PCMU
CODEC_G711_REQ="0"
```

3.5.2 Example with Incorrect Descriptions

The following listing shows an example of a configuration file that contains incorrect formatting:

- ① An improper description is entered in the first line. A configuration file must start with the designated character sequence "# Panasonic SIP Phone Standard Format File #".
- ② Comment lines start in the middle of the lines.
- ③ Space characters are inserted in the middle of the setting line.
- ④ A specified value is not in the range allowed for that setting.

Incorrect Example

```
# This is a simplified sample configuration file. —①
#####
# Configuration Setting #
#####
```

```

CFG_STANDARD_FILE_PATH="http://config.example.com/0123456789AB.cfg"
    # URL of this configuration file

#####
# SIP Settings #
# Suffix "_1" indicates this parameter is for "line 1". #
#####

SIP_RGSTR_ADDR_1="registrar.example.com" # IP Address or FQDN of SIP registrar server → ②
SIP_PRXY_ADDR_1="proxy.example.com"      # IP Address or FQDN of proxy server

# Enables DNS SRV lookup
SIP_DNSSRV_ENA_1="Y"

# ID, password for SIP authentication
SIP_AUTHID_1="SIP_User"                   → ③
SIP_PASS_1="SIP_Password"

# Some Timer Settings #
# Expiration time of SIP registration; "1 hour"
REG_EXPIRE_TIME_1="3600"
# Disables SIP Session Timer (RFC 4028)
SIP_SESSION_TIME_1="0"

# DTMF will be sent through SDP, according to RFC 2833
OUTBANDDTMF_1="Y"

#####
# Call Control Settings #
#####

# Enables subscription to the Voice Mail server
VM_SUBSCRIBE_ENABLE="Y"                  → ④
# Shared Call Settings
SHARED_CALL_ENABLE_1="Y"

# Disables Do Not Disturb, Call Forward synchronization.
FWD_DND_SYNCHRO_ENABLE_1="N"

```

3.5.2 Example with Incorrect Descriptions

Section 4

Configuration File Programming

This section provides information about the configuration parameters used in the configuration files.

4.1 General Information on the Configuration Files

4.1.1 Configuration File Parameters

The information on each parameter that can be written in a configuration file is shown in the tables in this section. The information includes parameter name (as the title of the table), value format, description, permitted value range, and the default value of each parameter. For details about corresponding Web user interface settings, see [2.1.3 Web User Interface Setting List](#).

Parameter Name

This is the system-predefined parameter name and cannot be changed.

Note

- Certain parameter names end with suffixes indicating their type, as shown in the table below:

Type of Setting	Parameter Name
System setting	"..." or "...x"
SIP-CS setting	"..._CS" or "...x_CS"
S-PS setting	"..._PSy" or "...x_PSy"
S-PS setting per line	"..._PSy_n"

- "x" refers a number within the setting, for example, a button number.
- "y" refers to the S-PS number (1–255).
- "n" refers to the line number (S-PS: 1–2).

Value Format

Each parameter value is categorized into Integer, Boolean, or String. Some parameters require a composite form such as "Comma-separated Integer" or "Comma-separated String".

- Integer:** a numerical value, described as a sequence of numerical characters, optionally preceded by a "-" (minus)
An empty string is not allowed.
- Boolean:** "Y" or "N" ("Yes" or "No" also are allowed.)
- String:** sequence of alphanumerical characters
For details about available characters, see [4.1.2 Characters Available for String Values](#).
- Comma-separated Integer:** a list of integers, separated by commas
No space characters are allowed.
- Comma-separated String:** a list of strings, separated by commas
No space characters are allowed.

Description

Describes the details of the parameter.

Value Range

Indicates the permitted value range of the parameter.

Default Value

Indicates the factory default value of the parameter.

Actual default values may vary depending on your dealer.

4.1.2 Characters Available for String Values

Unless noted otherwise in "Value Range", only ASCII characters can be used for parameter values. Unicode characters can also be used in some parameter values.

Available ASCII characters are shown on a white background in the following table:

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
20	SP	!	"	#	\$	%	&	'	()	*	+	,	-	.	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	'	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	

4.2 System Settings

4.2.1 Login Account Settings

ADMIN_ID

Value Format	String
Description	Specifies the account ID used to access the Web user interface with the Administrator account.
Value Range	Max. 16 characters (except ", &, :, <, >, and space)
Note	<ul style="list-style-type: none"> An empty string is not allowed.
Default Value	admin

ADMIN_PASS

Value Format	String
Description	Specifies the password to use to authenticate the Administrator account when logging in to the Web user interface.
Value Range	6–16 characters (except ", &, :, <, >, and space)
Default Value	adminpass

4.2.2 System Time Settings

USER_PASS_PSy

Value Format	String
Description	Specifies the password to use to authenticate the User account for Web user interface programming.
Note	<ul style="list-style-type: none">Although this setting is technically possible, you cannot log in to the Web user interface with the User account.
Value Range	6–16 characters (except ", &, :, <, >, and space)
Default Value	Empty string

4.2.2 System Time Settings

TIME_ZONE

Value Format	Integer
Description	Specifies the offset of local standard time from UTC (GMT), in minutes.
Value Range	-720–780
Note	<ul style="list-style-type: none">Only the following values are available: -720 (GMT -12:00), -660 (GMT -11:00), -600 (GMT -10:00), -540 (GMT -09:00), -480 (GMT -08:00), -420 (GMT -07:00), -360 (GMT -06:00), -300 (GMT -05:00), -240 (GMT -04:00), -210 (GMT -03:30), -180 (GMT -03:00), -120 (GMT -02:00), -60 (GMT -01:00), 0 (GMT), 60 (GMT +01:00), 120 (GMT +02:00), 180 (GMT +03:00), 210 (GMT +03:30), 240 (GMT +04:00), 270 (GMT +04:30), 300 (GMT +05:00), 330 (GMT +05:30), 345 (GMT +05:45), 360 (GMT +06:00), 390 (GMT +06:30), 420 (GMT +07:00), 480 (GMT +08:00), 540 (GMT +09:00), 570 (GMT +09:30), 600 (GMT +10:00), 660 (GMT +11:00), 720 (GMT +12:00), 780 (GMT +13:00)If your location is west of Greenwich (0 [GMT]), the value should be minus. For example, the value for New York City, U.S.A. is "-300" (Eastern Standard Time being 5 hours behind GMT).This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Default Value	0

DST_ENABLE

Value Format	Boolean
---------------------	---------

Description	Specifies whether to enable DST (Summer Time).
	<p>Note</p> <ul style="list-style-type: none"> • This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	<ul style="list-style-type: none"> • Y (Enable DST [Summer Time]) • N (Disable DST [Summer Time])
Default Value	N

DST_OFFSET

Value Format	Integer
Description	Specifies the amount of time, in minutes, to change the time when "DST_ENABLE" is set to "Y".
	<p>Note</p> <ul style="list-style-type: none"> • This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	0–720
	<p>Note</p> <ul style="list-style-type: none"> • This parameter is usually set to "60".
Default Value	60

DST_START_MONTH

Value Format	Integer
Description	Specifies the month in which DST (Summer Time) starts.
	<p>Note</p> <ul style="list-style-type: none"> • This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	1–12
Default Value	3

DST_START_ORDINAL_DAY

Value Format	Integer
---------------------	---------

4.2.2 System Time Settings

Description	Specifies the number of the week on which DST (Summer Time) starts. The actual start day is specified in " <code>DST_START_DAY_OF_WEEK</code> ". For example, to specify the second Sunday, specify "2" in this parameter, and "0" in the next parameter.
Note	<ul style="list-style-type: none"> • This parameter is disabled when the "<code>LOCAL_TIME_ZONE_POSIX</code>" parameter is specified.
Value Range	<p>1–5</p> <ul style="list-style-type: none"> – 1: the first week of the month – 2: the second week of the month – 3: the third week of the month – 4: the fourth week of the month – 5: the fifth week of the month
Default Value	2

[`DST_START_DAY_OF_WEEK`](#)

Value Format	Integer
Description	Specifies the day of the week on which DST (Summer Time) starts.
Note	<ul style="list-style-type: none"> • This parameter is disabled when the "<code>LOCAL_TIME_ZONE_POSIX</code>" parameter is specified.
Value Range	<p>0–6</p> <ul style="list-style-type: none"> – 0: Sunday – 1: Monday – 2: Tuesday – 3: Wednesday – 4: Thursday – 5: Friday – 6: Saturday
Default Value	0

[`DST_START_TIME`](#)

Value Format	Integer
Description	Specifies the start time of DST (Summer Time) in minutes after 12:00 AM.
Note	<ul style="list-style-type: none"> • This parameter is disabled when the "<code>LOCAL_TIME_ZONE_POSIX</code>" parameter is specified.
Value Range	0–1439
Default Value	120

DST_STOP_MONTH

Value Format	Integer
Description	Specifies the month in which DST (Summer Time) ends.
	<p>Note</p> <ul style="list-style-type: none"> This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	1–12
Default Value	10

DST_STOP_ORDINAL_DAY

Value Format	Integer
Description	Specifies the number of the week on which DST (Summer Time) ends. The actual end day is specified in "DST_STOP_DAY_OF_WEEK". For example, to specify the second Sunday, specify "2" in this parameter, and "0" in the next parameter.
	<p>Note</p> <ul style="list-style-type: none"> This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	1–5 – 1: the first week of the month – 2: the second week of the month – 3: the third week of the month – 4: the fourth week of the month – 5: the fifth week of the month
Default Value	2

DST_STOP_DAY_OF_WEEK

Value Format	Integer
Description	Specifies the day of the week on which DST (Summer Time) ends.
	<p>Note</p> <ul style="list-style-type: none"> This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.

4.2.2 System Time Settings

Value Range	0–6 – 0: Sunday – 1: Monday – 2: Tuesday – 3: Wednesday – 4: Thursday – 5: Friday – 6: Saturday
Default Value	0

DST_STOP_TIME

Value Format	Integer
Description	Specifies the end time of DST (Summer Time) in minutes after 12:00 AM.
	<p>Note</p> <ul style="list-style-type: none"> This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.
Value Range	0–1439
Default Value	120

LOCAL_TIME_ZONE_POSIX

Value Format	String
Description	Specifies a IEEE 1003.1 (POSIX)-compliant local time zone definition (e.g., "EST+5:00:00EDT+4:00:00,M4.1.0/2:00:00,M10.5.0/2:00:00").
	<p>Note</p> <ul style="list-style-type: none"> If this parameter is specified, the following parameters are disabled, and operation will be based on this parameter. <ul style="list-style-type: none"> – TIME_ZONE – DST_ENABLE – DST_OFFSET – DST_START_MONTH – DST_START_ORDINAL_DAY – DST_START_DAY_OF_WEEK – DST_START_TIME – DST_STOP_MONTH – DST_STOP_ORDINAL_DAY – DST_STOP_DAY_OF_WEEK – DST_STOP_TIME
Value Range	Max. 70 characters
Default Value	Empty string

4.2.3 Syslog Settings

SYSLOG_EVENT_SIP

Value Format	Integer
Description	<p>Specifies which SIP-related syslog events are sent to the syslog server.</p> <p>Note</p> <ul style="list-style-type: none"> • If the level of the event is higher than or equal to the set value, the log is sent to the syslog server.
Value Range	<p>0–6</p> <ul style="list-style-type: none"> – 0: no logs sent – 1: emergency (highest) – 2: alert – 3: critical – 4: error – 5: warning – 6: information (lowest)
Default Value	0

SYSLOG_EVENT_CFG

Value Format	Integer
Description	Specifies the threshold of syslog events regarding configuration.
Value Range	0–6
Default Value	0

SYSLOG_EVENT_VOIP

Value Format	Integer
Description	Specifies the threshold of syslog events regarding VoIP operation.
Value Range	0–6
Default Value	0

SYSLOG_EVENT_TEL

Value Format	Integer
Description	<p>Specifies the threshold of syslog events regarding telephone functions.</p> <p>Note</p> <ul style="list-style-type: none"> • This setting is not applicable for the current version. No logs will be sent to the syslog server, even if values "1–6" are specified.

4.2.4 Firmware Update Settings

Value Range	0–6
Default Value	0

SYSLOG_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the syslog server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SYSLOG_PORT

Value Format	Integer
Description	Specifies the port number of the syslog server.
Value Range	1–65535
Default Value	514

SYSLOG_RTPSMLY_INVL

Value Format	Integer
Description	Specifies the interval, in seconds, to send summarized information of RTP packets to the syslog server.
Value Range	0, 5–65535 (0: No information sent)
Default Value	20

4.2.4 Firmware Update Settings

FIRM_UPGRADE_ENABLE

Value Format	Boolean
Description	Specifies whether to perform firmware updates when the SIP-CS detects a newer version of firmware.
Note	<ul style="list-style-type: none">• Changing this setting may require restarting the SIP-CS.• Local firmware updates from the Web user interface (→ see 2.7.4 All Firmware Update) can be performed regardless of this setting.• Firmware updates using TR-069 can be performed regardless of this setting.

Value Range	<ul style="list-style-type: none"> Y (Enable firmware updates) N (Disable firmware updates)
Default Value	Y

FIRM_VERSION

Value Format	String
Description	<p>Specifies the firmware version of the SIP-CS.</p> <p>Note</p> <ul style="list-style-type: none"> Changing this setting may require restarting the SIP-CS.
Value Range	00.000–15.999
Default Value	Empty string

PS_FIRM_UPGRADE_AUTO

Value Format	Boolean
Description	<p>Specifies whether to perform the S-PS firmware update automatically when the S-PS detects a newer version of firmware or to disable automatic firmware update. If "N" is selected, the "Firmware Update" menu appears in the S-PS's "Setting Handset" → "System Option" menu.</p> <p>Note</p> <ul style="list-style-type: none"> This setting is available only when "FIRM_UPGRADE_ENABLE" is set to "Y". Changing this setting may require restarting the SIP-CS.
Value Range	<ul style="list-style-type: none"> Y (Enable automatic firmware update and hide S-PS firmware update menu) N (Disable automatic firmware update and show S-PS firmware update menu)
Default Value	Y

FIRM_FILE_PATH

Value Format	String
Description	<p>Specifies the URL where the firmware file is stored.</p> <p>Note</p> <ul style="list-style-type: none"> This setting is available only when "FIRM_UPGRADE_ENABLE" is set to "Y". Changing this setting may require restarting the SIP-CS.

4.2.5 Provisioning Settings

Value Range	Max. 500 characters
Note	<ul style="list-style-type: none">• The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩".<ul style="list-style-type: none">– "⟨user⟩" must be less than 128 characters.– "⟨password⟩" must be less than 128 characters.– "⟨user⟩:⟨password⟩@" may be empty.– The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.– ":⟨port⟩" can be omitted if you do not need to specify the port number.• If "{mac}" is included in this URL, it will be replaced with the SIP-CS's MAC address in lower-case.• If "{MAC}" is included in this URL, it will be replaced with the SIP-CS's MAC address in upper-case.• If "{MODEL}" is included in this URL, it will be replaced with the SIP-CS's model name.• If "{fwver}" is included in this URL, it will be replaced with "FIRM_VERSION" depending on the system. Note that this rule differs from other parameters such as "SIP_USER_AGENT".
Default Value	Empty string

4.2.5 Provisioning Settings

OPTION66_ENABLE

Value Format	Boolean
Description	Specifies whether to enable the SIP-CS to look for option 66 to receive the TFTP server address or FQDN from the DHCP server.
Note	<ul style="list-style-type: none">• The SIP-CS will try to download configuration files through the TFTP server, the IP address or FQDN of which is specified in the option number 66 field.
Value Range	<ul style="list-style-type: none">• Y (Enable option 66)• N (Disable option 66)
Default Value	Y

OPTION66_REBOOT

Value Format	Boolean
Description	Specifies whether the SIP-CS restarts automatically after pre-provisioning has completed successfully using DHCP server option 66. For details, see 3.1.4 Pre-provisioning Setting Example .

Value Range	<ul style="list-style-type: none"> • Y (Restart automatically) • N (Do not restart automatically)
Default Value	N

PROVISION_ENABLE

Value Format	Boolean
Description	<p>Specifies whether the SIP-CS is automatically configured by downloading the configuration files from the provisioning server of your phone system.</p> <p>Note</p> <ul style="list-style-type: none"> • Downloading configuration files using TR-069 can be performed regardless of this setting.
Value Range	<ul style="list-style-type: none"> • Y (Enable configuration file download) • N (Disable configuration file download)
Default Value	Y

CFG_STANDARD_FILE_PATH

Value Format	String
Description	<p>Specifies the URL of the standard configuration file, which is used when every SIP-CS needs different settings.</p> <p>Note</p> <ul style="list-style-type: none"> • When you change this setting, set "PROVISION_ENABLE" to "Y" at the same time.

4.2.5 Provisioning Settings

Value Range	Max. 500 characters
	<p>Note</p> <ul style="list-style-type: none"> • The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩" <ul style="list-style-type: none"> – "⟨user⟩" must be less than 128 characters. – "⟨password⟩" must be less than 128 characters. – "⟨user⟩:⟨password⟩@" may be empty. – The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters. – ":⟨port⟩" can be omitted if you do not need to specify the port number. • If "{mac}" is included in this URL, it will be replaced with the SIP-CS's MAC address in lower-case. • If "{MAC}" is included in this URL, it will be replaced with the SIP-CS's MAC address in upper-case. • If "{MODEL}" is included in this URL, it will be replaced with the SIP-CS's model name. • If "{fwver}" is included in this URL, it will be replaced with the SIP-CS's firmware version. • If this URL ends with "/" (slash), "Config{mac}.cfg" is automatically added at the end of the URL. For example, <code>CFG_STANDARD_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_STANDARD_FILE_PATH="http://host/dir/Config{mac}.cfg"</code>.
Default Value	<code>http://provisioning.e-connecting.net/redirect/conf/{mac}.cfg</code>

CFG_PRODUCT_FILE_PATH

Value Format	String
Description	Specifies the URL of the product configuration file, which is used when all SIP-CSs with the same model number need the same settings.

Note

- When you change this setting, set "`PROVISION_ENABLE`" to "Y" at the same time.

Value Range	<p>Max. 500 characters</p> <p>Note</p> <ul style="list-style-type: none"> The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩" <ul style="list-style-type: none"> "⟨user⟩" must be less than 128 characters. "⟨password⟩" must be less than 128 characters. "⟨user⟩:⟨password⟩@" may be empty. The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters. <li">":⟨port⟩" can be omitted if you do not need to specify the port number.</li"> If "{mac}" is included in this URL, it will be replaced with the SIP-CS's MAC address in lower-case. If "{MAC}" is included in this URL, it will be replaced with the SIP-CS's MAC address in upper-case. If "{MODEL}" is included in this URL, it will be replaced with the SIP-CS's model name. If "{fwver}" is included in this URL, it will be replaced with the SIP-CS's firmware version. If this URL ends with "/" (slash), "{MODEL}.cfg" is automatically added at the end of the URL. For example, <code>CFG_PRODUCT_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_PRODUCT_FILE_PATH="http://host/dir/{MODEL}.cfg"</code>.
Default Value	<p>Empty string</p> <p>Note</p> <ul style="list-style-type: none"> The URL specified by your dealer may be preset in the SIP-CS.

CFG_MASTER_FILE_PATH

Value Format	String
Description	<p>Specifies the URL of the master configuration file, which is used when all SIP-CSs need the same settings.</p> <p>Note</p> <ul style="list-style-type: none"> When you change this setting, set "PROVISION_ENABLE" to "Y" at the same time.

4.2.5 Provisioning Settings

Value Range	Max. 500 characters
	<p>Note</p> <ul style="list-style-type: none"> • The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩" <ul style="list-style-type: none"> – "⟨user⟩" must be less than 128 characters. – "⟨password⟩" must be less than 128 characters. – "⟨user⟩:⟨password⟩@" may be empty. – The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters. – ":⟨port⟩" can be omitted if you do not need to specify the port number. • If "{mac}" is included in this URL, it will be replaced with the SIP-CS's MAC address in lower-case. • If "{MAC}" is included in this URL, it will be replaced with the SIP-CS's MAC address in upper-case. • If "{MODEL}" is included in this URL, it will be replaced with the SIP-CS's model name. • If "{fwver}" is included in this URL, it will be replaced with the SIP-CS's firmware version. • If this URL ends with "/" (slash), "sip.cfg" is automatically added at the end of the URL. For example, <code>CFG_MASTER_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_MASTER_FILE_PATH="http://host/dir/sip.cfg"</code>.
Default Value	Empty string
	<p>Note</p> <ul style="list-style-type: none"> • The URL specified by your dealer may be preset in the SIP-CS.

CFG_SYSTEM_FILE_PATH

Value Format	String
Description	Specifies the URL of the system configuration file, which is used when the whole system needs the same settings.
	<p>Note</p> <ul style="list-style-type: none"> • When you change this setting, set "PROVISION_ENABLE" to "Y" at the same time.

Value Range	Max. 500 characters Note <ul style="list-style-type: none">• The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩"<ul style="list-style-type: none">– "⟨user⟩" must be less than 128 characters.– "⟨password⟩" must be less than 128 characters.– "⟨user⟩:⟨password⟩@" may be empty.– The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.– ":⟨port⟩" can be omitted if you do not need to specify the port number.• If "{mac}" is included in this URL, it will be replaced with the SIP-CS's MAC address in lower-case.• If "{MAC}" is included in this URL, it will be replaced with the SIP-CS's MAC address in upper-case.• If "{MODEL}" is included in this URL, it will be replaced with the SIP-CS's model name.• If "{fwver}" is included in this URL, it will be replaced with the SIP-CS's firmware version.• If this URL ends with "/" (slash), "system.cfg" is automatically added at the end of the URL. For example, <code>CFG_SYSTEM_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_SYSTEM_FILE_PATH="http://host/dir/system.cfg"</code>.
Default Value	Empty string Note <ul style="list-style-type: none">• The URL specified by your dealer may be preset in the SIP-CS.

CFG_FILE_KEY1

Value Format	String
Description	Specifies the encryption key (password) used to decrypt configuration files. Note <ul style="list-style-type: none">• If the extension of the configuration file is ".e1c", the configuration file will be decrypted using this key.
Value Range	32-byte characters Note <ul style="list-style-type: none">• If an empty string is set for this parameter, decryption with this value is disabled.
Default Value	A unique value is preset to each SIP-CS and S-PS.

4.2.5 Provisioning Settings

CFG_FILE_KEY2

Value Format	String
Description	Specifies the encryption key (password) used to decrypt configuration files. Note <ul style="list-style-type: none">If the extension of the configuration file is ".e2c", the configuration file will be decrypted using this key.
Value Range	32-byte characters Note <ul style="list-style-type: none">If an empty string is set for this parameter, decryption with this value is disabled.
Default Value	Empty string

CFG_FILE_KEY3

Value Format	String
Description	Specifies the encryption key (password) used to decrypt configuration files. Note <ul style="list-style-type: none">If the extension of the configuration file is ".e3c", the configuration file will be decrypted using this key.
Value Range	32-byte characters Note <ul style="list-style-type: none">If an empty string is set for this parameter, decryption with this value is disabled.
Default Value	Empty string

CFG_FILE_KEY4

Value Format	String
Description	Specifies the encryption key (password) used to decrypt configuration files. Note <ul style="list-style-type: none">If the extension of the configuration file is ".e4c", the configuration file will be decrypted using this key.
Value Range	32-byte characters Note <ul style="list-style-type: none">If an empty string is set for this parameter, decryption with this value is disabled.

Default Value	Empty string
----------------------	--------------

CFG_FILE_KEY_LENGTH

Value Format	Integer
Description	Specifies the key lengths in bits used to decrypt configuration files.
Value Range	128
Default Value	128 (fixed)

CFG_CYCLIC

Value Format	Boolean
Description	Specifies whether the SIP-CS periodically checks for updates of configuration files.
Value Range	<ul style="list-style-type: none"> • Y (Enable periodic synchronization of configuration files) • N (Disable periodic synchronization of configuration files)
Default Value	N

CFG_CYCLIC_INVL

Value Format	Integer
Description	Specifies the interval, in minutes, between periodic checks for updates of the configuration files.
Value Range	1–40320
Default Value	10080

CFG_RTRY_INVL

Value Format	Integer
Description	Specifies the period of time, in minutes, that the SIP-CS will retry checking for an update of the configuration files after a configuration file access error has occurred.
Note	<ul style="list-style-type: none"> • This setting is available only when "CFG_CYCLIC" is set to "Y".
Value Range	1–1440
Default Value	30

4.2.6 Other Settings

CFG_RESYNC_TIME

Value Format	String
Description	Specifies the time (hour:minute) that the SIP-CS checks for updates of configuration files.
Value Range	00:00–23:59 Note <ul style="list-style-type: none">• If the value for this setting is any valid value other than an empty string, the SIP-CS downloads the configuration files at the fixed time, and the settings specified in "CFG_CYCLIC", "CFG_CYCLIC_INTVL", and "CFG_RTRY_INTVL" are disabled.• If the value for this setting is an empty string, downloading the configuration files at the fixed time are disabled.
Default Value	Empty string

CFG_RESYNC_FROM_SIP

Value Format	String
Description	Specifies the value of the "Event" header sent from the SIP server to the SIP-CS so that the SIP-CS can access the configuration files on the provisioning server.
Value Range	Max. 15 characters Note <ul style="list-style-type: none">• An empty string is not allowed.
Default Value	check-sync

4.2.6 Other Settings

IPEI_PSy

Value Format	String
Description	Specifies the S-PS's IPEI, which is used when registering the S-PS to the SIP-CS.
Value Range	12 digits
Default Value	Empty string

SIP_REGI_PS_LIMIT

Value Format	Integer
---------------------	---------

Description	Specifies the number of S-PSs (SIP server accounts) per SIP-CS. Configure this setting referring to the expire time for SIP registration in the table below.		
Expire time (in seconds)	Number of S-PSs (1 account)	Number of S-PSs (2 accounts)	
20	32	16	
30	64	32	
360	192	96	
480	255	128	
960	255	255	

| **Value Range** | 1–255 | | |
| **Default Value** | 32 | | |

PROVISION_SUPERMASTER_ONLY

Value Format	Boolean
Description	Specifies whether only the Super Master CS or all SIP-CSs can perform provisioning.
Value Range	<ul style="list-style-type: none"> Y (Only the Super Master CS can perform provisioning.) N (All SIP-CSs can perform provisioning.) <p>Note</p> <ul style="list-style-type: none"> When "Y" is selected, after downloading the configuration file, the Super Master CS distributes it to all other SIP-CSs.
Default Value	N

PS_FIRM_UPGRADE_MODE

Value Format	String
Description	Specifies the download mode of S-PS firmware.
Value Range	<ul style="list-style-type: none"> UP (Download S-PS firmware for upgrades only.) DOWN (Download S-PS firmware for downgrades only.) UP/DOWN (Download S-PS firmware for upgrades and downgrades.)
Default Value	UP

4.3 Network Settings

4.3.1 IP Settings

[CONNECTION_TYPE](#)

Value Format	Integer
Description	Specifies whether to assign the IP address automatically (DHCP) or manually (static).
Value Range	<ul style="list-style-type: none"> • 1 (DHCP) • 0 (Static)
Default Value	1

[HOST_NAME](#)

Value Format	String
Description	Specifies the host name for the SIP-CS to send to the DHCP server.
Note	<ul style="list-style-type: none"> • This setting is available only when "CONNECTION_TYPE" is set to "1".
Value Range	Max. 63 characters
Note	<ul style="list-style-type: none"> • An empty string is not allowed. • If "{MODEL}" is included in this parameter, it will be replaced with the SIP-CS's model name.
Default Value	{MODEL}

[DHCP_DNS_ENABLE](#)

Value Format	Boolean
Description	Specifies whether to receive DNS server addresses automatically or to assign a DNS server addresses (up to 2) manually.
Note	<ul style="list-style-type: none"> • This setting is available only when "CONNECTION_TYPE" is set to "1".
Value Range	<ul style="list-style-type: none"> • Y (Use "USER_DNS1_ADDR" or, "USER_DNS1_ADDR" and "USER_DNS2_ADDR") • N (Receive DNS server address automatically)
Default Value	N

STATIC_IP_ADDRESS

Value Format	String
Description	<p>Specifies the IP address for the SIP-CS.</p> <p>Note</p> <ul style="list-style-type: none"> • This setting is available only when "CONNECTION_TYPE" is set to "0". • When you specify this parameter, you must specify "STATIC_SUBNET" together in a configuration file.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

STATIC_SUBNET

Value Format	String
Description	<p>Specifies the subnet mask for the SIP-CS.</p> <p>Note</p> <ul style="list-style-type: none"> • This setting is available only when "CONNECTION_TYPE" is set to "0". • When you specify this parameter, you must specify "STATIC_IP_ADDRESS" together in a configuration file.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

STATIC_GATEWAY

Value Format	String
Description	<p>Specifies the IP address of the default gateway for the network where the SIP-CS is connected.</p> <p>Note</p> <ul style="list-style-type: none"> • This setting is available only when "CONNECTION_TYPE" is set to "0". • When you specify this parameter, you must specify "STATIC_IP_ADDRESS" and "STATIC_SUBNET" together in a configuration file.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

4.3.2 DNS Settings

USER_DNS1_ADDR

Value Format	String
Description	Specifies the IP address of the primary DNS server. Note <ul style="list-style-type: none">• This setting is available only when "CONNECTION_TYPE" is set to "0".
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

USER_DNS2_ADDR

Value Format	String
Description	Specifies the IP address of the secondary DNS server. Note <ul style="list-style-type: none">• This setting is available only when "CONNECTION_TYPE" is set to "0".
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

4.3.2 DNS Settings

DNS_QRY_PRL

Value Format	Boolean
Description	Specifies the DNS query method as parallel or sequential.
Value Range	<ul style="list-style-type: none">• Y (Parallel)• N (Sequential) Note <ul style="list-style-type: none">• If set to "Y", the SIP-CS sends out all DNS queries at the same time. The first DNS reply will be accepted and used by the SIP-CS.• If set to "N", the SIP-CS sends DNS queries sequentially. The SIP-CS sends a request to the DNS server with the highest priority for a preprogrammed time period (5 seconds). When the timer expires, the SIP-CS sends a request to the DNS server with the second priority.
Default Value	Y

DNS_PRIORITY

Value Format	Boolean
Description	Specifies the priority of the DNS server.
Value Range	<ul style="list-style-type: none"> • Y ("DNS1_ADDR" and "DNS2_ADDR" have first priority.) • N ("DNS1_ADDR" and "DNS2_ADDR" have no priority.) <p>Note</p> <ul style="list-style-type: none"> • If set to "Y", the DNS servers specified in "DNS1_ADDR" and "DNS2_ADDR" will be queried first. If the queries fail, the DNS server specified by the user (DHCP or static) will be queried. • If set to "N", the DNS server specified by the user (DHCP or static) will be queried first. If the query fails, the DNS servers specified in "DNS1_ADDR" and "DNS2_ADDR" will be queried.
Default Value	N

DNS1_ADDR

Value Format	String
Description	Specifies the IP address of the primary DNS server for your dealer.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

DNS2_ADDR

Value Format	String
Description	Specifies the IP address of the secondary DNS server for your dealer.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

4.3.3 Ethernet Port Settings

LLDP_ENABLE

Value Format	Boolean
Description	Selects whether to enable or disable sending and receiving LLDP frames.
Value Range	<ul style="list-style-type: none"> • Y (Enable) • N (Disable)
Default Value	Y

4.3.4 HTTP Settings

LLDP_INTERVAL

Value Format	Integer
Description	Specifies the interval, in seconds, between sending each LLDP frame.
Value Range	1–3600
Default Value	30

VLAN_ENABLE

Value Format	Boolean
Description	Specifies whether to use the VLAN feature to perform VoIP communication securely.
Value Range	<ul style="list-style-type: none">• Y (Enable)• N (Disable)
Default Value	N

VLAN_ID_IP_PHONE

Value Format	Integer
Description	Specifies the VLAN ID for this SIP-CS.
Value Range	1–4094
Default Value	2

VLAN_PRI_IP_PHONE

Value Format	Integer
Description	Specifies the priority number for the SIP-CS.
Value Range	0–7
Default Value	7

4.3.4 HTTP Settings

HTTPD_PORTOPEN_AUTO

Value Format	Boolean
Description	Specifies whether the SIP-CS's Web port is always open.

Value Range	<ul style="list-style-type: none"> • Y (Web port is always open) • N (Web port must be opened manually) <p>Notice</p> <ul style="list-style-type: none"> • If you want to set to "Y", please fully recognize the possibility of unauthorized access to the SIP-CS through the Web user interface and change this setting at your own risk. In addition, please take full security measures for connecting to an external network and control all passwords for logging in to the Web user interface.
Default Value	N

HTTP_VER

Value Format	Integer
Description	Specifies which version of the HTTP protocol to use for HTTP communication.
Value Range	<ul style="list-style-type: none"> • 1 (Use HTTP 1.0) • 0 (Use HTTP 1.1) <p>Note</p> <ul style="list-style-type: none"> • For this SIP-CS, it is strongly recommended that you specify "1" for this setting. However, if the HTTP server does not function well with HTTP 1.0, try changing the setting "0".
Default Value	1

HTTP_USER_AGENT

Value Format	String
Description	Specifies the text string to send as the user agent in the header of HTTP requests.
Value Range	Max. 40 characters
Note	<ul style="list-style-type: none"> • An empty string is not allowed. • If "{mac}" is included in this parameter, it will be replaced with the SIP-CS's MAC address in lower-case. • If "{MAC}" is included in this parameter, it will be replaced with the SIP-CS's MAC address in upper-case. • If "{MODEL}" is included in this parameter, it will be replaced with the SIP-CS's model name. • If "{fwver}" is included in this parameter, it will be replaced with the firmware version of the SIP-CS.
Default Value	Panasonic_{MODEL}/{fwver} ({mac})

4.3.4 HTTP Settings

HTTP_SSL_VERIFY

Value Format	Integer
Description	Specifies whether to enable the verification of the root certificate.
Value Range	<ul style="list-style-type: none">• 0 (No verification of root certificate)• 1 (Simple verification of root certificate)• 2 (Precise verification of root certificate) <p>Note</p> <ul style="list-style-type: none">• If set to "0", the verification of the root certificate is disabled.• If set to "1", the verification of the root certificate is enabled. In this case, the validity of the certificate's date, certificate's chain, and the confirmation of the root certificate will be verified.• If set to "2", precise certificate verification is enabled. In this case, the validity of the server name will be verified in addition to the items verified when "1" is set.• If the SIP-CS has not obtained the current time, verification will not be performed irrelevant of this setting. In order to perform verification it is necessary to first set up the NTP server.
Default Value	0

CFG_ROOT_CERTIFICATE_PATH

Value Format	String
Description	Specifies the URI of the root certificate.
Value Range	<p>Max. 500 characters</p> <p>Note</p> <ul style="list-style-type: none">• The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩"<ul style="list-style-type: none">– "⟨user⟩" must be less than 128 characters.– "⟨password⟩" must be less than 128 characters.– "⟨user⟩:⟨password⟩@" may be empty.– The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.– "⟨port⟩" can be omitted if you do not need to specify the port number.
Default Value	Empty string

4.3.5 Time Adjust Settings

NTP_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the NTP server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

TIME_SYNC_INVL

Value Format	Integer
Description	Specifies the interval, in seconds, to resynchronize after having detected no reply from the NTP server.
Value Range	10–86400
Default Value	60

TIME_QUERY_INVL

Value Format	Integer
Description	Specifies the interval, in seconds, between synchronizations with the NTP server.
Value Range	10–86400
Default Value	43200

4.3.6 STUN Settings

STUN_SERV_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the STUN server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

STUN_SERV_PORT

Value Format	Integer
Description	Specifies the port number of the STUN server.
Value Range	1–65535

4.3.7 Xsi Server Settings

Default Value	3478
----------------------	------

STUN_2NDSERV_ADDR

Value Format	String
Description	Specifies the IP address of the secondary STUN server.
Note	<ul style="list-style-type: none">This setting is available only when "STUN_SERV_ADDR" is specified in IP address notation.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

STUN_2NDSERV_PORT

Value Format	Integer
Description	Specifies the port number of the secondary STUN server.
Value Range	1–65535
Default Value	3478

4.3.7 Xsi Server Settings

XSI_SERVER

Value Format	String
Description	Specifies the IP address or FQDN of Xsi server, which consists of "http (s)://" , and an Xsi Service server address and port, for example, "http://xsi.com", "https://xsi.com", "http://xsi.com:8080", "https://xsi.com:8080".
Value Range	Max. 84 characters
Default Value	Empty string

XSI_USERID

Value Format	String
Description	Specifies the unique ID used by the Xsi server.
Value Range	Max. 84 characters (except ", &, ', :, <, >, and space)
Default Value	Empty string

XSI_PASSWORD

Value Format	String
Description	Specifies the password used by the Xsi server.
Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Empty string

XSI_PHONEBOOK_TYPE

Value Format	Integer
Description	Selects the phonebook type that is downloaded from the Xsi server.
Value Range	1–5 1: Group 2: Group Common 3: Enterprise 4: Enterprise Common 5: Personal
Default Value	1

4.4 Telephone Settings

4.4.1 Call Control Settings

VM_SUBSCRIBE_ENABLE

Value Format	Boolean
Description	Specifies whether to send the SUBSCRIBE request to a voice mail server.
Note	<ul style="list-style-type: none"> • Your phone system must support voice mail.
Value Range	<ul style="list-style-type: none"> • Y (Send the SUBSCRIBE request) • N (Do not send the SUBSCRIBE request)
Default Value	N

CONFERENCE_SERVER_URI

Value Format	String
---------------------	--------

4.4.1 Call Control Settings

Description	Specifies the URI for a conference server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:conference@example.com".
Note	<ul style="list-style-type: none">• In a SIP URI, the user part ("conference" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.• Availability depends on your phone system.
Value Range	Max. 195 characters (except ", &, :, ;, <, >, and space)
Default Value	Empty string

FIRSTDIGIT_TIM

Value Format	Integer
Description	Specifies the length of time, in seconds, within which the first digits of a dial number must be dialed. When this timer expires, the SIP-CS will play a busy tone.
Value Range	1–600
Default Value	30

INTDIGIT_TIM

Value Format	Integer
Description	Specifies the length of time, in seconds, within which subsequent digits of a dial number must be dialed. When this timer expires after the last key was pressed, dialing will start.
Value Range	1–15
Default Value	5

MACRODIGIT_TIM

Value Format	Integer
Description	Specifies the length of time, in seconds, that the SIP-CS waits when a "T" or "t" has been entered in the dial plan.
Value Range	1–15
Default Value	5

INTERNATIONAL_ACCESS_CODE

Value Format	String
Description	Specifies the number to be shown in the place of the first "+" symbol when the phone number for incoming international calls contains "+".
Value Range	Max. 8 characters (consisting of 0–9, *, and #)
Note	<ul style="list-style-type: none"> No other characters are allowed.
Default Value	Empty string ("+" is deleted)

COUNTRY_CALLING_CODE

Value Format	String
Description	Specifies the country/area calling code to be used for comparative purposes when dialing a number from the incoming call log that contains a "+" symbol.
Value Range	Max. 8 characters (consisting of 0–9)
Default Value	Empty string

NATIONAL_ACCESS_CODE

Value Format	String
Description	When dialing a number from the incoming call log that contains a "+" symbol and the country calling code matches, the country calling code is removed and the national access code is added.
Value Range	Max. 8 characters (consisting of 0–9, *, and #)
Default Value	Empty string

DEFAULT_LINE_SELECT_PSY

Value Format	Integer
Description	Specifies the line used to make an outgoing call when no line is specified in the dialing operation.
Value Range	1–2
Default Value	1

HOLD_RECALL_TIM

Value Format	Integer
---------------------	---------

4.4.2 Tone Settings

Description	Specifies the duration of the hold recall timer. If set to "0", the function is disabled.
Value Range	0–240 (0: Disable)
Default Value	60

AUTO_CALL_HOLD

Value Format	Boolean
Description	Selects whether calls are disconnected or held when a DN button is pressed while having a conversation.
Value Range	<ul style="list-style-type: none">• X (Enable Auto Call Hold)• N (Disable Auto Call Hold)
Default Value	N

DISCONNECTION_MODE

Value Format	Integer
Description	Selects the tone heard (reorder tone or busy tone) when a dial operation fails.
Value Range	1–2 <ul style="list-style-type: none">– 1: Mode1 (ROT)– 2: Mode2 (BT)
Default Value	1

TONE_LEN_DISCONNECT_HANDSFREE

Value Format	Integer
Description	Specifies the duration, in seconds, that a disconnect tone will be heard when the other party ends a call. This setting applies to both Receiver mode and Hands-free mode.
Value Range	1–15
Default Value	3

4.4.2 Tone Settings

DIAL_TONE1_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of Dial Tone 1 using 2 whole numbers separated by a comma.

Value Range	0, 200–2000 (0: No tone)
Default Value	350,440

DIAL_TONE1_GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of Dial Tone 1.
Value Range	-24–6
Default Value	0

DIAL_TONE1_RPT

Value Format	Integer
Description	Specifies whether Dial Tone 1 is repeated.
Value Range	0–1 – 0: No Repeat – 1: Repeat
Default Value	0

DIAL_TONE1_TIMING

Value Format	Comma-separated Integer
Description	Specifies the pattern, in milliseconds, of Dial Tone 1 using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas. Note <ul style="list-style-type: none">• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).• Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,0

DIAL_TONE2_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of Dial Tone 2 using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	350,440

4.4.2 Tone Settings

DIAL_TONE2_GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of Dial Tone 2.
Value Range	-24–6
Default Value	0

DIAL_TONE2_RPT

Value Format	Integer
Description	Specifies whether Dial Tone 2 is repeated.
Value Range	0–1 — 0: No Repeat — 1: Repeat
Default Value	0

DIAL_TONE2_TIMING

Value Format	Comma-separated Integer
Description	Specifies the pattern, in milliseconds, of Dial Tone 2 using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas. Note <ul style="list-style-type: none">• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).• Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,0

DIAL_TONE4_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of Dial Tone 4 (stutter dial tones) to notify that a voice mail is waiting, using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	350,440

DIAL TONE4 GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of Dial Tone 4 (stutter-type dial tone).
Value Range	-24–6
Default Value	0

DIAL_TONE4_RPT

Value Format	Integer
Description	Specifies whether Dial Tone 4 (stutter-type dial tone) is repeated.
Value Range	0–1 <ul style="list-style-type: none">– 0: No Repeat– 1: Repeat
Default Value	0

DIAL_TONE4_TIMING

BUSY_TONE_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of busy tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	480,620

4.4.2 Tone Settings

BUSY_TONE_GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of the busy tone.
Value Range	-24–6
Default Value	0

BUSY_TONE_RPT

Value Format	Integer
Description	Specifies whether the busy tone is repeated.
Value Range	0–1 — 0: No Repeat — 1: Repeat
Default Value	1

BUSY_TONE_TIMING

Value Format	Comma-separated Integer
Description	Specifies the pattern, in milliseconds, of busy tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas. Note <ul style="list-style-type: none">• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).• Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,500,440

REORDER_TONE_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of reorder tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	480,620

REORDER_TONE_GAIN

Value Format	Integer
---------------------	---------

Description	Specifies the gain, in decibels, of the reorder tone.
Value Range	-24–6
Default Value	0

REORDER_TONE_RPT

Value Format	Integer
Description	Specifies whether the reorder tone is repeated.
Value Range	0–1 — 0: No Repeat — 1: Repeat
Default Value	1

REORDER_TONE_TIMING

Value Format	Comma-separated Integer
Description	Specifies the pattern, in milliseconds, of reorder tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
Note	<ul style="list-style-type: none"> It is recommended that you set a value of 60 milliseconds or more for the first value (off 1). Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,250,190

RINGBACK_TONE_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of ringback tones using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	440,480

RINGBACK_TONE_GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of the ringback tone.
Value Range	-24–6

4.4.2 Tone Settings

Default Value	0
----------------------	---

RINGBACK_TONE_RPT

Value Format	Integer
Description	Specifies whether the ringback tone is repeated.
Value Range	0–1 – 0: No Repeat – 1: Repeat
Default Value	1

RINGBACK_TONE_TIMING

Value Format	Comma-separated Integer
Description	Specifies the pattern, in milliseconds, of ringback tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas. Note <ul style="list-style-type: none">• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).• Avoid setting 1–50 for any of the values.
Value Range	0–16000 (0: Infinite time)
Default Value	60,2000,3940

HOLD_TONE_FRQ

Value Format	Comma-separated Integer
Description	Specifies the dual-tone frequencies, in hertz, of the hold tone using 2 whole numbers separated by a comma.
Value Range	0, 200–2000 (0: No tone)
Default Value	425

HOLD_TONE_GAIN

Value Format	Integer
Description	Specifies the gain, in decibels, of the hold tone.
Value Range	-24–6
Default Value	0

BELL_CORE_PATTERN1_TIMING

Value Format	Comma-separated Integer
Description	Specifies the cadence, in milliseconds, of pattern ID 1, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas. Note <ul style="list-style-type: none">• Avoid setting 1–99 for any of the values.
Value Range	0–5000 (0: Infinite time)
Default Value	2000,4000

BELL_CORE_PATTERN2_TIMING

Value Format	Comma-separated Integer
Description	Specifies the cadence, in milliseconds, of pattern ID 2, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas. Note <ul style="list-style-type: none">• Avoid setting 1–99 for any of the values.
Value Range	0–5000 (0: Infinite time)
Default Value	800,400,800,4000

BELL_CORE_PATTERN3_TIMING

Value Format	Comma-separated Integer
Description	Specifies the cadence, in milliseconds, of pattern ID 3, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas. Note <ul style="list-style-type: none">• Avoid setting 1–99 for any of the values.
Value Range	0–5000 (0: Infinite time)
Default Value	400,200,400,200,800,4000

BELL_CORE_PATTERN4_TIMING

Value Format	Comma-separated Integer
---------------------	-------------------------

4.4.3 Telephone Settings

Description	Specifies the cadence, in milliseconds, of pattern ID 4, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
Note	<ul style="list-style-type: none">Avoid setting 1–99 for any of the values.
Value Range	0–5000 (0: Infinite time)
Default Value	300,200,1000,200,300,4000

BELL_CORE_PATTERN5_TIMING

Value Format	Comma-separated Integer
Description	Specifies the cadence, in milliseconds, of pattern ID 5, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
Note	<ul style="list-style-type: none">Avoid setting 1–99 for any of the values.
Value Range	0–5000 (0: Infinite time)
Default Value	500

4.4.3 Telephone Settings

NUMBER_MATCHING_LOWER_DIGIT

Value Format	Integer
Description	Specifies the minimum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
Value Range	0–15
Default Value	7

NUMBER_MATCHING_UPPER_DIGIT

Value Format	Integer
Description	Specifies the maximum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
Value Range	0–15
Default Value	10

DEFAULT_LANGUAGE

Value Format	String
Description	Selects the language to use for the menus and display items on the phone.
Value Range	<p>Only the following values are available:</p> <ul style="list-style-type: none"> • <code>en-GB</code> (English (UK)) • <code>de</code> (German) • <code>fr</code> (French) • <code>it</code> (Italian) • <code>es</code> (Spanish) • <code>nl</code> (Dutch) • <code>sv</code> (Swedish) • <code>da</code> (Danish) • <code>pt</code> (Portuguese) • <code>ru</code> (Russian) • <code>el</code> (Greek) • <code>pl</code> (Polish) • <code>cs</code> (Czech) • <code>sk</code> (Slovak) • <code>hu</code> (Hungarian) • <code>hr</code> (Croatian) • <code>uk</code> (Ukrainian) • <code>en-US</code> (English (US)) • <code>fr-CA</code> (French (Canadian)) • <code>es-LA</code> (Latin Spanish) • <code>pt-BR</code> (Brazilian Portuguese)
Default Value	<code>en-US</code>

POUND_KEY_DELIMITER_ENABLE

Value Format	Boolean
Description	Specifies whether the # key is treated as a regular dialed digit or a delimiter, when dialed as or after the second digit.
Value Range	<ul style="list-style-type: none"> • <code>Y</code> (# is treated as the end of dialing delimiter) • <code>N</code> (# is treated as a regular dialed digit)
Default Value	<code>Y</code>

FLEXIBLE_KEY_LIST_DISPLAY_TIMER

Value Format	Integer
Description	Specifies, in seconds, the length of time that the PBX Flexible Button List is displayed on the phone.

4.4.4 SIP-CS Settings

Value Range	0–255
Default Value	15

4.4.4 SIP-CS Settings

WL_PSREGISTRATION_PIN

Value Format	String
Description	Specifies the PIN (Personal Identification Number) used when registering the S-PS.
Value Range	4 digits (consisting of 0–9)
Default Value	1234

WL_AIRSYNCGROUP_CS

Value Format	Integer
Description	Specifies the Air Sync Group of the SIP-CS. Notice <ul style="list-style-type: none">All calls will be disconnected when you change this setting.
Value Range	1–8
Default Value	1

SUPERMASTER_IPADDRESS_CS

Value Format	String
Description	Specifies the IP address of the Super Master CS to which the SIP-CS is connected. Notice <ul style="list-style-type: none">All calls will be disconnected when you change this setting.
Value Range	IP address in dotted-decimal notation
Default Value	Empty string

WL_CLASS_CS

Value Format	String
Description	Specifies the classification of the SIP-CS. Notice <ul style="list-style-type: none">All calls will be disconnected when you change this setting.

Value Range	<ul style="list-style-type: none"> • Slave • Master • SecondMaster
Default Value	Slave

HO_RTP_PORT_MIN

Value Format	Integer
Description	Specifies the lowest port number used for RTP packets when performing a call handover.
Value Range	1024–47152 Note <ul style="list-style-type: none"> • The value for this setting must be less than or equal to "HO_RTP_PORT_MAX" - 1999.
Default Value	40000

HO_RTP_PORT_MAX

Value Format	Integer
Description	Specifies the highest port number used for RTP packets when performing a call handover.
Value Range	3023–49151 Note <ul style="list-style-type: none"> • The value for this setting must be greater than or equal to "HO_RTP_PORT_MIN" + 1999.
Default Value	42000

HO_EXE_TIME

Value Format	Integer
Description	Specifies the processing speed as opposed to sound quality when performing a call handover.
Value Range	<ul style="list-style-type: none"> • 4 (Processing speed is very fast) • 3 (Processing speed is fast) • 2 (Processing speed is medium) • 1 (Processing speed is slow) • 0 (Processing speed is very slow)
Default Value	2

4.4.5 Flexible Button Settings

FLEX_BUTTON_FACILITY_ACTx_PSy

Value Format	String
Description	<p>Specifies a particular Facility Action for the flexible button. No facility action will be taken for the button if the string is empty or invalid.</p> <p>Note</p> <ul style="list-style-type: none"> If this parameter is specified, "FLEX_BUTTON_QUICK_DIALx_PSy" should be an empty string.
Value Range	<ul style="list-style-type: none"> X_PANASONIC_IPTEL_DN X_PANASONIC_IPTEL_ONETOUCH
Default Value	X_PANASONIC_IPTEL_DN

FLEX_BUTTON_FACILITY_ARGx_PSy

Value Format	String
Description	Optional argument associated with the specified Facility Action for the flexible button. For details, see 6.3.1 Flexible Button Settings .
Value Range	Max. 32 characters
Default Value	1

FLEX_BUTTON_QUICK_DIALx_PSy

Value Format	String
Description	<p>Specifies a quick dial destination number to be used for the flexible button.</p> <p>Note</p> <ul style="list-style-type: none"> If this parameter is specified, "FLEX_BUTTON_FACILITY_ACTx_PSy" should be an empty string. This parameter cannot be specified via Web user interface programming. Therefore, when using Web user programming and configuration file programming in conjunction, "FLEX_BUTTON_FACILITY_ACTx_PSy" should be set to "X_PANASONIC_IPTEL_ONETOUCH".
Value Range	Max. 32 characters (consisting of 0–9, *, and #)
Default Value	Empty string

FLEX_BUTTON_LABELx_PSy

Value Format	String
Description	Specifies the message to be displayed on the screen when the flexible button is pressed.
Value Range	Max. 10 characters Note <ul style="list-style-type: none">• You can use Unicode characters for this setting.
Default Value	Empty string

4.5 VoIP Settings

4.5.1 Codec Settings

CODEC_G711_REQ

Value Format	Integer
Description	Specifies whether to set "PCMU" as a codec selection automatically when the codec is set to any codec selection other than "PCMU".
Value Range	<ul style="list-style-type: none"> • 0 (Do not set "PCMU") • 1 (Set "PCMU")
Default Value	1

CODEC_G729_PARAM

Value Format	Integer
Description	Specifies whether to add an attribute line, "a=fmtp:18 annexb=no", to SDP when the codec is set to "G729A".
Value Range	<ul style="list-style-type: none"> • 0 (Do not add "a=fmtp:18 annexb=no") • 1 (Add "a=fmtp:18 annexb=no")
Default Value	0

CODEC_ENABLEx

Value Format	Boolean
---------------------	---------

4.5.2 RTP Settings

Description	Specifies whether to enable the codec specified in the parameter list.
Note	<ul style="list-style-type: none">• The "x" character in the parameter title should be changed to one of the following numbers, according to the codec to be changed.<ul style="list-style-type: none">– 0: G.722– 1: PCMA– 2: G.726-32– 3: G.729A– 4: PCMU• For codec setting examples, see 3.5.1 Examples of Codec Settings.
Value Range	<ul style="list-style-type: none">• Y (Enable)• N (Disable)
Default Value	Y

CODEC_PRIORITYx

Value Format	Integer
Description	Specifies the priority order for the codec.
Note	<ul style="list-style-type: none">• The "x" character in the parameter title should be changed to one of the following numbers, according to the codec to be changed.<ul style="list-style-type: none">– 0: G.722– 1: PCMA– 2: G.726-32– 3: G.729A– 4: PCMU• For codec setting examples, see 3.5.1 Examples of Codec Settings.
Value Range	1–255
Default Value	1

4.5.2 RTP Settings

DSCP_RTP

Value Format	Integer
Description	Selects the DSCP level of DiffServ applied to RTP packets.
Value Range	0–63
Default Value	0

DSCP_RTCP

Value Format	Integer
Description	Selects the DSCP level of DiffServ applied to RTCP packets.
Value Range	0–63
Default Value	0

RTCP_INTVL

Value Format	Integer
Description	Specifies the interval, in seconds, between RTCP packets.
Value Range	5–65535
Default Value	5

MAX_DELAY

Value Format	Integer
Description	Specifies the maximum delay, in 10-millisecond units, of the jitter buffer.
Value Range	3–50 (\times 10 ms)
	<p>Note</p> <ul style="list-style-type: none"> This setting is subject to the following conditions: <ul style="list-style-type: none"> This value must be greater than "NOM_DELAY" This value must be greater than "MIN_DELAY" "NOM_DELAY" must be greater than or equal to "MIN_DELAY"
Default Value	20

MIN_DELAY

Value Format	Integer
Description	Specifies the minimum delay, in 10-millisecond units, of the jitter buffer.
Value Range	1 or 2 (\times 10 ms)
	<p>Note</p> <ul style="list-style-type: none"> This setting is subject to the following conditions: <ul style="list-style-type: none"> This value must be less than or equal to "NOM_DELAY" This value must be less than "MAX_DELAY" "MAX_DELAY" must be greater than "NOM_DELAY"
Default Value	2

4.5.2 RTP Settings

NOM_DELAY

Value Format	Integer
Description	Specifies the initial delay, in 10-millisecond units, of the jitter buffer.
Value Range	1–7 ($\times 10$ ms) Note <ul style="list-style-type: none">• This setting is subject to the following conditions:<ul style="list-style-type: none">– This value must be greater than or equal to "MIN_DELAY"– This value must be less than "MAX_DELAY"
Default Value	2

RTP_PORT_MIN

Value Format	Integer
Description	Specifies the lowest port number that the SIP-CS will use for RTP packets.
Value Range	1024–45150 (even number only) Note <ul style="list-style-type: none">• The value for this setting must be less than or equal to "RTP_PORT_MAX" - 4000.• Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines \times No. of channels \times 2 \times 1 (No. of terminals)
Default Value	16000

RTP_PORT_MAX

Value Format	Integer
Description	Specifies the highest port number that the SIP-CS will use for RTP packets.
Value Range	5024–49150 (even number only) Note <ul style="list-style-type: none">• The value for this setting must be greater than or equal to "RTP_PORT_MIN" + 4000.• Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines \times No. of channels \times 2 \times 1 (No. of terminals)
Default Value	29000

RTP_PTIME

Value Format	Integer
Description	Specifies the interval, in milliseconds, between transmissions of RTP packets.
Value Range	<ul style="list-style-type: none"> • 20 • 30 • 40
Default Value	20

RTCP_ENABLE

Value Format	Boolean
Description	Selects whether to enable or disable RTCP (Real-Time Transport Control Protocol). For details, refer to RFC 3550.
Value Range	<ul style="list-style-type: none"> • Y (Enable RTCP) • N (Disable RTCP)
Default Value	N

RTCP_SEND_BY_SD

Value Format	Integer
Description	Specifies whether to send RTCP signals by SDP (Session Description Protocol).
Value Range	0–1 <ul style="list-style-type: none"> – 0: Send RTCP signals using the value specified in "RTCP_INTVL", if the "RTCP_ENABLE" parameter is enabled. – 1: Send RTCP signals using the value specified in the SDP attribute "a=rtcp:".
Default Value	0

RTP_CLOSE_ENABLE

Value Format	Boolean
Description	Specifies whether to enable processing to close held RTP sockets.
Value Range	<ul style="list-style-type: none"> • Y (Enable RTP Close) • N (Disable RTP Close)
Default Value	Y

4.5.3 Miscellaneous VoIP Settings

OUTBANDDTMF

Value Format	Boolean
Description	Specifies the method for transmitting DTMF tones.
Value Range	<ul style="list-style-type: none"> • Y (Outband [use telephone-event]) • N (Inband) <p>Note</p> <ul style="list-style-type: none"> • If set to "Y", DTMF tones will be sent through SDP, compliant with RFC 2833. • If set to "N", DTMF tones will be encoded in the RTP stream.
Default Value	Y

DTMF_RELAY

Value Format	Boolean
Description	Selects whether DTMF tones are sent in the SIP INFO message.
Value Range	<ul style="list-style-type: none"> • Y • N <p>Note</p> <ul style="list-style-type: none"> • If set to "Y", DTMF tones will be sent in the SIP INFO message. • If set to "N", the method selected in "OUTBANDDTMF" will be used.
Default Value	N

OUTBANDDTMF_VOL

Value Format	Integer
Description	Specifies the volume (in decibels [dB]) of the DTMF tone using RFC 2833.
Value Range	-63–0
Default Value	-5

INBANDDTMF_VOL

Value Format	Integer
Description	Specifies the volume (in decibels [dB]) of in-band DTMF tones.
Value Range	-46–0

Default Value	-5
----------------------	----

TELEVENT_PAYLOAD

Value Format	Integer
Description	Specifies the RFC 2833 payload type for DTMF tones.
Note	<ul style="list-style-type: none"> This setting is available only when "OUTBANDDTMF" is set to "Y".
Value Range	96–127
Default Value	101

RFC2543_HOLD_ENABLE

Value Format	Boolean
Description	Specifies whether to enable the RFC 2543 Call Hold feature on this line.
Value Range	<ul style="list-style-type: none"> Y (Enable RFC 2543 Call Hold) N (Disable RFC 2543 Call Hold) Note <ul style="list-style-type: none"> If set to "Y", the "c=0.0.0.0" syntax will be set in SDP when sending a re-INVITE message to hold the call. If set to "N", the "c=x.x.x.x" syntax will be set in SDP.
Default Value	Y

DTMF_SIGNAL_LEN

Value Format	Integer
Description	Specifies the length of the DTMF signal, in milliseconds.
Value Range	60–200
Default Value	180

DTMF_INTDIGIT_TIM

Value Format	Integer
Description	Specifies the interval, in milliseconds, between DTMF signals.
Value Range	60–200
Default Value	90

4.6 Line Settings

4.6.1 Call Control Settings

[DISPLAY_NAME_PSy_n](#)

Parameter Name Example	<code>DISPLAY_NAME_PS1_1, DISPLAY_NAME_PS1_2, DISPLAY_NAME_PS2_1, DISPLAY_NAME_PS2_2, : DISPLAY_NAME_PS255_1, DISPLAY_NAME_PS255_2</code>
Value Format	String
Description	Specifies the name to display as the caller on the other party's phone when you make a call.
Value Range	Max. 24 characters
	<p>Note</p> <ul style="list-style-type: none"> • You can use Unicode characters for this setting.
Default Value	Empty string

[VM_NUMBER_PSy_n](#)

Parameter Name Example	<code>VM_NUMBER_PS1_1, VM_NUMBER_PS1_2, VM_NUMBER_PS2_1, VM_NUMBER_PS2_2, : VM_NUMBER_PS255_1, VM_NUMBER_PS255_2</code>
Value Format	String
Description	Specifies the phone number used to access the voice mail server.
	<p>Note</p> <ul style="list-style-type: none"> • Your phone system must support voice mail.
Value Range	Max. 32 characters
Default Value	Empty string

[DIAL_PLAN_PSy](#)

Value Format	String
Description	Specifies a dial format, such as specific phone numbers, that control which numbers can be dialed or how to handle the call when making a call. For details, see 6.2 Dial Plan .
Value Range	Max. 500 characters
Default Value	Empty string

DIAL_PLAN_NOT_MATCH_ENABLE_PSy

Value Format	Boolean
Description	Specifies whether to enable dial plan filtering so that a call is not made when the dialed number does not match any of the dial formats specified in "DIAL_PLAN_PSy".
Value Range	<ul style="list-style-type: none"> • Y (Enable dial plan filtering) • N (Disable dial plan filtering) <p>Note</p> <ul style="list-style-type: none"> • If set to "Y", the dialed number will not be sent to the line when the number dialed by the user does not match any of the dial formats specified in the dial plan. • If set to "N", the dialed number will be sent to the line, even if the number dialed by the user does not match any of the dial formats specified in the dial plan.
Default Value	N

SHARED_CALL_ENABLE_PSy_n

Parameter Name Example	<pre>SHARED_CALL_ENABLE_PS1_1, SHARED_CALL_ENABLE_PS1_2, SHARED_CALL_ENABLE_PS2_1, SHARED_CALL_ENABLE_PS2_2, : SHARED_CALL_ENABLE_PS255_1, SHARED_CALL_ENABLE_PS255_2</pre>
Value Format	Boolean
Description	Specifies whether to enable the Shared Call feature of the SIP server, which is used to share one line among the SIP-CSs.
Value Range	<ul style="list-style-type: none"> • Y (Enable shared call) • N (Disable shared call) <p>Note</p> <ul style="list-style-type: none"> • You cannot set both "SHARED_CALL_ENABLE_PSy_n" and "FWD_DND_SYNCHRO_ENABLE_PSy_n" to "Y" at the same time. • Availability depends on your phone system.
Default Value	N

4.6.1 Call Control Settings

FWD_DND_SYNCHRO_ENABLE_PSy_n

Parameter Name Example	FWD_DND_SYNCHRO_ENABLE_PS1_1, FWD_DND_SYNCHRO_ENABLE_PS1_2, FWD_DND_SYNCHRO_ENABLE_PS2_1, FWD_DND_SYNCHRO_ENABLE_PS2_2, : FWD_DND_SYNCHRO_ENABLE_PS255_1, FWD_DND_SYNCHRO_ENABLE_PS255_2
Value Format	Boolean
Description	Specifies whether to synchronize the Do Not Disturb and Call Forward settings, configured via the Web user interface, between the SIP-CS and the portal server that is provided by your dealer.
	<p>Note</p> <ul style="list-style-type: none"> • Even if you specify "Y", this feature may not function properly if your phone system does not support it. Before you configure this setting, consult your dealer. • You cannot set both "SHARED_CALL_ENABLE_PSy_n" and "FWD_DND_SYNCHRO_ENABLE_PSy_n" to "Y" at the same time.
Value Range	<ul style="list-style-type: none"> • Y (Enable Do Not Disturb/Call Forward synchronization) • N (Disable Do Not Disturb/Call Forward synchronization)
Default Value	N

CW_ENABLE_PSy_n

Parameter Name Example	CW_ENABLE_PS1_1, CW_ENABLE_PS1_2, CW_ENABLE_PS2_1, CW_ENABLE_PS2_2, : CW_ENABLE_PS255_1, CW_ENABLE_PS255_2
Value Format	Boolean
Description	Specifies whether automatic call waiting is enabled.
Value Range	<ul style="list-style-type: none"> • Y (Enable Call Waiting) • N (Disable Call Waiting)
Default Value	Y

RETURN_VOL_SET_DEFAULT_ENABLE

Value Format	Boolean
Description	Specifies whether the volume is returned to its default setting after each call.
Value Range	<ul style="list-style-type: none"> • Y (Volume returns to the default setting after each call) • N (Volume does not change after each call)

Default Value	N
----------------------	----------

FLASH_RECALL_TERMINATE

Value Format	Boolean
Description	Selects the function of the FLASH/RECALL button during a conversation.
Value Range	<ul style="list-style-type: none"> • Y (Terminate) • N (EFA)
Default Value	Y

FLASHHOOK_CONTENT_TYPE

Value Format	String
Description	Specifies the type of signal sent when sending a flash hook event.
Value Range	<ul style="list-style-type: none"> • Signal • flashhook
Default Value	Signal

VOICE_MESSAGE_AVAILABLE

Value Format	Boolean
Description	Selects how the existence of voice messages is determined when a "Messages-Waiting: yes" message is received.
Value Range	<ul style="list-style-type: none"> • Y (Determines that voice messages exist when "Messages-Waiting: yes" is received with a "Voice-Message" line included.) • N (Determines that voice messages exist when "Messages-Waiting: yes" is received even without a "Voice-Message" line included.)
Default Value	Y

HOLD_SOUND_PATH

Value Format	Integer
---------------------	---------

4.6.2 SIP Settings

Description	Selects whether the SIP-CS's hold tone or the network server's hold tone (Music on hold) is played when a party is put on hold.
Note	<ul style="list-style-type: none"> • It is necessary to set the following parameters to play the SIP-CS's hold tone. <ul style="list-style-type: none"> – HOLD_TONE_FRQ – HOLD_TONE_GAIN
Value Range	0–1 <ul style="list-style-type: none"> – 0: The SIP-CS's hold tone is played. – 1: The network server's hold tone (Music on hold) is played.
Default Value	0

4.6.2 SIP Settings

SIP_USER_AGENT

Value Format	String
Description	Specifies the text string to send as the user agent in the headers of SIP messages.
Value Range	Max. 40 characters
Note	<ul style="list-style-type: none"> • An empty string is not allowed. • If "{mac}" is included in this parameter, it will be replaced with the SIP-CS's MAC address in lower-case. • If "{MAC}" is included in this parameter, it will be replaced with the SIP-CS's MAC address in upper-case. • If "{MODEL}" is included in this parameter, it will be replaced with the SIP-CS's model name. • If "{fwver}" is included in this parameter, it will be replaced with the firmware version of the SIP-CS.
Default Value	Panasonic_{MODEL}/{fwver} ({mac})

PHONE_NUMBER_PSy_n

Parameter Name Example	PHONE_NUMBER_PS1_1, PHONE_NUMBER_PS1_2, PHONE_NUMBER_PS2_1, PHONE_NUMBER_PS2_2, : PHONE_NUMBER_PS255_1, PHONE_NUMBER_PS255_2
Value Format	String

Description	Specifies the phone number to use as the user ID required for registration to the SIP registrar server.
Note	<ul style="list-style-type: none"> When registering using a user ID that is not a phone number, you should use the "SIP_URI" setting.
Value Range	Max. 32 characters
Default Value	Empty string

SIP_URI_PSy_n

Parameter Name Example	SIP_URI_PS1_1, SIP_URI_PS1_2, SIP_URI_PS2_1, SIP_URI_PS2_2, : SIP_URI_PS255_1, SIP_URI_PS255_2
Value Format	String
Description	Specifies the unique ID used by the SIP registrar server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com".
Note	<ul style="list-style-type: none"> When registering using a user ID that is not a phone number, you should use this setting. In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.
Value Range	Max. 195 characters (except ", &, ', :, ;, <, >, and space)
Default Value	Empty string

LINE_ENABLE_PSy_n

Parameter Name Example	LINE_ENABLE_PS1_1, LINE_ENABLE_PS1_2, LINE_ENABLE_PS2_1, LINE_ENABLE_PS2_2, : LINE_ENABLE_PS255_1, LINE_ENABLE_PS255_2
Value Format	String
Description	Specifies whether a line is enabled or disabled.
Note	<ul style="list-style-type: none"> Even when this parameter is enabled, if the "PROFILE_ENABLE_PSY" parameter is disabled, the line will be disabled.
Value Range	<ul style="list-style-type: none"> Disabled Enabled

4.6.2 SIP Settings

Default Value	Enabled
----------------------	----------------

PROFILE_ENABLE_PSy

Value Format	String
Description	Specifies whether all lines in the profile are enabled or disabled. Note <ul style="list-style-type: none">• Even when this parameter is enabled, if the "LINE_ENABLE_PSy_n" parameter is disabled, the line will be disabled.
Value Range	<ul style="list-style-type: none">• Disabled• Enabled
Default Value	Enabled

PROFILE_NAME_CS **PROFILE_NAME_PSy**

Value Format	String
Description	Specifies the name of the SIP-CS or S-PS.
Value Range	Max. 20 characters
Default Value	Empty string

SIP_AUTHID_PSy_n

Parameter Name Example	SIP_AUTHID_PS1_1, SIP_AUTHID_PS1_2, SIP_AUTHID_PS2_1, SIP_AUTHID_PS2_2, : SIP_AUTHID_PS255_1, SIP_AUTHID_PS255_2
Value Format	String
Description	Specifies the authentication ID required to access the SIP server.
Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Empty string

SIP_PASS_PSy_n

Parameter Name Example	SIP_PASS_PS1_1, SIP_PASS_PS1_2, SIP_PASS_PS2_1, SIP_PASS_PS2_2, : SIP_PASS_PS255_1, SIP_PASS_PS255_2
-------------------------------	---

Value Format	String
Description	Specifies the authentication password used to access the SIP server.
Value Range	Max. 127 characters (except ", &, :, <, >, and space)
Default Value	Empty string

SIP_SRC_PORT_PS_n

Parameter Name Example	<code>SIP_SRC_PORT_PS1_1, SIP_SRC_PORT_PS1_2, SIP_SRC_PORT_PS2_1, SIP_SRC_PORT_PS2_2, : SIP_SRC_PORT_PS255_1, SIP_SRC_PORT_PS255_2</code>
Value Format	Integer
Description	Specifies the source port number used by the SIP-CS for SIP communication.
Value Range	1024–49151
Note	<ul style="list-style-type: none"> The SIP port number for each line must be unique.
Default Value	<ul style="list-style-type: none"> PS1 Line1: 5061 PS1 Line2: 5062 PS2 Line1: 5063...
Note	<ul style="list-style-type: none"> The default value increases by 1 for each line.

SIP_PRXY_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the SIP proxy server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_PRXY_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the SIP proxy server.
Value Range	1–65535
Default Value	5060

4.6.2 SIP Settings

SIP_RGSTR_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the SIP registrar server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_RGSTR_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the SIP registrar server.
Value Range	1–65535
Default Value	5060

SIP_SVCDOMAIN

Value Format	String
Description	Specifies the domain name provided by your dealer. The domain name is the part of the SIP URI that comes after the "@" symbol.
Value Range	Max. 127 characters
Default Value	Empty string

REG_EXPIRE_TIME

Value Format	Integer
Description	Specifies the length of time, in seconds, that the registration remains valid. This value is set in the "Expires" header of the REGISTER request.
Value Range	1–4294967295
Default Value	3600

REG_INTERVAL_RATE

Value Format	Integer
Description	Specifies the percentage of the "expires" value after which to refresh registration by sending a new REGISTER message in the same dialog.
Value Range	1–100
Default Value	90

SIP_SESSION_TIME

Value Format	Integer
Description	Specifies the length of time, in seconds, that the SIP-CS waits before terminating SIP sessions when no reply to repeated requests is received. For details, refer to RFC 4028.
Value Range	0, 60–65535 (0: Disable)
Default Value	0

SIP_SESSION_METHOD

Value Format	Integer
Description	Selects the refreshing method of SIP sessions.
Value Range	0–2 – 0: reINVITE – 1: UPDATE – 2: AUTO
Default Value	0

DSCP_SIP

Value Format	Integer
Description	Selects the DSCP level of DiffServ applied to SIP packets.
Value Range	0–63
Default Value	0

SIP_2NDPROXY_ADDR

Value Format	String
Description	Specifies the IP address of the secondary SIP proxy server.
	<p>Note</p> <ul style="list-style-type: none"> This setting is available only when "SIP_PRXY_ADDR" is specified in IP address notation.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_2NDPROXY_PORT

Value Format	Integer
---------------------	---------

4.6.2 SIP Settings

Description	Specifies the port number to use for communication with the secondary SIP proxy server.
Value Range	1–65535
Default Value	5060

SIP_2NDRGSTR_ADDR

Value Format	String
Description	Specifies the IP address of the secondary SIP registrar server.
Note	<ul style="list-style-type: none">This setting is available only when "SIP_RGSTR_ADDR" is specified in IP address notation.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_2NDRGSTR_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the secondary SIP registrar server.
Value Range	1–65535
Default Value	5060

SIP_TIMER_T1

Value Format	Integer
Description	Specifies the default interval, in milliseconds, between transmissions of SIP messages. For details, refer to RFC 3261.
Value Range	<ul style="list-style-type: none">250500100020004000
Default Value	500

SIP_TIMER_T2

Value Format	Integer
Description	Specifies the maximum interval, in seconds, between transmissions of SIP messages. For details, refer to RFC 3261.

Value Range	<ul style="list-style-type: none"> • 2 • 4 • 8 • 16 • 32
Default Value	4

SIP_TIMER_T4

Value Format	Integer
Description	Specifies the maximum period, in seconds, that a message can remain on the network.
Value Range	<ul style="list-style-type: none"> • 0 • 1 • 2 • 3 • 4 • 5
Default Value	0

SIP_FOVR_NORSP

Value Format	Boolean
Description	Specifies whether to perform the fail-over process when the SIP-CS detects that the SIP server is not replying to SIP message.
Value Range	<ul style="list-style-type: none"> • Y (Enable fail-over) • N (Disable fail-over) <p>Note</p> <ul style="list-style-type: none"> • If set to "Y", the SIP-CS will try to use the other SIP servers via the DNS SRV and A records. • If set to "N", the SIP-CS will not try to use the other SIP servers.
Default Value	Y

SIP_FOVR_MAX

Value Format	Integer
Description	Specifies the maximum number of servers (including the first [normal] server) used in the fail-over process.
Value Range	1–4
Default Value	2

4.6.2 SIP Settings

SIP_REFRESHER

Value Format	Integer
Description	Specifies whether to add the refresher parameter for Session Expire in SIP INVITE.
Value Range	0–2 <ul style="list-style-type: none">– 0: Do not add the refresher parameter– 1: Add the refresher parameter with the value "UAS"– 2: Add the refresher parameter with the value "UAC"
Default Value	0

SIP_DNSSRV_ENA

Value Format	Boolean
Description	Specifies whether to request the DNS server to translate domain names into IP addresses using the SRV record.
Value Range	<ul style="list-style-type: none">• Y (Enable DNS SRV lookup)• N (Disable DNS SRV lookup) <p>Note</p> <ul style="list-style-type: none">• If set to "Y", the SIP-CS will perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.• If set to "N", the SIP-CS will not perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.
Default Value	Y

SIP_UDP_SRV_PREFIX

Value Format	String
Description	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using UDP.
Note	<ul style="list-style-type: none">• This setting is available only when "SIP_DNSSRV_ENA" is set to "Y".
Value Range	Max. 32 characters
Default Value	_sip._udp.

SIP_TCP_SRV_PREFIX

Value Format	String
---------------------	--------

Description	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using TCP.
Note	<ul style="list-style-type: none"> This setting is available only when "SIP_DNSSRV_ENA" is set to "Y".
Value Range	Max. 32 characters
Default Value	_sip._tcp.

SIP_100REL_ENABLE

Value Format	Boolean
Description	Specifies whether to add the option tag 100rel to the "Supported" header of the INVITE message. For details, refer to RFC 3262.
Value Range	<ul style="list-style-type: none"> Y (Enable 100rel function) N (Disable 100rel function) Note <ul style="list-style-type: none"> If set to "Y", the Reliability of Provisional Responses function will be enabled. The option tag 100rel will be added to the "Supported" header of the INVITE message and to the "Require" header of the "1xx" provisional message. If set to "N", the option tag 100rel will not be used.
Default Value	N

SIP_INVITE_EXPIRE

Value Format	Integer
Description	Specifies the period, in seconds, in which the INVITE message will expire.
Value Range	0, 60–65535 (0: Disable)
Default Value	0

SIP_18X_RTX_INTVL

Value Format	Integer
Description	Specifies the retransmission interval, in seconds, for "18x" responses.
Value Range	0, 1–600 (0: Disable)
Default Value	0

4.6.2 SIP Settings

SIP_PRSNC_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the SIP presence server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_PRSNC_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the SIP presence server.
Value Range	1–65535
Default Value	5060

SIP_2NDPRSNC_ADDR

Value Format	String
Description	Specifies the IP address of the secondary presence server.
Note	<ul style="list-style-type: none">This setting is available only when "SIP_PRSNC_ADDR" is specified in IP address notation.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_2NDPRSNC_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the secondary SIP presence server.
Value Range	1–65535
Default Value	5060

USE_DEL_REG_OPEN

Value Format	Boolean
Description	Specifies whether to enable cancelation before registration when, for example, the SIP-CS is turned on.

Value Range	<ul style="list-style-type: none"> • Y (Enable cancelation before registration) • N (Disable cancelation before registration)
Default Value	N

PORT_PUNCH_INTVL

Value Format	Integer
Description	<p>Specifies the interval, in seconds, between transmissions of the Keep Alive packet to the SIP-CS in order to maintain the NAT binding information.</p> <p>Note</p> <ul style="list-style-type: none"> • This setting is available only when "SIP_TRANSPORT" is set to "0" for UDP.
Value Range	0, 10–300 (0: Disable)
Default Value	0

SIP_ADD_RPORT

Value Format	Boolean
Description	Selects whether to add the 'rport' parameter to the top Via header field value of requests generated. For details, refer to RFC 3581.
Value Range	<ul style="list-style-type: none"> • Y (Add Rport [RFC 3581]) • N (Do not add Rport [RFC 3581])
Default Value	N

SIP_REQURI_PORT

Value Format	Boolean
Description	Specifies whether to add the port parameter to the Request-Line in the initial SIP request.
Value Range	<ul style="list-style-type: none"> • Y (Add the port parameter) • N (Do not add the port parameter) <p>Note</p> <ul style="list-style-type: none"> • Request URI in REGISTER example: <ul style="list-style-type: none"> – If set to "Y", the port parameter is added to the Request-Line, as follows: Request-Line: REGISTER sip:192.168.0.10:5060 SIP/2.0 – If set to "N", the port parameter is not added to the Request-Line, as follows: Request-Line: REGISTER sip:192.168.0.10 SIP/2.0
Default Value	Y

4.6.2 SIP Settings

SIP_SUBS_EXPIRE

Value Format	Integer
Description	Specifies the length of time, in seconds, that the subscription remains valid. This value is set in the "Expires" header of the SUBSCRIBE request.
Value Range	1–4294967295
Default Value	3600

SUB_RTX_INTVL

Value Format	Integer
Description	Specifies the interval, in seconds, between transmissions of SUBSCRIBE requests when a subscription results in failure (server no reply or error reply).
Note	<ul style="list-style-type: none">Transmissions will not be sent when the "403 Forbidden" error occurred.
Value Range	10–86400
Default Value	10

REG_RTX_INTVL

Value Format	Integer
Description	Specifies the interval, in seconds, between transmissions of the REGISTER request when a registration results in failure (server no reply or error reply).
Note	<ul style="list-style-type: none">Transmissions will not be sent when the "403 Forbidden" error occurred.
Value Range	10–86400
Default Value	10

SIP_P_PREFERRED_ID

Value Format	Boolean
Description	Specifies whether to add the "P-Preferred-Identity" header to SIP messages.
Value Range	<ul style="list-style-type: none">y (Add the "P-Preferred-Identity" header)n (Do not add the "P-Preferred-Identity" header)

Default Value	N
----------------------	---

SIP_PRIVACY

Value Format	Boolean
Description	Specifies whether to add the "Privacy" header to SIP messages.
Value Range	<ul style="list-style-type: none"> • Y (Add the "Privacy" header) • N (Do not add the "Privacy" header)
Default Value	N

ADD_USER_PHONE

Value Format	Boolean
Description	Specifies whether to add "user=phone" to the SIP URI in SIP messages.
Value Range	<ul style="list-style-type: none"> • Y (Add "user=phone") • N (Do not add "user=phone") <p>Note</p> <ul style="list-style-type: none"> • SIP URI example: <ul style="list-style-type: none"> – "sip:1111@tokyo.example.com;user=phone", when set to "Y" – "sip:1111@tokyo.example.com", when set to "N"
Default Value	N

SDP_USER_ID

Value Format	String
Description	Specifies the user ID used in the "o=" line field of SDP.
Value Range	Max. 32 characters (except ", &, ', :, <, >, and space)
Default Value	-

SUB_INTERVAL_RATE

Value Format	Integer
Description	Specifies the percentage of the "expires" value after which to refresh subscriptions by sending a new SUBSCRIBE message in the same dialog.
Value Range	1–100
Default Value	90

4.6.2 SIP Settings

SIP_OUTPROXY_ADDR

Value Format	String
Description	Specifies the IP address or FQDN of the SIP outbound proxy server.
Value Range	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
Default Value	Empty string

SIP_OUTPROXY_PORT

Value Format	Integer
Description	Specifies the port number to use for communication with the SIP outbound proxy server.
Value Range	1–65535
Default Value	5060

SIP_TRANSPORT

Value Format	Integer
Description	Specifies which transport layer protocol to use for sending SIP packets.
Value Range	<ul style="list-style-type: none">• 0 (UDP)• 1 (TCP)
Default Value	0

SIP_ANM_DISPNAME

Value Format	Integer
Description	Specifies the text string to set as the display name in the "From" header when making anonymous calls.
Value Range	<ul style="list-style-type: none">• 0 (Use normal display name)• 1 (Use "Anonymous" for display name)• 2 (Do not send a display name)
Default Value	1

SIP_ANM_USERNAME

Value Format	Integer
Description	Specifies the text string to set as the user name in the "From" header when making anonymous calls.

Value Range	<ul style="list-style-type: none"> • 0 (Use normal user name) • 1 (Use "anonymous" for user name) • 2 (Do not send a user name)
Default Value	0

SIP_ANM_HOSTNAME

Value Format	Boolean
Description	Specifies whether to set an anonymous host name in the "From" header when making anonymous calls.
Value Range	<ul style="list-style-type: none"> • y (Use "anonymous.invalid" for host name) • n (Use normal host name)
Default Value	n

SIP_DETECT_SSAF

Value Format	Boolean
Description	Specifies whether to enable SSAF for the SIP servers (registrar server, proxy server, and presence server).
Value Range	<ul style="list-style-type: none"> • y (Enable SSAF) • n (Disable SSAF) <p>Note</p> <ul style="list-style-type: none"> If set to "y", the SIP-CS receives SIP messages only from the source addresses stored in the SIP servers (registrar server, proxy server, and presence server), and not from other addresses. However, if "SIP_OUTPROXY_ADDR" in 4.6.2 SIP Settings is specified, the SIP-CS also receives SIP messages from the source address stored in the SIP outbound proxy server.
Default Value	n

SIP_RCV_DET_HEADER

Value Format	Boolean
Description	Specifies whether to check the username part of the SIP URI in the "To" header when receiving the INVITE message with an incorrect target SIP URI.

4.6.2 SIP Settings

Value Range	<ul style="list-style-type: none">• Y (Enable username check)• N (Disable username check)
Note	<ul style="list-style-type: none">• If set to "Y", the SIP-CS will return an error reply when it receives the INVITE message with an incorrect target SIP URI.• If set to "N", the SIP-CS will not check the username part of the SIP URI in the "To" header.
Default Value	N

SIP_CONTACT_ON_ACK

Value Format	Boolean
Description	Specifies whether to add the "Contact" header to SIP ACK message.
Value Range	<ul style="list-style-type: none">• Y (Add the "Contact" header)• N (Do not add the "Contact" header)
Default Value	N

SIP_TIMER_B

Value Format	Integer
Description	Specifies the value of SIP timer B (INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000
Default Value	32000

SIP_TIMER_D

Value Format	Integer
Description	Specifies the value of SIP timer D (wait time for answer resending), in milliseconds. For details, refer to RFC 3261.
Value Range	0, 250–64000
Default Value	5000

SIP_TIMER_F

Value Format	Integer
Description	Specifies the value of SIP timer F (non-INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000

Default Value	10000
----------------------	-------

SIP_TIMER_H

Value Format	Integer
Description	Specifies the value of SIP timer H (wait time for ACK reception), in milliseconds. For details, refer to RFC 3261.
Value Range	250–64000
Default Value	32000

SIP_TIMER_J

Value Format	Integer
Description	Specifies the value of SIP timer J (wait time for non-INVITE request resending), in milliseconds. For details, refer to RFC 3261.
Value Range	0, 250–64000
Default Value	5000

ADD_TRANSPORT_UDP

Value Format	Boolean
Description	Specifies whether to add the attribute "transport=udp" to the SIP header URI.
Value Range	<ul style="list-style-type: none"> • Y (Add Transport UDP) • N (Do not add Transport UDP)
Default Value	N

ADD_EXPIRES_HEADER

Value Format	Boolean
Description	Specifies whether to add an "Expires" header to REGISTER (adds an "expires" parameter to the "Contact" header).
Value Range	<ul style="list-style-type: none"> • Y (Add Expires Header) • N (Do not add Expires Header)
Default Value	Y

SIP_HOLD_HOLDRECEIVE

Value Format	Boolean
---------------------	---------

4.6.2 SIP Settings

Description	Specifies whether to allow re-INVITE for calls on hold.
Value Range	<ul style="list-style-type: none">• Y (Enable SIP Hold Receive)• N (Disable SIP Hold Receive)
Default Value	Y

SIP_ADD_DIVERSION

Value Format	Integer
Description	Specifies whether to add Diversion header information.
Value Range	<ul style="list-style-type: none">– 0: Do not add Diversion header information– 1: Use own diversion information only for the Diversion header– 2: Add diversion information to existing Diversion header
Default Value	1

SIP_RESPONSE_CODE_DND

Value Format	Integer
Description	Selects the response code when a call is received in Do Not Disturb mode.
Value Range	400–699
Default Value	403

SIP_RESPONSE_CODE_CALL_REJECT

Value Format	Integer
Description	Selects the response code when a call is rejected.
Value Range	400–699
Default Value	603

SIP_FOVR_MODE

Value Format	Boolean
Description	Specifies whether INVITE/SUBSCRIBE will follow the REGISTER Failover result.
Value Range	<ul style="list-style-type: none">• Y (INVITE/SUBSCRIBE will follow the REGISTER Failover result.)• N (INVITE/SUBSCRIBE will not follow the REGISTER Failover result.)
Default Value	N

SIP_FOVR_DURATION

Value Format	Integer
Description	Specifies the number of transmission times for the REGISTER method at the Failover destination.
Value Range	0–10
Default Value	0

SIP_403_REG_SUB_RTX

Value Format	Boolean
Description	Specifies whether or not to send a request when a "403 Forbidden" reply is received from the server in response to an INVITE or SUBSCRIBE.
Value Range	<ul style="list-style-type: none"> • y (Send) • n (Do not send)
Default Value	n

CSL_PC_LISTEN_PORT

Value Format	Integer
Description	Specifies the port number of the CS Maintenance Tool.
Value Range	1024–49151
Default Value	1102

4.6.2 SIP Settings

Section 5


PS Registration

This section provides information about how to register S-PSs to SIP-CSs.

5.1 PS Registration from Web User Interface

This section explains how to register an S-PS via Web user interface programming.

Registering Extension Numbers and Extension Names for S-PSs



1. Log in to the Web user interface for the Super Master CS (→ see **2.1 Web User Interface Programming**).
2. Click the **[System]** tab, and then select **[PS Registration]**.
3. Enter an extension name in **[PS Name]**.
4. Click **[All Save]**.

5. Select [Line1 SIP Setting] or [Line2 SIP Setting].

Note

- Some SIP servers allow only 1 extension number per telephone. For details, refer to your SIP server's documentation.

SIP CS KX-UDS124

Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

System

Web Language Administrator Password Change User Password Web Server Settings Time Setting Time Adjust Settings CS Name Air Settings CS Management Tree Survey CS Monitor PS Registration - PS Settings

SIP Settings - PS [Line 1]

PS Name

Phone Number

SIP Authentication

SIP Source Port

All Save Cancel

- Enter the **[Phone Number]**, and enter **[Authentication ID]** and **[Authentication Password]** if necessary.
- Click **[All Save]**.
- Click **[Back]**.
- Repeat steps 3 to 8 for each S-PS.

Note

- If the S-PS name is too long to display, the end of the name may not be displayed on the S-PS's standby screen.

Starting Registration Mode

After you have configured the S-PS name and SIP settings, follow the procedure below to register S-PSs.

SIP CS KX-UDS124

Status Network System VoIP Telephone Maintenance

Web Logout Web Port Close

System

Web Language Administrator Password Change User Password Web Server Settings Time Setting Time Adjust Settings CS Name Air Settings CS Management Tree Survey CS Monitor PS Registration - PS Settings

PS Registration - Start PS Registration

PS Lists

Available PS
1 PanaTaro001

Selected PS

>> > < <<

Next Cancel

5.1 PS Registration from Web User Interface

1. Click the [System] tab, click [PS Registration], and then click [Start PS Registration].
2. Select the S-PSs to be registered in [Available PS], and then click . To select all available S-PSs, click . To deselect S-PS(s), click or .
3. Click [Next].
4. Click [OK] to confirm registration.

Registering S-PSs

After entering PS Registration mode, follow the procedure below to register each S-PS.


For unregistered S-PSs

1. Display the standby screen below.



*1 The symbol for the center soft key (Menu) differs depending on the country/area.

2. Hold down until "Please wait..." is displayed.




3. When registration has completed, "Registered" will be displayed.




For registered S-PSs

1. Enter the "Setting Handset" menu (→ see **Opening the Web Port** in **2.1.1 Before Accessing the Web User Interface**).
2. Select "System Option" and then press .




3. Select "Register H/S" and then press **OK**.



4. Select a base number and then press **OK**.

Note

- You can register four separate bases on your S-PS.



5. Hold down **OK** until "Please wait..." is displayed.



6. When registration has completed, "Registered" will be displayed.



Note

- You can register multiple S-PSs continuously. However, PS Registration mode will terminate if no registrations are detected within 2 minutes. All SIP-CSs controlled by the Super Master CS will enter PS Registration mode at the same time as the Super Master CS. You can register an S-PS to any of the SIP-CSs.
- When registering multiple S-PSs, perform the registration procedure on each S-PS individually. Performing the registration procedure on multiple S-PSs at the same time may result in an error. In this case, reperform the registration procedure.
- After registering S-PSs, the Web port will be closed (→ see **Opening the Web Port** in **2.1.1 Before Accessing the Web User Interface**).
- After registering S-PSs, S-PS firmware update may start automatically. During the firmware update, the S-PS may reboot up to 3 times. Therefore, you should not remove the battery/batteries of the S-PS.

5.1 PS Registration from Web User Interface

Checking Progress

You can check registration progress on the [PS Registration] screen.


The screenshot shows the Panasonic SIP CS KX-UDS124 web interface. The top navigation bar includes links for Web Logout, Web Port Close, Status, Network, System (highlighted in blue), VoIP, Telephone, and Maintenance. The main content area has a title "PS Registration" with a message "PS Registration Complete". A sub-section titled "PS Registration" contains instructions to push the "Stop PS Registration" button to stop the process. Below this is a "PS Registration Delete" section with a "Delete PS Registration" button. The main table, titled "PS Name / Number", lists five entries:

No.	PS Name	Select Button	Phone Number	Wireless Status
1	PanaTaro001	<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>	1000	Registered
2		<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>		Un Registered
3		<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>		Un Registered
4		<input type="button" value="Line1 SIP Setting"/> <input type="button" value="Line2 SIP Setting"/>		Un Registered
5		<input type="button" value="Line1 SIP Setting"/>		Un Registered

If "Trying" is displayed on the left of the screen, you can check the registration status of each S-PS in the [Wireless Status] field. If "PS Registration Complete" is displayed on the left of the screen, all S-PSs that selected for registration were registered successfully.

Unregistering S-PSs

If you want to unregister a specified S-PS, follow the procedure below.




1. Click the [System] tab, click [PS Registration], and then click [Delete PS Registration].
2. Select the S-PSs to be unregistered in [Available PS], and then click . To select all available S-PSs, click . To deselect S-PS(s), click or .
3. Click [Next].
4. Click [OK] to confirm unregistration.

Unregistering a Base System from the S-PS

If the S-PS was outside the coverage area or was turned off when the above-mentioned unregistration procedure was performed, you must unregister the base system manually.

1. Enter the "Setting Handset" menu.
2. Select "System Option" and then press .



3. Select "Cancel Base" and then press .




5.2 PS Registration using Provisioning

4. Select the base number for unregistration by pressing **V**, and then press **OK**.

Note


- You can select multiple base numbers for unregistration if necessary.



5. Select "Yes" and then press **OK**.



When unregistration has completed, "Deleted" will be displayed.



5.2 PS Registration using Provisioning

This section shows how to register the S-PS via configuration file programming.

You must prepare a configuration file (e.g., UserAccount.cfg) for each user account, as follows:

```
# Panasonic SIP Phone Standard Format File # DO NOT CHANGE THIS LINE!  
  
# Setting for PS1  
# 12 digits IPEI code for registering PS  
IPEI_PS1="123456789012"  
# Line1 Setting  
PHONE_NUMBER_PS1_1="3331231"  
SIP_AUTHID_PS1_1="userid1"  
SIP_PASS_PS1_1="userpass1"  
# Line2 Setting  
PHONE_NUMBER_PS1_2="3331232"  
SIP_AUTHID_PS1_2="userid2"
```


The IPEI code is a unique number throughout the world. Therefore, you can register S-PSs remotely by stating the IPEI in a configuration file.

After the above configuration file is provisioned, all SIP-CSs enter PS Registration mode until the specified S-PS registration is performed.

You can confirm the IPEI code of your S-PS either from the label of its package or via the S-PS's system option menu.

Confirming the S-PS's IPEI code

1. Enter the "Setting Handset" menu (→ see Opening the Web Port in 2.1.1 Before Accessing the Web User Interface).
2. Select "System Option" and then press **OK**.



3. Select "H/S Information" and then press **OK**.



4. Confirm the IPEI code (lower item).



5.2 PS Registration using Provisioning

Section 6

Useful Telephone Functions

This section describes various phone number settings, such as copying the phone number settings dial plan, and the phonebook import/export function.

6.1 Phonebook Import and Export

This section explains how to import and export phonebook data. S-PS phonebook data includes names and phone numbers.


Phonebook data on the S-PS can be exported, edited with editor tools, and imported again. In addition, phonebook data created with other software can be imported into the S-PS.

You can use the phonebook import and export functions as follows.

Editing Phonebook Data on a PC

The phonebook data stored on the S-PS can be edited using a program such as Microsoft Excel® spreadsheet software. For details about the operation, see [6.1.2 Editing with Microsoft Excel](#).

You can export the phonebook data to the PC, edit the exported file using appropriate software, and then import it into the S-PS.




Importing Address Book Data from a PC

You can import address book data stored in programs, such as Microsoft Outlook® messaging and collaboration client, into the S-PS.


First, export address book data from the e-mail software to a program such as Microsoft Excel, edit it as necessary, and then import the exported data into the S-PS.

For details about the operation, see [6.1.3 Exporting Data from Microsoft Outlook](#).




Backing up Phonebook Data

You can export the phonebook data from the S-PS to a PC and keep the file as a backup in case of data loss or for use when exchanging the S-PS.




Importing the Same Phonebook Data to other S-PSs

You can export the phonebook data created on an S-PS to a PC, and then import it into other S-PSs.



You can also import phonebook data created on a PC to other S-PSs.



Import/Export File Format


The file format used for importing and exporting the phonebook data is "TSV". When importing or exporting using Microsoft Excel, "CSV (Comma-separated Value)" is generally used as the file format.

A phonebook entry in the S-PS has 9 fields. An entry in the phonebook data is represented in text as "reserved <TAB> name <TAB> reserved <TAB> phone number <TAB> reserved <line break>".

The text data can be edited using any text editing software that supports UTF-16 encoding with a BOM and little endian byte ordering. When you save the text file, it must be saved using the same format, or the text might become garbled.

6.1.1 Import/Export Operation

Phonebook Data in Text Format



- ① Reserved for KX-NS1000 System Phonebook Download
- ② Tab
- ③ Name (up to 24 characters)
- ④ Tab
- ⑤ Reserved
- ⑥ Tab
- ⑦ Phone number (up to 32 digits)
- ⑧ Tab
- ⑨ Phone number (up to 32 digits)
- ⑩ Tab
- ⑪ Phone number (up to 32 digits)
- ⑫ Tab
- ⑬ Phone number (up to 32 digits)
- ⑭ Tab
- ⑮ Phone number (up to 32 digits)
- ⑯ Tab
- ⑰ Reserved

6.1.1 Import/Export Operation

The following procedures explain how to import phonebook data to S-PSs, and how to export phonebook data from S-PSs to a PC through the Web user interface.

For details about the settings, see [2.6.10 Import Phonebook - All](#), [2.6.11 Import Phonebook - PS](#) or [2.6.13 Export Phonebook - PS](#).

To import phonebook data to all S-PSs immediately

1. Click the [Telephone] tab, and then click [Import Phonebook].
2. Click [All] to select all S-PSs.
3. Select [Direct] for [Import Mode].
4. In [File Name], enter the full path to the file that you want to import, or click [Browse] to select the phonebook data file that you want to import.
5. Click [All Import].

To import phonebook data to all S-PSs at a set time

1. Click the [Telephone] tab, and then click [Import Phonebook].
2. Click [All] to select all S-PSs.
3. Select [Appoint Date/Time] for [Import Mode].
4. Input [Date] and [Time] for [Import Time Setting].

5. In **[File Name]**, enter the full path to the file that you want to import, or click **[Browse]** to select the phonebook data file that you want to import.
6. Click **[All Import]**.

To import phonebook data to one S-PS

1. Click the **[Telephone]** tab, and then click **[Import Phonebook]**.
2. Click a numbered tab to find the appropriate S-PS, and then click **[Import Phonebook]** for that S-PS.
3. In **[File Name]**, enter the full path to the file that you want to import, or click **[Browse]** to select the phonebook data file that you want to import.
4. Click **[Import]**.

To export the phonebook data from an S-PS

1. Click the **[Telephone]** tab, and then click **[Export Phonebook]**.
2. Click a numbered tab to find the appropriate S-PS, and then click **[Export Phonebook]** for that S-PS.
3. Click **[Export]**.
4. On the "Now Processing File Data" screen, click the text "HERE" in the displayed message, or wait until **File Download** window appears.

Note

- Depending on the security settings of your Web browser, pop-up menus might be blocked. If the file cannot be exported successfully, try the export operation again or change the security settings of your Web browser.
5. Click **[Save]** on **File Download** window.
 6. On the **Save As** window, select a folder to save the exported phonebook data to, enter the file name in **File name**, select **TSV File** for **Save as type**, and click **Save**.
If the file is downloaded successfully, the **Download complete** window appears.
 7. Click **Close**.
 8. To exit the operation, click the text "HERE" in the displayed message.
The **[Export Phonebook]** screen returns.

Note

- Make sure that the import source or destination S-PS is in standby mode.
- The phonebook for an S-PS has the following limitations:
 - A maximum of 500 phone numbers can be stored in the S-PS. If the S-PS already has phonebook data, it accepts up to the 500th number, including the existing numbers. The rest of the numbers will not be imported.
 - The name can contain up to 24 characters.
 - The phone number can contain up to 32 digits.
 - Phonebook entries exceeding the characters or digits limits cannot be imported properly.
- If the export is interrupted by an operation on the SIP-CS/S-PS, only the data that has been successfully exported before the interruption is exported to a file.
- When an incoming call arrives at an S-PS which is importing/exporting phonebook data, the S-PS does not ring and the call is not displayed. However, the call is stored in the incoming call log.

6.1.2 Editing with Microsoft Excel

You can edit exported phonebook data on a PC with software such as Microsoft Excel. You can then import the phonebook data into S-PSs.

To open the phonebook data on a PC

1. Open Microsoft Excel.


6.1.2 Editing with Microsoft Excel

2. Click **Office Button**, and then **Open**.


Note

- Make sure to open a TSV file in this procedure. If you change the extension of a TSV file to ".csv", the file will open by simply double-clicking it. However, the character encoding of the file might not be recognized properly, resulting in garbled characters, or the phone numbers might be recognized as numbers, resulting in data alteration.

3. Select **All Files** for the file type, select the exported phonebook data file, and click **Open**.




4. On the **Text Import Wizard - Step 1 of 3** window, click **Next**.



Note


- Regardless of what is selected for **File origin**, the file will be processed normally if the format is appropriate.

5. On the **Text Import Wizard - Step 2 of 3** window, select **Tab** for **Delimiters**, and then click **Next**.



6. On the **Text Import Wizard - Step 3 of 3** window, select all columns in **Data preview**, select **Text** in **Column data format**, and then click **Finish**.

The TSV file will be opened.



Note

- Phone numbers must be treated as text strings. Otherwise, a "0" at the beginning of a phone number might disappear when exported.

To save the phonebook data for importing to the S-PS

1. After editing the phonebook entries, click **Office Button**, and then **Save As**.
2. Enter a file name in **File name**, and select **Unicode Text** in **Save as type**.
The file will be saved in UTF-16 little endian with a BOM. Fields will be separated by tabs.
3. Click **Save**.
A message warning you about file compatibility will be displayed.
4. Click **Yes**.
The file will be saved as a Unicode text file, with the fields separated by tabs.

Note

- The procedure may vary depending on the software version of Microsoft Excel. Therefore, files exported and imported between the S-PS and Microsoft Excel are not always compatible with each other.
- For KX-NS1000 users, if you find numbers in the first column of the exported TSV record data, they are records downloaded from the KX-NS1000 System Phonebook. These files are updated through the KX-NS1000 automatically so do not modify this data.

- For KX-NS1000 users, after importing a phonebook TSV file containing KX-NS1000 System Phonebook records in the first column, the previous System Phonebook records are deleted from the S-PSs.

6.1.3 Exporting Data from Microsoft Outlook

You can export address book data stored in programs such as Microsoft Outlook, and then edit the exported data with a program such as Microsoft Excel in order to import it to the S-PS.

To export the Microsoft Outlook address book data

1. In Microsoft Outlook, click **File**, and then click **Import and Export**.
2. Select **Export to a file**, and click **Next**.
3. Select **Tab Separated Values (Windows)**, and click **Next**.
4. Select **Contacts**, and click **Next**.
5. Click **Browse**, select a folder, and then enter the file name to export the data to.
6. Click **OK**.
7. On the **Export to a File** window, click **Next**.
8. Click **Map Custom Fields**.
9. Clear all items in the **To** list by clicking **Clear Map**. Then, drag only **Last Name** and **Business Phone** from the **From** list to the **To** list, and click **OK**.
10. On the **Export to a File** window, click **Finish**.

The data will be exported.

Note


- You can export data from Microsoft Outlook Express by using a similar procedure. It is also possible to export data from other applications that are compatible with Microsoft Excel.
- You can open the exported file in Microsoft Excel, and then import it to the S-PS. For details, see [6.1.2 Editing with Microsoft Excel](#).
- First and middle names are not exported using this procedure. You can export all necessary items and edit the entry before importing them to the S-PS.
- In the file exported from Microsoft Outlook, fields are separated by tabs and encoded using the default character encoding for your operating system.

6.2 Dial Plan

The dial plan settings control how numbers dialed by the user are transmitted over the network. Dial plan settings can be configured for each S-PS. These settings can be programmed either through the Web user interface (→ see [2.6.3.3 Dial Plan](#)) or by configuration file programming (→ see [4.6.1 Call Control Settings](#)).

[Dial Plan Flowchart]

When a user dials a single digit on an S-PS, the following sequence of events begins.



6.2.1 Dial Plan Settings

To set Dial Plan

1. In the Web user interface, click the **[Telephone]** tab, and then click **[Call Control]**.
 2. Click a numbered tab to find the appropriate S-PS, and then click **[PS Call Control]** for that S-PS.
 3. In **[Dial Plan]**, enter the desired dial format.
- The dial plan settings can be configured for each S-PS.

6.2.1 Dial Plan Settings

For details about available characters for the dial format, see **Available Values for the Dial Plan Field** in this section.

4. Select **[Yes]** or **[No]** for **[Call Even If Dial Plan Does Not Match]**.

- If you select **[Yes]**, the call will be made even if the user dials a phone number that does not match the dial format in **[Dial Plan]**.
- If you select **[No]**, the call will be made only if the user dials a phone number that matches the dial format in **[Dial Plan]**.

Note

- For details about configuring these settings by configuration file programming, see "**DIAL_PLAN**" and "**DIAL_PLAN_NOT_MATCH_ENABLE**" in **4.6.1 Call Control Settings**.

Available Values for the Dial Plan Field

The following table explains which characters you can use in the dial format, and what the characters mean.

Element	Available Value	Description
String	0–9, [, - ,] , < , : , > , * , # , ! , S , s , T , t , X , x , . , , +	You can enter dial plan descriptions using a combination of the characters listed as available values.
Digit	0–9, *, #, +	Example: "123" If the dialed phone number is "123", the call is made immediately.
Wildcard	X, x	Example: "12xxxxx" If the dialed phone number is "12" followed by any 5-digit number, the call is made immediately.
Range	[]	Example: "[123]" If the dialed phone number is either one of "1", "2", or "3", the call is made immediately.
Subrange	-	Example: "[1-5]" If the dialed phone number is "1", "2", "3", "4", or "5", the call is made immediately. <ul style="list-style-type: none">• A subrange is only valid for single-digit numbers. For example, "[4-9]" is valid, but "[12-21]" is invalid.
Repeat	.	Example: "1." If the dialed phone number is "1" followed by zero or more "1"s (e.g., "11", "111"), the call is made.
Substitution	<(before):(after)>	Example: "<101:9999>" If the dialed phone number is "101", "101" is replaced by "9999", and then the call is made immediately.
Timer	S, s (second)	Example: "1x.S2" If the dialed phone number begins with "1", the call is made after a lapse of 2 seconds. <ul style="list-style-type: none">• The number (0–9) followed by "S" or "s" shows the duration in seconds until the call is made.

Element	Available Value	Description
Macro Timer	T, t	Example: "1x.T" If the dialed phone number begins with "1", the call is made after a lapse of "T" seconds. <ul style="list-style-type: none"> The value of "T" or "t" can be configured through the Web user interface (→ see [Timer for Dial Plan] in 2.6.1.1 Call Control).
Reject	!	Example: "123xxx!" If the dialed phone number is "123" followed by 3 digits, the call is not made.
Alternation		Example: "1xxxx 2xxx" If the dialed phone number is "1" followed by 4 digits, or "2" followed by 3 digits, the call is made immediately. You can use this element to specify multiple numbers.

Note

- You can enter up to 500 characters in **[Dial Plan]**.
- You can assign up to 40 dial plans separated by "|" in **[Dial Plan]**.
- You can assign up to 32 digits per dial plan in **[Dial Plan]**.
- After the user completes dialing, the S-PS immediately sends all the dialed digits if **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]** in the Web user interface or if "**DIAL_PLAN_NOT_MATCH_ENABLE**" is set to "**N**" in a configuration file. The S-PS recognizes the end of dialing as follows:
 - The inter-digit timer expires (→ see **[Inter-digit Timeout]** in **2.6.1.1 Call Control** in the Web user interface or "**INTDIGIT_TIM**" in **4.4.1 Call Control Settings** in the configuration file).
 - The user presses the # key.
 - The call is initiated after going off-hook (pre-dial).

Dial Plan Example

The following example shows dial plans containing character sequences separated by "|".
 Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

Complete Match:

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "211", "911" and so on, the call is made immediately.

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "2123456789", "5987654321" and so on, the call is made immediately.

Partial Match (when the dial plan contains "."):

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "01254", "012556" and so on, the call is made after the inter-digit timer expires.

Partial Match (when the dial plan does not contain "."):

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "21", "91" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]**, the call is made after the inter-digit timer expires.
- If the dialed phone number is "21", "91" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[No]**, the call is denied after the inter-digit timer expires.

6.3.1 Flexible Button Settings

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "21234567", "598765432" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]**, the call is made after the inter-digit timer expires.
- If the dialed phone number is "21234567", "598765432" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[No]**, the call is denied after the inter-digit timer expires.

No Match:

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "0011", "1011" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]**, the call is made after the inter-digit timer expires.
- If the dialed phone number is "0011", "1011" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[No]**, the call is denied.

6.3 Flexible Buttons

You can customize the flexible buttons on the S-PS. They can then be used to make or receive outside calls or as feature buttons. These settings can be programmed either through the Web user interface (→ see **2.6.6 Button Settings - PS**) or by configuration file programming (→ see **4.4.5 Flexible Button Settings**).

Note

- If the flexible button settings for an S-PS are changed through the Web user interface, the calls via the target S-PS will be disconnected.
- This feature may not be supported on your phone system.

The following types of flexible buttons are available:

Button	Description	Lamp Indication
DN	<p>Used to seize the line assigned to the DN (Directory Number) button. When a call arrives at the DN button, pressing the button answers the call.</p> <p>Notice</p> <ul style="list-style-type: none">• At least 2 DN buttons must be assigned to each line. If DN buttons are not assigned, calls cannot be made or answered. <p>Note</p> <ul style="list-style-type: none">• The shared line (shared call) feature is an optional feature and may not be supported on your phone system.	<p>Off: Idle Green on: The extension is on a call using the DN button. Flashing green rapidly: The DN extension is receiving an incoming call. Flashing green slowly: A call is on hold at the DN extension. Red on: A shared line is in use or on hold (private). Flashing red slowly: A shared line is on hold (normal).</p>
One-Touch	Used to access a desired party or system feature using the One-Touch Dialing feature.	—

6.3.1 Flexible Button Settings

To set Flexible Buttons

1. In the Web user interface, click the **[Telephone]** tab, and then click **[Button Settings]**.
2. Click a numbered tab to find the appropriate S-PS, and then click **[Button Settings]** for that S-PS.

3. Enter settings as described in the following table.

When it is necessary to set both parameter 1 and parameter 2, enter a comma between the values.

Button	Parameter 1		Parameter 2	
	Description	Value	Description	Value
DN	Ringtone ^{*1}	(1–32)	Line No.	1–2
One-Touch	Phone Number	Up to 32 digits	–	–

^{*1} S-PSs do not support this feature. However, a value must be set before the comma when configuring a DN button.

Note

- For details about configuring these settings by configuration file programming, see **4.4.5 Flexible Button Settings**.

[Setting Example]

The following screen shows an example of setting flexible buttons.

The screenshot shows the 'Flexible Button Settings' page of the Panasonic SIP CS KX-UDS124 web interface. The left sidebar has a 'Telephone' section with 'Call Control', 'Button Settings', 'Tone Settings', 'Telephone Settings', 'Import Phonebook', and 'Export Phonebook'. The main area has a 'PS Name' field set to '001' and a 'Back' button. Below is a table with 12 rows:

No.	Type	Parameter	Label Name
1.	DN	1,1	DN1
2.	DN	1,1	DN1
3.	DN	1,1	DN1
4.	DN	1,1	DN1
5.	DN	2,2	DN2
6.	DN	2,2	DN2
7.	DN	2,2	DN2
8.	DN	2,2	DN2
9.	One-Touch	0123456789	Office
10.	One-Touch	1112233333	Office 2
11.	One-Touch	012343333	Home
12.	One-Touch	0123232323	Home 2

At the bottom are 'All Save' and 'Cancel' buttons.

Description:

- Buttons 1, 2, 3 and 4 are set to make/receive calls on line 1.
- Buttons 5, 6, 7 and 8 are set to make/receive calls on line 2.
- Buttons 9, 10, 11 and 12 are set to make calls to a certain destination using the One-Touch Dialing feature.

6.4 Copying Flexible Button Settings to Other S-PSs

You can copy the flexible button settings that you have customized for an S-PS and apply them to other S-PSs through the Web user interface programming. For details about the settings, see **2.6.7 Button Settings - Copy & Paste**.

To copy the source settings to the desired S-PS

1. In the Web user interface, click the [Telephone] tab, and then click [Button Settings].
The [Button Settings] screen appears.
2. Click a numbered tab to find the S-PS whose settings you want to copy, and then click [Copy & Paste] for that S-PS.
The [Button Settings - Copy & Paste] screen appears.
3. Select the S-PSs to have settings copied to in [Available PS], and then click . To select all available S-PSs, click . To deselect S-PS(s), click or .
4. Click [Copy & Paste].
The flexible button settings will be applied to the other S-PS(s).

Section 7

Firmware Update

This section explains how to update the firmware of the SIP-CSs/S-PSs.

7.1 Firmware Update Overview

You can update the firmware of both SIP-CSs and S-PSs.

The updating mechanism is different depending on whether you are using configuration file programming or Web user interface programming.

Updating SIP-CS Firmware

Web user interface programming

After you upgrade the firmware of the Super Master CS, the Super Master CS distributes the firmware to all other Master CSs, and then the Master CSs distribute the firmware to all Slave CSs.

The update timing can be programmable via Web user interface programming.

Configuration file programming

After a configuration file that includes firmware update information is acquired by the Super Master CS, configuration information is distributed to all other SIP-CSs.

After that, each SIP-CS will acquire the firmware file to update individually.

The SIP-CS will reboot if the firmware is updated successfully.

Updating S-PS Firmware

The downloaded firmware file consists of SIP-CS firmware and S-PS firmware. These two kinds of firmware are combined into one file.

Firmware Update File

SIP-CS Firmware
S-PS Firmware

After the SIP-CS's firmware is updated, the S-PS will update its firmware wirelessly if the firmware version is different from current version.

The S-PS will reboot if the firmware is updated successfully.

7.2 Firmware Server Setup

No special server is necessary for the firmware update. You can use an HTTP, HTTPS, FTP, or TFTP server as the firmware server by simply setting its URL.

7.3 Firmware Update Settings

Firmware updates are provided by the manufacturer when necessary.

The firmware update will be executed by setting the corresponding parameters using configuration file programming (→ see **4.2.4 Firmware Update Settings**) or Web user interface programming (→ see **2.7.3 Firmware Maintenance**).

Note

- After firmware updates are complete for the SIP-CSs, the newer firmware will be applied to the S-PSs.
- If the firmware version of an S-PS is older, the firmware updates for the S-PS will be executed to register to the SIP-CS.
- If you are using a language other than English, the display language may unexpectedly change to English during an S-PS firmware update. One of the following messages may be displayed:

Displayed Message	Description
<ERASING>	Data is being erased.
<WRITING>	Data is being written.
<WRITE OK>	Data writing was successful.
<ERROR 1>	A deletion error occurred.
<ERROR 2>	A writing error occurred.
<Charge Battery>	Charge the S-PS's battery.

- When executing firmware updates for the S-PSs, make sure of the following:
 - The target S-PSs are on the charger with the power ON.
 - The S-PSs' batteries have enough charge remaining (or is recommended).
 - The S-PSs are located where the radio signal is strong (or is recommended).
 - The S-PSs are in standby mode.
- If automatic update is enabled and the S-PS firmware update does not start automatically after the SIP-CS firmware update, turn the S-PS off and on.

The following shows the parameters and the setting procedures:

Firmware Update Enable/Disable

- In a configuration file, add the line, `FIRM_UPGRADE_ENABLE="Y"`.
- In the Web user interface, click the **[Maintenance]** tab, click **[Firmware Maintenance]**, and then select **[Yes]** for **[Enable Firmware Update]**.

Firmware Version Number

- In a configuration file, specify the new version number in `"FIRM_VERSION"`.

Automatic Update

- In a configuration file, add the line, `PS_FIRM_UPGRADE_AUTO="Y"`.

7.4 Executing Firmware Update

- In the Web user interface, click the [Maintenance] tab, click [Firmware Maintenance], and then select [Automatic] for [PS Update Type].

Firmware Server URL

- In a configuration file, specify the URL in "FIRM_FILE_PATH".
- In the Web user interface, click the [Maintenance] tab, click [Firmware Maintenance], and then enter the URL in [Firmware File URL].

Configuration Parameter Example


By setting the parameters as shown in the following example, the SIP-CS will automatically download the firmware file from the specified URL, "http://firm.example.com/firm/01.050.fw", and perform the update operation if the currently used firmware version is older than 01.050.

Example

```
FIRM_UPGRADE_ENABLE="Y"  
FIRM_VERSION="01.050"  
PS_FIRM_UPGRADE_AUTO="Y"  
FIRM_FILE_PATH="http://firm.example.com/firm/01.050.fw"
```

7.4 Executing Firmware Update

After configuring the firmware update settings for the Super Master CS in the configuration file, the Super Master CS distributes configuration information to all other SIP-CSs. The firmware of each SIP-CS is updated when it receives the configuration information. The firmware update procedure of each SIP-CS is detailed below.




The firmware update process of each SIP-CS

Step 1

The SIP-CS downloads a configuration file from the provisioning server.


- For details about setting the timing of when configuration files are downloaded, see [3.2.4 Downloading Configuration Files](#).



Step 2


The SIP-CS compares the version number of the firmware in the configuration file to the SIP-CS's current firmware version.

(In this example, the SIP-CS is using version 01.000 and the configuration file specifies version 01.050.)




Step 3

When a newer firmware version is specified in the configuration file, the SIP-CS will download the firmware from the address specified under "`FIRM_FILE_PATH`" in the configuration file.



Step 4

Once the newer firmware is downloaded, it is applied to the SIP-CS and the SIP-CS automatically restarts.



Step 5

The firmware updates for the S-PSs will be executed.


7.5 Local Firmware Update

When an updated version of the firmware is provided on a Web site or other means, you can perform the firmware update manually using Web user interface programming.

After the firmware is uploaded to the Super Master CS, the Super Master CS distributes the firmware to all other SIP-CSs.

7.5 Local Firmware Update

For details about the local firmware update, see [2.7.4 All Firmware Update](#).



To manually update the firmware immediately

1. Click the [Maintenance] tab, and then click [All Firmware Update].
2. Select [Direct] for [Update Mode].
3. Click [Browse], select the folder where the firmware file is stored, and specify the firmware file on your PC.
4. Click [All Update Firmware].

To manually update the firmware at a set time

1. Click the [Maintenance] tab, and then click [All Firmware Update].
2. Select [Appoint Date/Time] for [Update Mode].
3. Input [Date] and [Time] for [Import Time Setting].
4. Click [Browse], select the folder where the firmware file is stored, and specify the firmware file on your PC.
5. Click [All Update Firmware].

Section 8

How to Backup and Restore Configurations

This section provides information about how to backup and restore Super Master CS configurations.

8.1 How to back up and restore configuration data

It is recommended to keep a backup of Super Master CS configuration data.

The backup data is useful when restoring the same configuration data to the Super Master CS when it must be re-installed due to a hardware error, etc.

The following data can be backed up and restored:

- Standard configuration data
- Product configuration data
- Master configuration data
- System configuration data
- Web settings
- Internal management data (e.g., Air Sync settings, PS registration settings, telephone parameters, etc)

Notice

The following data cannot be backed up or restored:


- Logs
- Pre-provisioning data
- Certifications

Note

- If the firmware version of the Super Master CS differs from that of the backup data, you cannot restore the configuration data.


Follow the procedure below to back up and restore the configuration data of SIP-CSs via the Web user interface.

Backing up configuration data



1. Log in to the Super Master CS as the administrator.
2. In the [**Maintenance**] tab, select [**Backup**].
3. Click [**Backup**] for [**Export CS Backup File**].
4. On the [**Save As**] window, select a folder to save the backup data to, enter the file name in [**File name**] and click [**Save**].

Restoring the configuration data



1. While the SIP-CS is on, press the RESET switch on the back of the SIP-CS for about 10 seconds. For details, see **9.1 Resetting to Factory Default**.
2. Log in to the Super Master CS as the administrator.
3. In the **[Maintenance]** tab, select **[Restore]**.
4. In **[File Name]**, enter the full path to the file that you want to import, or click **[Browse]** to select the configuration or settings file that you want to restore.
5. Click **[Restore]**.

Note

- If the unit's firmware version changes between backup and restore, the data may not be restored. For details, refer to "Failed (Firmware Version Mismatch)" in **Result Messages** in **2.1.3 Web User Interface Setting List**.
- If the Web settings were changed after the backup file was created, the S-PSs near the restored Super Master CS will function according to older Web settings. To use the most recent settings, log in to the Web user interface for the Super Master CS and reconfigure the settings.

8.1 How to back up and restore configuration data

Section 9

Resetting to Factory Default

This section provides information about the procedure to reset the settings in the SIP-CS to their factory defaults.


9.1 Resetting to Factory Default

This procedure resets all settings in the SIP-CS to their factory defaults.

This type of initialization also deletes all other data on the SIP-CS, such as the call logs and the phonebook.

To perform this initialization, follow the procedure below:

1. Press the RESET switch on the back of the SIP-CS for about 10 seconds.



Notice

- After performing this procedure, the SIP-CS will restart automatically. To avoid problems, it is recommended that you save your settings beforehand.

Section 10

Troubleshooting

This section provides information about troubleshooting.

10.1 Troubleshooting

Status indicator

Status	Problem	Cause/Solution
Off	The unit is not receiving power.	The unit is not designed to function when there is a power failure. Make sure that the device supplying PoE is receiving power and that the Ethernet cable is properly connected. If an AC adaptor is connected, confirm that the AC adaptor is connected and receiving power.
Red on	Device error	Consult your dealer.
Red flashing rapidly	<ul style="list-style-type: none"> • A network failure occurred during startup. • The SIP-CS could not register with the SIP server on startup. 	<ul style="list-style-type: none"> • Check network settings. • Check that settings are correct for registration to the SIP server.
Red flashing	The SIP-CS is waiting for air synchronization.	<p>If this state continues for a while, check the CS monitor screen in the Web user interface.</p> <ol style="list-style-type: none"> 1. Click the [System] tab, and then click [CS Monitor]. 2. Select [Air Sync Group]. 3. Check the CS monitor screen.
Amber on	An air synchronization error has occurred.	<p>Check the CS monitor screen in the Web user interface.</p> <ol style="list-style-type: none"> 1. Click the [System] tab, and then click [CS Monitor]. 2. Select [Air Sync Group]. 3. Check the CS monitor screen.
Amber flashing	An air synchronization error has occurred (while an S-PS is in use).	<p>Check the CS monitor screen in the Web user interface.</p> <ol style="list-style-type: none"> 1. Click the [System] tab, and then click [CS Monitor]. 2. Select [Air Sync Group]. 3. Check the CS monitor screen.
Amber flashing rapidly	An air synchronization error has occurred and the SIP-CS is in a busy state.	<p>Check the CS monitor screen in the Web user interface.</p> <ol style="list-style-type: none"> 1. Click the [System] tab, and then click [CS Monitor]. 2. Select [Air Sync Group]. 3. Check the CS monitor screen.
Green on	Normal	—
Green flashing	Normal (while an S-PS is in use)	—
Green flashing rapidly	The SIP-CS is in a busy state.	If users frequently experience busy conditions, put an additional cell station near the frequently busy cell station. ¹

¹ When a user makes a call and the cell station is busy, the user sees the message "CS Busy" on the S-PS's display.

Password for Web User Interface Programming

Problem	Cause/Solution
I have lost the login password of the Web user interface for the Administrator or User account.	<ul style="list-style-type: none"> Reset the password from the SIP-CS. The passwords for both Administrator and User will be reset (→ see Section 9 Resetting to Factory Default). For security reasons, it is recommended that the passwords are set again immediately (→ see 2.4.2 Administrator Password).

Time

Problem	Cause/Solution
The time is not correct.	<ul style="list-style-type: none"> In the Web user interface, you can set NTP synchronization and DST (Summer Time) control to adjust the time automatically (→ see 2.4.6 Time Adjust Settings). If the time is still incorrect even after setting NTP synchronization, check the firewall and port forwarding settings on the router.

Checking the Status of the SIP-CS

You can check the status of the SIP-CS by using Web user interface programming (→ see **2.2.2 Network Status** and **2.2.6 PS VoIP Status**) or by looking at system logs (→ see **4.2.3 Syslog Settings**) sent from the SIP-CS.

To check the setting status in the Web user interface

1. Click the **[Status]** tab, and then click **[Network Status]** to check the network settings.
2. Check the status displayed.
3. Click **[PS VoIP Status]** to check the VoIP settings.
4. Click a numbered tab to check the status of the desired S-PS.

To send the system logs of specified events to the syslog server

1. Set the following parameters to specify your PC (Windows operating system, etc.) as the syslog server:
 - **SYSLOG_ADDR**: Specifies the IP address or FQDN of the syslog server.
 - **SYSLOG_PORT**: Specifies the port number of the syslog server.
2. Set the following parameters to log specific events:
 - **SYSLOG_EVENT_SIP**: Logs SIP-related syslog events.
 - **SYSLOG_EVENT_CFG**: Logs syslog events regarding configuration.
 - **SYSLOG_EVENT_VOIP**: Logs syslog events regarding VoIP operation.

10.1 Troubleshooting

Section 11

Appendix

11.1 Open Source Software

Parts of this product use Open Source Software. Relevant conditions apply to this software. Panasonic cannot accept inquiries regarding the content of the following copyright and license information.

<<NetBSD kernel>>

This product uses a part of NetBSD kernel.

The use of a part of NetBSD kernel is based on the typical BSD style license below.

Copyright (c)

The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:
This product includes software developed by the University of California, Berkeley and its contributors.
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

However, parts of the NetBSD Kernel are provided with the following copyright notices.

Copyright (c) 1980, 1983, 1988, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1980, 1986, 1989, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1980, 1986, 1991, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1980, 1986, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1985, 1986, 1988, 1993, 1994 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1990, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1990, 1993, 1995 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1990, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1991, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1988, 1993, 1995 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1989, 1991, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1989, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1990, 1991, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1990, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1990, 1993, 1994 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1991, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1991, 1993, 1994 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1991, 1993, 1995 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1993 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1993, 1994 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1993, 1994, 1995 The Regents of the University of California. All rights reserved.

Copyright (c) 1982, 1986, 1993, 1995 The Regents of the University of California. All rights reserved.
Copyright (c) 1982, 1988, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1983, 1990, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1983, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1985, 1986, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1985, 1986, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1986, 1989, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1986, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1987, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1987, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1987, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1988 Regents of the University of California. All rights reserved
Copyright (c) 1988 Stephen Deering.
Copyright (c) 1988 University of Utah.
Copyright (c) 1988, 1989, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1988, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1988, 1992, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1988, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1989 The Regents of the University of California. All rights reserved.
Copyright (c) 1989, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1989, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1989, 1993, 1994 The Regents of the University of California. All rights reserved.
Copyright (c) 1990, 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1990, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1991, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1991, 1993, 1994 The Regents of the University of California. All rights reserved.
Copyright (c) 1992 Regents of the University of California. All rights reserved.
Copyright (c) 1992, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1993 Adam Glass
Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.
Copyright (c) 1994 Gordon W. Ross
Copyright (c) 1994 Winning Strategies, Inc. All rights reserved.
Copyright (c) 1995 The Regents of the University of California. All rights reserved.
Copyright (C) 1995, 1996, 1997, and 1998 WIDE Project. All rights reserved.
Copyright (c) 1996 The Regents of the University of California. All rights reserved.
Copyright (c) 1996 John S. Dyson All rights reserved.
Copyright (c) 1996 Matt Thomas. All rights reserved.
Copyright (c) 1996 Matthew R. Green. All rights reserved.
Copyright (c) 1996 Paul Kranenburg
Copyright (c) 1996, 1997, 1999, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1996, 2000 Christopher G. Demetriou. All rights reserved.
Copyright (c) 1996, 1999 by Internet Software Consortium.
Copyright (c) 1996-1999 by Internet Software Consortium.
Copyright (c) 1997 Jonathan Stone and Jason R. Thorpe. All rights reserved.
Copyright (c) 1997 Christos Zoulas. All rights reserved.
Copyright (c) 1997 Manuel Bouyer. All rights reserved.
Copyright (c) 1997, 1998 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 1999, 2000 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 1999, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 2002 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 2000, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1997, 1998, 1998 The NetBSD Foundation, Inc. All rights reserved.
Copyright (C) 1997-2000 Sony Computer Science Laboratories Inc. All rights reserved.
Copyright (c) 1997-2002 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998 Todd C. Miller <Todd.Miller@courtesan.com> All rights reserved.
Copyright (c) 1998, 1999 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998, 1999, 2000 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998, 1999, 2000, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998, 2000 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1998, 2000, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1999 The NetBSD Foundation, Inc. All rights reserved.
Copyright (C) 1999 WIDE Project. All rights reserved.

11.1 Open Source Software

Copyright (c) 1999, 2000 Jason L. Wright (jason@thought.net) All rights reserved.
Copyright (c) 1999, 2000 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1999, 2000, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1999, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2000 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2000, 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2000, 2002 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2002 The NetBSD Foundation, Inc. All rights reserved.
Copyright 1998 Massachusetts Institute of Technology. All rights reserved.
Copyright 2001 Wasabi Systems, Inc. All rights reserved.
Portions Copyright (c) 1993 by Digital Equipment Corporation.
Portions Copyright (c) 1995 by International Business Machines, Inc.
Copyright (c) 1983, 1989 The Regents of the University of California. All rights reserved.
Copyright (c) 1996 by Internet Software Consortium. All rights reserved.
Copyright (c) 1980, 1986, 1989 Regents of the University of California. All rights reserved.
Copyright (c) 1988 The Regents of the University of California. All rights reserved.
Copyright (c) 1992, 1993 The Regents of the University of California. All rights reserved.
Copyright (c) 1994 Christopher G. Demetriou. All rights reserved.
Copyright (c) 1997 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1999 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 2001 The NetBSD Foundation, Inc. All rights reserved.
Copyright (c) 1996 Gardner Buchanan <gbuchanan@shl.com> All rights reserved.
Parts of the NetBSD Kernel are provided with the licenses that are slightly different from the
above Berkeley-formed license. Please refer the source code of the NetBSD Kernel about the details.
The source code of the NetBSD Kernel is provided by the NetBSD CVS Repositories
(<http://cvsweb.netbsd.org/bsdweb.cgi/>), and this product includes parts of the source code in the
following directories.
<http://cvsweb.netbsd.org/bsdweb.cgi/src/sys/kern/>
<http://cvsweb.netbsd.org/bsdweb.cgi/src/sys/net/>
<http://cvsweb.netbsd.org/bsdweb.cgi/src/sys/netinet/>

<<MD5>>
This software uses the Source Code of RSA Data Security, Inc. described in the
RFC1321 (MD5 Message-Digest Algorithm).

Copyright (C) 1991-2, RSA Data Security, Inc. Created 1991. All
rights reserved.

License to copy and use this software is granted provided that it
is identified as the "RSA Data Security, Inc. MD5 Message-Digest
Algorithm" in all material mentioning or referencing this software
or this function.

License is also granted to make and use derivative works provided
that such works are identified as "derived from the RSA Data
Security, Inc. MD5 Message-Digest Algorithm" in all material
mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either
the merchantability of this software or the suitability of this
software for any particular purpose. It is provided "as is"
without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this
documentation and/or software.

<<MT19937>>
The MT19937 software that Takuji Nishimura and Makoto Matsumoto developed
is contained, and this product shall be used subject to the following
license conditions.

Copyright (C) 1997 - 2002, Makoto Matsumoto and Takuji Nishimura,
All rights reserved.

Redistribution and use in source and binary forms, with or without
modification, are permitted provided that the following conditions
are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The names of its contributors may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

<<thttpd>>

The thttpd software that ACME Labs developed is contained, and this product shall be used subject to the following license conditions.

Copyright 1995,1998,1999,2000 by Jef Poskanzer <jef@acme.com>. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

11.2 Revision History

11.2.1 KX-UDS124 Software File Version 01.400

New Contents

- 2.3.5 Network Directory (Page 71)
- 4.3.7 Xsi Server Settings (Page 194)

Changed Contents

- 2.3.1 Basic Network Settings (Page 62)
- 2.3.2 HTTP Client Settings (Page 67)
- 2.3.3 HTTP Authentication (Page 68)
- 2.5.3 SIP Settings - PS [Line 1–2] (Page 104)

Index

A

Access Levels (IDs and Passwords) 22
Administrator Password, setting 73, 167

B

Backup, setting 139

C

Characters Available for String Values 167
Configuration File Programming 165
CS Management 84
CS Monitor 89

D

Dial Plan 260

E

Enable LLDP 65
Encryption 158
Error Log 146
Export Phonebook 137, 254

F

Firmware Update 141, 267
Firmware Update, setting 140, 174
Flexible Button Settings 126, 210, 264
Flexible Button Settings, Copy & Paste 128, 265

H

How to backup and restore configurations 273

I

Import Phonebook 134, 254
Import Phonebook - PS 135
IP Phone (Priority) 66
IP Phone (VLAN ID) 66

L

LLDP Settings 65
LLDP-MED Interval timer 65

M

Maintenance Settings 138

N

Network Settings 61, 186

O

Open Source Software 284

P

Provisioning 147, 152
Provisioning, setting 143, 176

PS Registration 92, 243

R

Recommended Environment 22
Resetting to Factory Default 277
Restart 146
Restore, setting 139
Result Messages 46

S

SIP Settings 96, 222
Status Settings 50
System Settings 72, 167

T

Telephone Settings 112, 195
Terminology 3
Tone Settings 130, 198
Tree Survey, setting 87
Troubleshooting 279

V

VoIP Settings 95, 211

W

Web User Interface Programming 21
Web User Interface Setting List 25
Web User Interface Window 44

Panasonic System Networks Co., Ltd.
1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:

This material is copyrighted by Panasonic System Networks Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic System Networks Co., Ltd.

© Panasonic System Networks Co., Ltd. 2012

PNQX3739VA DD0712US4103